

# **i10**

# **OWNER'S MANUAL**

Operation Maintenance Specifications

All information in this Owner's Manual is current at the time of publication. However, HYUNDAI reserves the right to make changes at any time so that our policy of continual product improvement may be carried out.

This manual applies to all models of this vehicle and includes descriptions and explanations of optional as well as standard equipment.

As a result, you may find material in this manual that does not apply to your specific vehicle.

We recommend that you contact a HYUNDAI authorised repairer for information regarding current standard and optional equipment levels.

# CAUTION: MODIFICATIONS TO ORIGINAL VEHICLE SPECIFICATION

Modification to the original vehicle specification may invalidate the manufacturers warranty and may adversely affect the safety and durability of the vehicle.

Components which are subject to modification or are added to the original vehicle specification without the express approval of the manufacturer and result in consequential loss or damage are not covered by the vehicle manufacturers warranty.

Particular attention is drawn to the fitment of replacement road wheels having a different specification to those installed in production. The electric power assisted steering system is specifically programmed to operate only with the road wheels fitted during production. The installation of alternative specification road wheels may result in the replacement road wheels fouling the vehicle body resulting in tyre damage and compromised safety. The installation of after market wheels on vehicles equipped with TPMS may result in wheel balancing difficulties or malfunction of the TPMS system.

We recommend that you contact a HYUNDAI authorised repairer before non original specification road wheels are installed.

#### TWO WAY RADIO INSTALLATION

This vehicle is fitted with electronically controlled fuel injection or other micro processor controlled equipment.

It is possible for incorrectly installed two way radio equipment including mobile telephones to adversely affect these systems.

Before radio equipment of this kind is installed, we recommend that you contact your HYUNDAI authorised repairer for recommendation regarding the suitability of the particular radio equipment concerned and the recommended method of installation and equipment location. Incorrectly installed or unsuitable equipment which gives rise to incorrect functioning of or damage to electronic vehicle components will not fall within the scope of the vehicle manufacturers warranty.

#### WARNING! (IF EQUIPPED)

The vehicle is equipped with a device of the system Pan-european eCall which calls emergency services. Any self-or unauthorised interference in the system Pan-european eCall, in vehicle systems and its components, installing of equipment which is not recommended by vehicle manufacturer and/or in HYUNDAI authorised repairerships can cause incorrect operation (of the device of) the system Pan-european eCall, making erroneous calls, causing failure of the device (in cars) in case of traffic accident or other accidents, when you need emergency care.

This may be dangerous and threaten your life!

#### SAFETY AND VEHICLE DAMAGE WARNING

This manual includes information titled as DANGER, WARNING, CAUTION and NOTICE.

These titles indicate the following:



#### DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.



#### WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.




#### **CAUTION**

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

## NOTICE

NOTICE indicates a situation which, if not avoided, could result in vehicle damage.



# **Table of contents**

Foreword	1
Vehicle information	2
Safety system	3
Instrument cluster	4
Convenience features	5
Whilst driving	6
Driver assistance system	7
Emergency situations	8
Maintenance	9
Index	1

# 1. Foreword

Foreword	1-2
Hyundai motor company	1-2
How to use this manual	1-3
Safety messages	1-3
Fuel requirementsPetrol engine	1-5 1-5
Vehicle modifications	1-8
Vehicle handling instructions	1-8
Vehicle break-in process	1-9
Returning used vehicles	1-9
Vehicle data collection and event data recorders	1-10

#### **FOREWORD**

Congratulations, and thank you for choosing HYUNDAI.We are pleased to welcome you to the growing number of discerning people who drive HYUNDAIs. We are very proud of the advanced engineering and high-quality construction of each HYUNDAI we build.

Your Owner's Manual will introduce you to the features and operation of your new HYUNDAI. To become familiar with your new HYUNDAI, so that you can fully enjoy it, read this Owner's Manual carefully before driving your new vehicle.

This manual contains important safety information and instructions intended to familiarize you with your vehicle's controls and safety features so you can safely operate your vehicle.

This manual also contains information on maintenance designed to enhance safe operation of the vehicle. It is recommended that all service and maintenance on your car be performed by a HYUNDAI authorised repairer.

HYUNDAI authorised repairers are prepared to provide high-quality service, maintenance and any other assistance that may be required.

This Owner's Manual should be considered a permanent part of your vehicle, and should be kept in the vehicle so you can refer to it at any time. The manual should stay with the vehicle if you sell it to provide the next owner with important operating. safety and maintenance information.

#### HYUNDAI MOTOR COMPANY



# **CAUTION**

Severe engine and transmission damage may result from the use of poor quality fuels and lubricants that do not meet HYUNDAI specifications. You must always use high quality fuels and lubricants that meet the specifications listed on Page 2-15 in the Vehicle Specifications section of the Owner's Manual.

Copyright 2024 HYUNDAI Motor Company, All rights reserved. No part of this publication may be reproduced, stored in any retrieval system or transmitted in any form or by any means without the prior written permission of HYUNDAI Motor Company.

#### **HOW TO USE THIS MANUAL**

We want to help you get the greatest possible driving pleasure from your vehicle. Your Owner's Manual can assist you in many ways. We strongly recommend that you read the entire manual. In order to minimise the chance of death or injury, you must read the DANGER, WARNING and CAUTION sections in the manual.

Illustrations complement the words in this manual to best explain how to enjoy your vehicle. By reading your manual, you will learn about features, important safety information, and driving tips under various road conditions.

The general layout of the manual is provided in the Table of Contents. Use the index when looking for a specific area or subject; it has an alphabetical listing of all information in your manual.

Sections: This manual has nine chapters plus an index. Each section begins with a brief list of contents so you can tell at a glance if that section has the information you want.

#### **SAFETY MESSAGES**

Your safety, and the safety of others, is very important. This Owner's Manual provides you with many safety precautions and operating procedures. This information alerts you to potential hazards that may hurt you or others, as well as damage your vehicle.

Safety messages found on vehicle labels and in this manual describe these hazards and what to do to avoid or reduce the risks.

Warnings and instructions contained in this manual are for your safety. Failure to follow safety warnings and instructions can lead to serious injury or death.

Throughout this manual DANGER, WARNING, CAUTION, NOTICE and the SAFE-TY ALERT SYMBOL will be used.



This is the safety alert symbol. It is used to alert you to potential physical injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death. The safety alert symbol precedes the signal words DANGER, WARNING and CAUTION.



DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.



WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

## NOTICE

NOTICE indicates a situation which, if not avoided, could result in vehicle damage.

#### **FUEL REQUIREMENTS**

#### **Petrol engine**

#### Unleaded

For the optimal vehicle performance, we recommend you use unleaded petrol which has an octane rating of RON (Research Octane Number) 95 / AKI (Anti Knock Index) 91 or higher. You may use unleaded petrol with an octane rating of RON 91-94 / AKI 87-90 but it may result in slight performance reduction of the vehicle. (Do not use methanol blended fuels)

Your new vehicle is designed to obtain maximum performance with UNLEADED FUEL, as well as minimise exhaust emissions and spark plug fouling.

#### NOTICE

NEVER USE LEADED FUEL. The use of leaded fuel is detrimental to the catalytic converter and will damage the engine control system's oxygen sensor and affect emission control.

Also, severe wear and crack of piston ring, valve, etc., may occur and knocking noise may be heard from your engine.

Never add any fuel system cleaning agents to the fuel tank other than what has been specified (We recommend that you consult a HYUNDAI authorised repairers for details.)

# **⚠** WAF

#### **WARNING**

- · Do not "top off" after the nozzle automatically shuts off when refuelling.
- Always check that the fuel cap is installed securely to prevent fuel spillage in the event of an accident.

#### Petrol containing alcohol and methanol

Gasohol, a mixture of petrol and ethanol (also known as grain alcohol), and petrol or gasohol containing methanol (also known as wood alcohol) are being marketed along with or instead of leaded or unleaded petrol.

Do not use gasohol containing more than 10% ethanol, and do not use petrol or gasohol containing any methanol. Either of these fuels may cause drivability problems and damage to the fuel system, engine control system and emission control system.

Discontinue using gasohol of any kind if drivability problems occur.

Vehicle damage or driveability problems may not be covered by the manufacturer's warranty if they result from the use of:

- 1. Gasohol containing more than 10% ethanol.
- 2. Petrol or gasohol containing methanol.
- 3. Leaded fuel or leaded gasohol.



Never use gasohol which contains methanol. Discontinue use of any gasohol product which impairs drivability.

#### **Using Fuel Additives**

Using fuel additives such as:

- Silicone fuel additive
- MMT (Manganese, Mn) fuel additive
- Ferrocene (iron-based) fuel additive
- Other metallic-based fuel additives

May result in cylinder misfire, poor acceleration, engine stalling, engine plugging, heavy knocking noise, damage to the catalyst, or abnormal corrosion, and may cause damage to the engine resulting in a reduction in the overall life of the powertrain. The Malfunction Indicator Light (MIL) may illuminate.

## NOTICE

Damage to the fuel system or performance problem caused by the use of these fuels may not be covered by your New Vehicle Limited Warranty.

#### Use of MTBE

HYUNDAI recommends avoiding fuels containing MTBE (Methyl Tertiary Butyl Ether) over 15.0% vol. (Oxygen Content 2.7% weight) in your vehicle.

Fuel containing MTBE over 15.0% vol. (Oxygen Content 2.7% weight) may reduce vehicle performance and produce vapour lock or hard starting.



#### **CAUTION**

Your New Vehicle Limited Warranty may not cover damage to the fuel system and any performance problems that are caused by the use of fuels containing methanol or fuels containing MTBE (Methyl Tertiary Butyl Ether) over 15.0% vol. (Oxygen Content 2.7% weight.)

#### Do not use methanol

Fuels containing methanol (wood alcohol) should not be used in your vehicle. This type of fuel can reduce vehicle performance and damage components of the fuel system, engine control system and emission control system.

#### Fuel Additives

HYUNDAI recommends that you use unleaded petrol which has an octane rating of RON (Research Octane Number) 95 / AKI (Anti Knock Index) 91 or higher (for Europe) or Octane Rating of RON (Research Octane Number) 91 / AKI (Anti-Knock Index) 87 or higher (except Europe).

For customers who do not use good quality petrols including fuel additives regularly, and have problems starting or the engine does not run smoothly, one bottle of additive added to the fuel tank according to the maintenance schedule (refer to the Service Passport in your vehicle).

Additives are available from your HYUNDAI authorised repairer along with information on how to use them. Do not mix other additives.

## Operation in foreign countries

If you are going to drive your vehicle in another country, be sure to:

- Observe all regulations regarding registration and insurance.
- · Determine that acceptable fuel is available.

#### **VEHICLE MODIFICATIONS**

- This vehicle should not be modified. Modification of your vehicle could affect its performance, safety or durability and may even violate governmental safety and emissions regulations.
  - In addition, damage or performance problems resulting from any modification may not be covered under warranty.
- If you use unauthorised electronic devices, it may cause the vehicle to operate abnormally, wire damage, battery discharge and fire. For your safety, we recommend that you do not use unauthorised electronic devices.

#### **VEHICLE HANDLING INSTRUCTIONS**

As with other vehicles of this type, failure to operate this vehicle correctly may result in loss of control, an accident or vehicle rollover.

Specific design characteristics (higher ground clearance, track, etc.) give this vehicle a higher centre of gravity than other types of vehicles. In other words they are not designed for cornering at the same speeds as conventional 2-wheel drive vehicles. Avoid sharp turns or abrupt manoeuvres. Again, failure to operate this vehicle correctly may result in loss of control, an accident or vehicle rollover. Be sure to read the "Reducing the risk of a rollover" driving guidelines, in section 6 of this manual.

#### **VEHICLE BREAK-IN PROCESS**

By following a few simple precautions for the first 600 miles (1,000 km) you may add to the performance, economy and life of your vehicle.

- · Do not race the engine.
- · Whilst driving, avoid sudden acceleration.
- Do not maintain a single speed for long periods of time, either fast or slow. Varying engine speed is needed to properly break-in the engine.
- Avoid hard stops, except in emergencies, to allow the brakes to seat properly.
- Fuel economy and engine performance may vary depending on vehicle break-in process and be stabilized after 4,000 miles (6,000 km). New engines may consume more oil during the vehicle break-in period.
- Don't tow a trailer during the first 1,200 miles (2,000 km) of operation.

#### **RETURNING USED VEHICLES**

HYUNDAI promotes an environmentally sound treatment for end of life vehicles and offers to take back your Hyundai end of life vehicles in accordance with the European Union (EU) End of Life Vehicles Directive.

You can get detailed information from your national HYUNDAI homepage.

#### VEHICLE DATA COLLECTION AND EVENT DATA RECORDERS

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less. The EDR in this vehicle is designed to record such data as:

- · How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- · How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur. NOTE: EDR data is recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (for example, name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

# 2. Vehicle information

Exterior overview (front view)	2-2
Exterior overview (rear view)	2-4
Interior overview	2-6
Centre console overview	2-7
Engine compartment overview	2-9
Dimensions	2-10
Engine specification	2-10
Bulb wattage	2-11
Tyres and wheels	2-12
Tyre load and speed capacity	2-13
Air conditioning system	2-13
Gross vehicle weight	2-14
Luggage volume	2-14
Recommended lubricants and capacities	
Vehicle Identification Number (VIN)	2-17
Vehicle certification label	
Tyre specification and pressure label	2-18
Engine number	
Air conditioner compressor label	2-19
Fuel label	2-20
Declaration of conformity	2-2
Importer information for United Kingdom	

# **EXTERIOR OVERVIEW (FRONT VIEW)**





The actual shape may differ from the illustration.

OAC3013001R

1. Bonnet	5-32
2. Headlight	
3. Daytime running light	
4. Front fog light*	
5. Tyres and wheels	
6. Outside rearview mirror	5-25
7. Front windscreen wiper blades	9-24
8. Windows	

<sup>\*:</sup> if equipped





# The actual shape may differ from the illustration.

OAC3013001R

1. Bonnet	5-32
2. Headlight	9-58
3. Daytime running light	9-60
4. Front fog light*	9-60
5. Tyres and wheels	9-30
6. Outside rearview mirror	5-25
7. Front windscreen wiper blades	9-24
8. Windows	5-28

\*: if equipped

# **EXTERIOR OVERVIEW (REAR VIEW)**

■ 5 Door



The actual shape may differ from the illustration.

OAC3013002R

1. Antenna	5-87
2. Doors	5-14
3. Fuel filler door	5-35
4. High mounted stop light	9-68
5. Rear window wiper blade*	9-25
6. Tailgate	5-33
7. Wide-rear view camera*	7-45
8. License plate light	
9. Rear ultrasonic sensors*	9-66
10. Rear combination light	
11. Rear fog light	9-66
12. Back up light	
* : if equipped	






The actual shape may differ from the illustration.

OAC3N013005TU

1. Antenna	5-87
2. Doors	5-14
3. Fuel filler door	5-35
4. High mounted stop light	9-68
5. Rear window wiper blade*	9-25
6. Tailgate	5-33
7. Wide-rear view camera*	7-45
8. License plate light	9-62
9. Rear ultrasonic sensors*	7-48
10. Rear combination light	9-66
11. Rear fog light	9-66
12. Back up light	
*: if equipped	

# **INTERIOR OVERVIEW**




The actual shape may differ from the illustration.

OAC3013003R

1. Door handle	5-16
2. Outside rearview mirror control switch	5-26
3. Outside rearview mirror folding button*	5-26
4. Power window switches	5-28
5. Power window lock switch	5-31
6. Electronic Stability Control (ESC)	6-34
7. Headlight levelling device	5-42
8. Fuse box	9-40
9. Key ignition switch	6-7
Engine Start/Stop button*	6-10
10. Steering wheel	
11. Bonnet release lever	5-32
12. Fuel filler door opener	5-35
13. Seats	
and the second s	

#### **CENTRE CONSOLE OVERVIEW**



# Vehicle information

12. Power outlet	5-79
13. Wireless mobile phone charging system*	5-81
14. USB charger	5-80
15. Seat warmers*	3-17
16. Heated steering wheel switch*	5-23
17. Idle Stop and Go (ISG) on/off switch*	6-43
18. Shift lever	6-14, 6-17
19. Passenger's front airbag	3-43
20. Glove box	5-76
21. Rear seat USB charger	5-80
*: if equipped	

# **ENGINE COMPARTMENT OVERVIEW**

■ Smartstream G1.0



■ Smart stream G1.0 T-GDi



■ Smartstream G1.2



The actual engine room in the vehicle may differ from the illustration.

OAC3089001R/OAC3N080001R/OAC3089002R

1. Engine coolant reservoir	9-14
2. Engine oil filler cap	9-12
3. Brake/Clutch* fluid reservoir	9-17
4. Air cleaner	9-20
5. Fuse box	9-40
6. Battery	9-26
7. Windscreen washer fluid reservoir	9-19
8. Radiator cap	9-14
9. Engine oil dipstick	9-11
* : if equipped	

# **DIMENSIONS**

in. (mm)

Iten	ns	5 Door	N line
Overall length		144.49 (3,670)	144.68 (3,675)
Overall width		66.14 (1,680)	66.14 (1,680)
Overall height		58.27 (1,480)	58.38 (1,483)
	175/65R14	58.23 (1,479)	-
Front tread	185/55R15	57.76 (1,467)	-
	195/45R16	57.76 (1,467)	57.76 (1,467)
	175/65R14	58.66 (1,490)	-
Rear tread	185/55R15	58.19 (1,478)	-
	195/45R16	58.19 (1,478)	58.19 (1,478)
Wheelbase		95.47 (2,425)	95.47 (2,425)

# **ENGINE SPECIFICATION**

		Petrol Engine Smartstream   Sm							
Item	Item		Smartstream G1.2	Smartstream G1.0 T-GDi					
Displacement	cc (cu. in)	998 (60.90)	1,197 (73.05)	998 (60.90)					
Bore x Stroke	in. (mm)	2.80x3.31 (71.0x84.0)	2.80x2.98 (71.0x75.6)	2.80x3.31 (71.0x84.0)					
Firing order		1-2-3	1-3-4-2	1-2-3					
No. of cylinders	S	3	4	3					

# **BULB WATTAGE**

	Light Bulb		Bulb type	Wattage
	Type A*1	Headlight (High/Low)	H19	60/55
	31	Turn signal light	PY21WLL	21
		Headlight (High/Low)	НВ3	60
	Type B*2	Low beam assist- Static light	H7LL	55
Front		Turn signal light	PY21WLL	21
	Fog light *	51W	51	
	Position light &	Type A	P21/5WLL	21/5
	Daytime Running Light (DRL)	Type B	LED	LED
	Side repeater light (Outside Mi	LED	LED	
	Side repeater light *		WY5W	5
	Туре А	Tail and stop light	P21/5WLL	21/5
	Tuno D	Tail light	LED	LED
	Type B	Stop light	P21WLL	21
	Turn signal light		PY21WLL	21
Rear	Reflex reflector	-	-	
	Back up light	W16W	16	
	Fog light	P21WLL	21	
	High mounted stop light	LED	LED	
	License plate lights		W5WLL	5
Interior	Map lamp		FESTOON	8
menor	Luggage room lamp		FESTOON	10

<sup>\*:</sup> If equipped

<sup>\*1:</sup> MFR (Multi Focus Reflector) Headlight

<sup>\*2 :</sup> Bi-Function Projection Headlight

#### **TYRES AND WHEELS**

			Inf	lation pressu	Inflation pressure, bar (psi, kPa)	Pa)	Wheel lug nut
item	Tyre size	Wheel	Normal	Normal load *1	Maxim	Maximum load	torque lbf·ft
			Front	Rear	Front	Rear	(kgf·m, N·m)
	175/65R14	5.5JX14	230,33 (2.3)	210,30 (2.1)	5.5JX14   230,33 (2.3)   210,30 (2.1)   230,33 (2.3)   250,36 (2.5)	250,36 (2.5)	
Full size tyre	185/55R15	6.0JX15	230,33 (2.3)	210,30 (2.1)	185/55R15 6.0JX15 230,33 (2.3) 210,30 (2.1) 230,33 (2.3) 250,36 (2.5)	250,36 (2.5)	11-13
	195/45R16	6.5JX16	230,33 (2.3)	210,30 (2.1)	95/45R16 6.5JX16 230,33 (2.3) 210,30 (2.1) 230,33 (2.3) 250,36 (2.5)	250,36 (2.5)	107-127)
Temporary tyre *2   T115/70D15   3.5JX15	T115/70D15	3.5JX15		420,6	420,60 (4.2)		,

<sup>1:</sup> Normal load: Up to 3 persons

- are expected soon. Tyres typically lose 1 psi (7 kPa) for every 7°C (12°F) temperature drop. If extreme · It is permissible to add 3 psi (20 kPa) to the standard tyre pressure specification if colder temperatures temperature variations are expected, recheck your tyre pressure as necessary to keep them properly
- An air pressure generally decreases, as you drive up to a high-altitude area above sea level. Thus, if you If necessary, inflate them to a proper level (Air inflation per altitude: +2.4 psi/1 mile (+10 kPa/1 km). plan to drive a high-altitude area, check the tyre pressures in advance.
- Do not exceed maximum inflation pressure shown on equipped tire sidewall.

# CAUTION

When replacing tires, ALWAYS use the same size, type, brand, construction and tread pattern supplied with the vehicle. If not, it can damage the related parts or make it work irregularly.

<sup>2:</sup> If your vehicle is not equipped with a temporary tyre, a Tyre Mobility Kit will be provided with your vehicle.

# **AIR CONDITIONING SYSTEM**

Item		Weight of Volume	Classification
Refrigerant	oz. (g)	15.17±0.88 (430±25)	R-134a R-1234yf
Compressor lubricant	oz. (g)	3.53 (100)	PAG

We recommend that you contact a HYUNDAI authorised repairer for more details.

## TYRE LOAD AND SPEED CAPACITY

lto	Tyro oizo	Wheel	Load C	apacity	Speed Capacity		
Item	Tyre size	size	LI *1	kg	SS *2	mph (km/h)	
	175/65R14	5.5JX14	86	530	Т	118 (190)	
Full size tyre	185/55R15	6.0JX15	86	530	Η	130 (210)	
	195/45R16	6.5JX16	84	500	Η	130 (210)	
Temporary tyre	T115/70D15	3.5JX15	90	600	М	81 (130)	

<sup>\*1</sup> LI : LOAD INDEX \*2 SS : SPEED SYMBOL

# **GROSS VEHICLE WEIGHT**

lbs. (kg)

		4 S	eater		
Sn	nartstream G	1.0	Smartstream G1.0 T-GDi	Smartstr	eam G1.2
AMT	МТ	MT (ECO)	MT	AMT	MT
2,954 (1,340)	2,954 (1,340)	2,888 (1,310)	3,042 (1,380)	2,976 (1,350)	2,976 (1,350)

		5 Seater		
Smartstr	eam G1.0	Smartstream G1.0 T-GDi	Smartstr	eam G1.2
AMT	MT	MT	AMT	MT
3,108 (1,410)	3,108 (1,410)	3,240 (1,470)	3,152 (1,430)	3,152 (1,430)

# **LUGGAGE VOLUME**

	Items		Petrol Engine
VDA		MIN.	252 (8.90)
	l (cu ft)	MAX.	1,050 (37.08)

Min: Behind rear seat to upper edge of the seat back.

Max : Behind front seat to roof.

#### **RECOMMENDED LUBRICANTS AND CAPACITIES**

To help achieve proper engine and powertrain performance and durability, use only lubricants of the proper quality. The correct lubricants also help promote engine efficiency that results in improved fuel economy.

These lubricants and fluids are recommended for use in your vehicle.

	bricant		Volume	Classification
Engine oil *1 *2 (drain and refill)	Smartstream	G1.0	3.1 <i>l</i> (2.73 lmp qt.)	
Shell HELIX ULTRA	Smartstream	G1.2	3.4 <i>l</i> (2.99 lmp qt.)	SAE 0W20, API SN PLUS/ SP or ILSAC GF-6
Motor oils	Smartstream T-GDi	G1.0	3.6 <i>l</i> (3.16 lmp qt.)	
Manual 5 Door transmission			1.3-1.4 <i>l</i> (1.14-1.23 lmp qt.)	API GL-4, SAE 70W - SK : HK SYN MTF 70W - H.K.SHELL : SPIRAX S6
fluid N line		1.6-1.7 <i>l</i> (1.40-1.50 lmp qt.)	GHME 70W MTF - GS CALTEX : GS MTF HD 70W	
Automated manual transmission fluid			1.1-1.2 <i>l</i> (0.96-1.05 lmp qt.)	API GL-4, SAE 70W - SK: HK SYN MTF 70W - H.K.SHELL: SPIRAX S6 GHME 70W MTF - GS CALTEX: GS MTF HD 70W
	Smartstream	AMT	5.51 <i>l</i> (4.85 lmp qt.)	
Coolont	G1.0	МТ	5.53 <i>l</i> (4.87 lmp qt.)	MIXTURE, Antifreeze with water (Ethylene glycol base
Coolani	Coolant Smartstream G1		5.89 <i>l</i> (5.18 lmp qt.)	coolant for aluminium radia- tor)
	Smartstream G1 T-GDi		6.02 <i>l</i> (5.30 lmp qt.)	
Brake/Clutch flu	iid		0.7-0.8 <i>l</i> (0.62-0.7 lmp qt.)	FMVSS116 DOT-4
Fuel			36 l (7.92 lmp gal.)	-

<sup>\*1:</sup> Refer to the recommended SAE viscosity numbers on the next page.

<sup>\*2:</sup> If the above recommended specification oil is not available, SAE 0W-20 grade synthetic oil can be used.

## **Recommended SAE viscosity number**



#### **CAUTION**

- Always be sure to clean the area around any filler plug, drain plug, or dipstick before checking or draining any lubricant. This is especially important in dusty or sandy areas and when the vehicle is used on unpaved roads. Cleaning the plug and dipstick areas will prevent dirt and grit from entering the engine and other mechanisms that could be damaged.
- Never add any additives to the engine oil. Engine oil additives can change the properties of engine oil and may cause serious engine failure.

Engine oil viscosity (thickness) has an effect on fuel economy and cold weather operating (engine start and engine oil flowability). Lower viscosity engine oils can provide better fuel economy and cold weather performance, however, higher viscosity engine oils are required for satisfactory lubrication in hot weather. Using oils of any viscosity other than those recommended could result in engine damage.

When choosing an oil, consider the range of temperature your vehicle will be operated in before the next oil change.

Proceed to select the recommended oil viscosity from the chart.

	Temperature Range for SAE Viscosity Numbers										
Tomporatura	°C	-30	-20		-10	0	10	20	30	40	50
Temperature	(°F)	-	10	0	20		40	60	80	100	120
Petrol Engine C	Oil *1						0W-	20			

<sup>\*1:</sup> If mineral oil or semi-synthetic oil is used, it is a severe maintenance condition in terms of engine oil change.




An engine oil displaying this American Petroleum Institute(API) Certification Mark conforms to the International Lubricant Specification Advisory Committee (ILSAC). It is recommended to only use engine oils that uphold this API Certification Mark.

# VEHICLE IDENTIFICATION NUMBER (VIN)



The vehicle identification number (VIN) is the number used in registering your vehicle and in all legal matters pertaining to its ownership, etc.

The number is punched on the floor under the driver seat. To check the number, open the cover.



The VIN is also on a plate attached to the top of the dashboard. The number on the plate can easily be seen through the windscreen from outside.

# VEHICLE CERTIFICATION LABEL



The vehicle certification label attached on the driver's (or front passenger's) side centre pillar gives the vehicle identification number (VIN).


# TYRE SPECIFICATION AND PRESSURE LABEL



The tyres supplied on your new vehicle are chosen to provide the best performance for normal driving.

The tyre label located on the left side centre pillar gives the tyre pressures recommended for your vehicle.

### **ENGINE NUMBER**



The engine number is stamped on the engine block as shown in the drawing.


# AIR CONDITIONER COMPRESSOR LABEL



A compressor label informs you the type of compressor your vehicle is equipped with such as model, supplier part number, production number, refrigerant (1) and refrigerant oil (2).

# **FUEL LABEL (IF EQUIPPED)**

The fuel label is attached on the fuel filler door.



- A. Octane rating of unleaded Petrol
  - 1) RON/ROZ: Research Octane Number
  - 2) (R+M)/2, AKI: Anti Knock Index
- B. Identifiers for Petrol-type fuels
  - \* This symbol means usable fuel. Do not use any other fuel.
- C. For further details, refer to the "Fuel Requirement" section in chapter 1.

# DECLARATION OF CONFORMITY (IF EQUIPPED)

# **C€ C€** 0678

CE0678

The radio frequency components of the vehicle comply with requirements and other relevant provisions of Directive 1995/5/EC.

Further information including the manufacturer's declaration of conformity is available on Hyundai web site as follows:

http://service.hyundai-motor.com

# IMPORTER INFORMATION FOR UNITED KINGDOM



OANATEL454-1

Name: HYUNDAI Motor UK Limited Address: Birchwood, Springfield Dr, Leatherhead KT22 7LP, UK

# 3. Safety system

Important safety precautions	3-2
Always wear your seat belt	
Restrain all children	3-2
Airbag hazards	3-2
Driver distraction	3-2
Control your speed	3-3
Keep your vehicle in safe condition	3-3
Seats	3-4
Safety precautions	
Front seats	
Rear seats	3-10
Head restraint	3-12
Seat warmers	3-17
Seat belts	3-19
Seat belt safety precautions	
Seat belt warning light	3-20
Seat belt restraint system	3-22
Pre-tensioner seat belt	3-24
Additional seat belt safety precautions	3-27
Care of seat belts	3-29
Child Restraint System (CRS)	3-30
Our recommendation: Children always in the rear	
Selecting a Child Restraint System (CRS)	3-31
Installing a Child Restraint System (CRS)	3-32
Airbag - supplemental restraint system	3-41
Where are the airbags?	
How does the airbags system operate?	3-48
What to expect after an airbag inflates	
Do not install a child restraint on the front passenger seat	
Why didn't my airbag go off in a collision?	
SRS Care	3-58
Additional safety precautions	3-59
Airbag warning labels	

#### IMPORTANT SAFETY PRECAUTIONS

You will find many safety precautions and recommendations throughout this section, and throughout this manual. The safety precautions in this section are among the most important.

# Always wear your seat belt

A seat belt is your best protection in all types of accidents. Airbags are designed to supplement seat belts, not replace them. So even though your vehicle is equipped with airbags, ALWAYS make sure you and your passengers wear your seat belts, and wear them properly.

#### Restrain all children

All children under age 13 should ride in your vehicle properly restrained in a rear seat, not the front seat. Infants and small children should be restrained in an appropriate child restraint. Larger children should use a booster seat with the lap/shoulder belt until they can use the seat belt properly without a booster seat.

# Airbag hazards

Whilst airbags can save lives, they can also cause serious or fatal injuries to occupants who sit too close to them, or who are not properly restrained. Infants, young children, and short adults are at the greatest risk of being injured by an inflating airbag. Follow all instructions and warnings in this manual.

## **Driver distraction**

Driver distraction presents a serious and potentially deadly danger, especially for inexperienced drivers. Safety should be the first concern when behind the wheel and drivers need to be aware of the wide array of potential distractions, such as drowsiness, reaching for objects, eating, personal grooming, other passengers, and using mobile phones.

Drivers can become distracted when they take their eyes and attention off the road or their hands off the wheel to focus on activities other than driving. To reduce your risk of distraction and an accident:

- ALWAYS set up your mobile devices (for example, MP3 players, phones, navigation units, etc.) when your vehicle is parked or safely stopped.
- ONLY use your mobile device when allowed by laws and conditions permit safe use.
  - NEVER text or email whilst driving. Most countries have laws prohibiting drivers from texting. Some countries and cities also prohibit drivers from using handheld phones.
- NEVER let the use of a mobile device distract you from driving. You have a responsibility to your passengers and others on the road to always drive safely, with your hands on the wheel as well as your eyes and attention on the road.


# **Control your speed**

Excessive speed is a major factor in crash injuries and deaths. Generally, the higher the speed, the greater the risk, but serious injuries can also occur at lower speeds. Never drive faster than is safe for current conditions, regardless of the maximum speed posted.

# Keep your vehicle in safe condition

Having a tyre blowout or a mechanical failure can be extremely hazardous. To reduce the possibility of such problems, check your tyre pressures and condition frequently, and perform all regularly scheduled maintenance.

# **SEATS**



The actual feature in the vehicle may differ from the illustration.

OAC3033001R

## Front seats

- 1. Forward and backward
- 2. Seatback angle
- 3. Seat height\*
- 4. Head restraint
- 5. Sear warmer\*

## **Rear seats**

- 6. Head restraint (outboard and/or centre\*)
- 7. Seatback folding
- \*: if equipped

# Safety precautions

Adjusting the seats so that you are sitting in a safe, comfortable position plays an important role in driver and passenger safety together with the seat belts and airbags in an accident.



Do not use a cushion that reduces friction between the seat and the passenger. The passenger's hips may slide under the lap portion of the seat belt during an accident or a sudden stop. Serious or fatal internal injuries could result because the seat belt cannot operate properly.

## Airbaas

You can take steps to reduce the risk of being injured by an inflating airbag. Sitting too close to an airbag greatly increases the risk of injury in the event the airbag inflates. Move your seat as far back as possible from front airbags. whilst still maintaining control of the vehicle.



# **⚠ WARNING**

To reduce the risk of serious injury or death from an inflating airbag, take the following precautions:

- · Adjust the driver's seat as far to the rear as possible whilst maintaining the ability to maintain full control of the vehicle.
- · Adjust the front passenger seat as far to the rear as possible.
- Hold the steering wheel by the rim with your hands at the 9 o'clock and 3 o'clock positions to minimise the risk of injuries to your hands and arms.
- NEVER place anything or anyone between the airbag.
- Do not allow the front passenger to place feet or legs on the dashboard to minimise the risk of leg injuries.

#### Seat belts

Always fasten your seat belt before starting any trip.

At all times, passengers should sit upright and be properly restrained. Infants and small children must be restrained in appropriate child restraint systems. Children who have outgrown a booster seat and adults must be restrained using the seat belts.



# **WARNING**

Take the following precautions when adjusting your seat belt:

- · NEVER use one seat belt for more than one occupant.
- Always position the seatback upright with the lap portion of the seat belt snug and low across the hips.
- · NEVER allow children or small infants to ride in a passenger's lap.
- · Do not route the seat belt across your neck, across sharp edges, or reroute the shoulder strap away from your body.
- · Do not allow the seat belt to become caught or jammed.

#### Front seats

The front seat can be adjusted by using the control lever or switches located on the outside of the seat cushion. Before driving, adjust the seat to the proper position so that you can easily control the steering wheel, foot pedals and controls on the instrument panel.



# ! WARNING

Take the following precautions when adjusting your seat:

- NEVER attempt to adjust the seat whilst the vehicle is moving. The seat could respond with unexpected movement and may cause loss of vehicle control resulting in an accident.
- · Do not place anything under the front seats. Loose objects in the driver's foot area could interfere with the operation of the foot pedals, causing an accident.
- Do not allow anything to interfere with the normal position and proper locking of the seatback.
- · Do not place a cigarette lighter on the floor or seat. When you operate the seat, gas may exit out of the lighter causing a fire.
- Use extreme caution when picking small objects trapped under the seats or between the seat and the centre console. Your hands might be cut or injured by the sharp edges of the seat mechanism.

- If there are occupants in the rear seats, be careful whilst adjusting the front seat position.
- Make sure that the seat is locked in place after the adjustment. If not, the seat might move unexpectedly resulting in an accident.

# **A** CAUTION

# To prevent injury:

- Do not adjust your seat whilst wearing your seat belt. Moving the seat cushion forward may cause strong pressure on your abdomen.
- Do not allow your hands or fingers to get caught in the seat mechanisms whilst the seat is moving.

# Forward and rearward adjustment



To move the seat forward or rearward:

- 1. Pull up the seat slide adjustment lever and hold it.
- 2. Slide the seat to the position you desire.
- Release the lever and make sure the seat is locked in place. Move forward and rearward without using the lever. If the seat moves, it is not locked properly.

## Seatback angle



To recline the seatback:

- Lean forward slightly and lift up the seatback lever.
- Carefully lean back on the seat and adjust the seatback to the position you desire.
- Release the lever and make sure the seatback is locked in place. (The lever MUST return to its original position for the seatback to lock.)

#### Reclining seatback

Sitting in a reclined position when the vehicle is in motion can be dangerous. Even when buckled up, the protections of your restraint system (seat belts and/ or airbags) is greatly reduced by reclining your seatback.

# A

# WARNING

NEVER ride with a reclined seatback when the vehicle is moving.

Riding with a reclined seatback increases your chance of serious or fatal injuries in the event of a collision or sudden stop.


Drivers and passengers should ALWAYS sit well back in their seats, properly belted, and with the seatbacks upright.

Seat belts must be snug against your hips and chest to work properly. When the seatback is reclined, the shoulder belt cannot do its job because it will not be snug against your chest. Instead, it will be in front of you.

During an accident, you could be thrown into the seat belt, causing neck or other injuries.

The more the seatback is reclined, the greater chance the passenger's hips will slide under the lap belt or the passenger's neck will strike the shoulder belt.


# Seat height (for driver's seat, if equipped)



To change the height of the seat cushion:

- Push down the lever several times, to lower the seat cushion.
- Pull up the lever several times, to raise the seat cushion.

# Armrest (for driver's seat, if equipped)



Pull the armrest down to use it.

# Seatback pocket (if equipped)



The seatback pocket is provided on the back of the front seatback.



Do not put heavy or sharp objects in the seatback pockets. In an accident they could come loose from the pocket and injure occupants.


# Rear seats (if equipped)

The rear seatbacks can be folded to facilitate carrying long items or to increase the luggage capacity of the vehicle.

# **⚠** WARNING

- Never allow passengers to sit on top of the folded down seatback whilst the vehicle is moving. This is not a proper seating position and no seat belts are available for use. This could result in serious injury or death in case of an accident or sudden stop.
- Objects carried on the folded down seatback should not extend higher than the top of the front seatbacks.
   This could allow cargo to slide forward and cause injury or damage during sudden stops.

- Set the front seatback to the upright position and if necessary, slide the front seat forward.
- Lower the rear head restraints to the lowest position (if equipped with adjustable head restraints).



 Insert the rear lap/shoulder belt plate into the holder on the side trim. It will prevent the lap/shoulder belt from interfering with the seatback when folding.





 Pull up the seatback lever and fold the seatback toward the front of the vehicle

To use the rear seat, lift and push up the seatback backward. Push the seatback firmly until it clicks into place. Make sure the seatback is locked in place.

When returning the rear seatbacks to the upright position, remember to return the rear shoulder belts to their proper position.

# **MARNING**

When you return the rear seatback to its upright position after being folded down:

Be careful not to damage the seat belt webbing or buckle. Do not allow the seat belt webbing or buckle to get caught or pinched in the rear seat. Ensure that the seatback is completely locked into its upright position by pushing on the top of the seatback. Otherwise, in an accident or sudden stop, the seat could fold down and allow cargo to enter the passenger compartment, which could result in serious injury or death.

## NOTICE

- When returning the rear seatbacks to the upright position, remember to return the rear shoulder belts to their proper position.
- Routing the seat belt webbing through the rear seat belt guides will help keep the seat belts from being trapped behind or under the seats.



# **⚠** WARNING

## Cargo

Cargo should always be secured to prevent it from being thrown about the vehicle in a collision and causing injury to the vehicle occupants. Do not place objects in the rear seats, since they cannot be properly secured and may hit the front seat occupants in a collision.



# **⚠ WARNING**

## Cargo loading

Make sure the engine is off, the Automated manual transmission is in N (Neutral) or the Manual transmission is in R (Reverse) or 1st, and the parking brake is securely applied whenever loading or unloading cargo. Failure to take these steps may allow the vehicle to move if the shift lever is inadvertently moved to another position.


## Head restraint

The vehicle's front and rear seats have adjustable head restraints. The head restraints provide comfort for passengers, but more importantly they are designed to help protect passengers from whiplash and other neck and spinal injuries during an accident, especially in a rear impact collision.

# WARNING

To help reduce the risk of serious injury or death in an accident, take the following precautions when adjusting your head restraints:

· Always properly adjust the head restraints for all passengers BEFORE starting the vehicle.



Adjust the head restraints so the middle of the head restraints is at the same height as the height of the top of the eyes.

- NEVER adjust the head restraint position of the driver's seat when the vehicle is in motion.
- Adjust the head restraint as close to the passenger's head as possible. Do not use a seat cushion that holds the body away from the seatback.
- Make sure the head restraint locks into position after adjusting it.

# **⚠** WARNING



OTL035061

When sitting on the rear seat, do not adjust the height of the headrest to the lowest position.

# NOTICE

To prevent damage, NEVER hit or pull on the head restraints.

# **A** CAUTION

When there is no occupant in the rear seats, adjust the height of the head restraint to the lowest position. The rear seat head restraint can reduce the visibility of the rear area.


#### Front seat head restraints



The driver's and front passenger's seats are equipped with adjustable head restraints for the passengers safety and comfort.



Forward and rearward adjustment
The head restraint may be adjusted forward to 3 different positions by pulling the head restraint forward to the desired detent. To adjust the head restraint to it's furthest rearwards position, pull it fully forward to the farthest position and release it.



Adjusting the height up and down To raise the head restraint:

1. Pull it up to the desired position (1).

To lower the head restraint:

- 1. Push and hold the release button (2) on the head restraint support.
- 2. Lower the head restraint to the desired position (3).

# NOTICE



If you recline the seatback towards the front with the head restraint and seat cushion raised, the head restraint may come in contact with the sunvisor or other parts of the vehicle.




#### Removal/Reinstall

To remove the head restraint:

- 1. Recline the seatback (2) using the seatback angle lever or switch (1).
- 2. Raise head restraint as far as it can go.
- 3. Press the head restraint release button (3) whilst pulling the head restraint up (4).



NEVER allow anyone to travel in a seat with the head restraint removed.




To reinstall the head restraint:

- 1. Recline the seatback.
- 2. Put the head restraint poles (2) into the holes whilst pressing the release button (1).
- 3. Adjust the head restraint to the appropriate height.
- 4. Recline the seatback (4) using seatback angle lever or switch (3).

# **WARNING**


Always make sure the head restraint locks into position after reinstalling and adjusting it properly.

#### Rear seat head restraints



\*: 5 Seater

The rear seats are equipped with head restraints in all the seating positions for the passenger's safety and comfort.




Adjusting the height up and down To raise the head restraint:

1. Pull it up to the desired position (1).

#### To lower the head restraint:

- 1. Push and hold the release button (2) on the head restraint support.
- 2. Lower the head restraint to the desired position (3).



#### Removal and installation

To remove the head restraint:

- 1. Raise it as far as it can go.
- 2. Press the release button (1) whilst pulling upward (2).

#### To reinstall the head restraint:

- 1. Put the head restraint poles (3) into the holes whilst pressing the release button (1).
- 2. Adjust the head restraint to the appropriate height.

# **Seat warmers (if equipped)**

Seat warmers are provided to warm the seats during cold weather.



The seat warmers can cause a SERI-OUS BURN, even at low temperatures and especially if used for long periods of time.

Passengers must be able to feel if the seat is becoming too warm so they can turn it off, if needed.

People who cannot detect temperature change or pain to the skin should use extreme caution, especially the following types of passengers:

- Infants, children, elderly or disabled persons, or hospital outpatients.
- People with sensitive skin or who burn easily.
- Fatigued individuals.
- · Intoxicated individuals.
- People taking medication that can cause drowsiness or sleepiness.

# **MARNING**

NEVER place anything on the seat that insulates against heat when the seat warmer is in operation, such as a blanket or seat cushion. This may cause the seat warmer to overheat, causing a burn or damage to the seat.

# NOTICE

To prevent damage to the seat warmers and seats:


- Never use a solvent such as paint thinner, benzene, alcohol or petrol to clean the seats.
- Do not place heavy or sharp objects on seats equipped with seat warmers.
- Do not change the seat cover. It may damage the seat warmer or air ventilation system.



Whilst the engine is running, push either of the switches to warm the driver's seat or front passenger's seat.

During mild weather or under conditions where the operation of the seat warmer is not needed, keep the switches in the OFF position.

 Each time you push the switch, the temperature setting of the seat is changed as follows:



- The seat warmer defaults to the OFF position whenever the ignition switch is turned on.
- When pressing the switch for more than 1.5 seconds with the seat warmer operating, the seat warmer will turn OFF.

#### **SEAT BELTS**

This section describes how to use the seat belts properly. It also describes some of the things not to do when using seat belts.

# Seat belt safety precautions

Always fasten your seat belt and make sure all passengers have fastened their seat belts before starting any trip. Airbags (if equipped) are designed to supplement the seat belt as an additional safety device, but they are not a substitute. Most countries require all occupants of a vehicle to wear seat belts.

# **⚠** WARNING

Seat belts must be used by ALL passengers whenever the vehicle is moving. Take the following precautions when adjusting and wearing seat belts:

- ALWAYS properly restrain children under age 13 in the rear seats.
- NEVER allow children to ride in the front passenger seat. If a child age 13 or older must be seated in the front seat, move the seat as far back as possible. And the child must always be restrained in the seat properly.
- NEVER allow an infant or child to be carried on an occupant's lap.
- NEVER ride with the seatback reclined when the vehicle is moving.
- Do not allow children to share a seat or seat belt.
- Do not wear the shoulder belt under your arm or behind your back.
- Never wear a seat belt over fragile objects. If there is a sudden stop or impact, the seat belt can damage it.

- Do not use the seat belt if it is twisted. A twisted seat belt will not protect you properly in an accident.
- Do not use a seat belt if the webbing or hardware is damaged.
- Do not latch the seat belt into the buckles of other seats.
- NEVER unfasten the seat belt whilst driving. This may cause loss of vehicle control resulting in an accident.
- Make sure there is nothing in the buckle interfering with the seat belt latch mechanism, because any materials in the buckle can cause the seat belt not to be fastened securely.
- No modifications or additions should be made by the user which will either prevent the seat belt adjusting devices from operating to remove slack, or prevent the seat belt assembly from being adjusted to remove slack.

# **!** WARNING

Damaged seat belts and seat belt assemblies will not operate properly. Always replace:

- Frayed, contaminated, or damaged webbing.
- · Damaged hardware.
- The entire seat belt assembly after it has been worn in an accident, even if damage to webbing or assembly is not apparent.

# Seat belt warning light Driver's seat belt



Regardless of the driver's seat belt fastening, the warning light will illuminate for about 6 seconds each time you turn the ignition switch ON. If the driver's seat belt is not fastened, the warning chime will sound for about 6 seconds and the waning light will stay ON until the driver's seat belt is fastened.

If you start to drive without the driver's seat belt fastened, when vehicle speed is below 12 mph (20 km/h), the warning light will illuminate.

When vehicle speed is 12 mph (20 km/h) or faster, the warning light will blink and warning chime will sound for about 100 seconds.

If the driver's seat belt is unfastened whilst driving, the warning light will illuminate when vehicle speed is below 12 mph (20 km/h). When vehicle speed is 12 mph (20 km/h) and faster, the warning light will blink and warning chime will sound for about 100 seconds.

# Front passenger's seat belt (if equipped)

Regardless of the passenger's seat belt fastening, the warning light will illuminate for about 6 seconds each time you turn the ignition switch ON. If the passenger's seat belt is not fastened, the waning light will stay turned ON until the passenger's seat belt is fastened.

If you start to drive without the passenger's seat belt fastened, when vehicle speed is below 12 mph (20 km/h), the warning light will illuminate.

When vehicle speed is 12 mph (20 km/h) or faster, the warning light will blink and warning chime will sound for about 100 seconds.

If the passenger's seat belt is unfastened whilst driving, the warning light will illuminate when vehicle speed is below 12 mph (20 km/h). When vehicle speed is 12 mph (20 km/h) and faster, the warning light will blink and warning chime will sound for about 100 seconds



Riding in an improper position adversely affects the front passenger's seat belt warning system. It is important for the driver to instruct the passenger to properly be seated as instructed in this manual.

# *i* Information

- Although the front passenger seat is not occupied, the seat belt warning light will blink or illuminate for 6 seconds. Also, when the front passenger gets off the vehicle whilst the warning is activating, the warning may continue for 6 seconds even after the passenger gets off.
- The front passenger's seat belt warning may operate when luggage, laptop or other electronic device is aced on the front passenger seat.

# Rear seat belt warning (if equipped)



Rear left (1) and right side (3) seat

As a reminder to the rear passenger, the rear passenger's seat belt warning lights will illuminate for about 6 seconds each time you turn the ignition switch ON regardless of belt fastening.

If the seat belt is not fastened when the ignition switch is turned ON, the corresponding warning light will illuminate until the seat belt is fastened.

If you start to drive without the seat belt fastened or you unfasten the seat belt when vehicle speed is below 12 mph (20 km/h), the corresponding warning light will continue to illuminate until you fasten the seat belt.

If you continue to drive without the seat belt fastened or you unfasten the seat belt when vehicle speed is 12 mph (20 km/h) or faster, the seat belt warning chime will sound for about 35 seconds and the corresponding warning light will blink.

When the seat belt is unfastened whilst driving, the warning lights will illuminate when vehicle speed is below 12 mph (20 km/h).

When vehicle speed is 12 mph (20 km/h) or faster, the warning light will blink and warning chime will sound for about 35 seconds.

Rear centre seat (2) (5 Seater, if equipped)

As a reminder to the rear passenger, the rear passenger's seat belt warning lights will illuminate for about 6 seconds each time you turn the ignition switch ON regardless of belt fastening.

Whether or not a passenger is seated:

If the seat belt is not fastened when the ignition switch is turned ON, the seat belt warning light will illuminate for about 70 seconds.

If you start to drive without the seat belt fastened the corresponding warning light will continue to illuminate for about 70 seconds regardless of vehicle speed.

If you unfasten the seat belt when vehicle speed is below 12 mph (20 km/h), the corresponding warning light will illuminate for about 70 seconds. If you unfasten the seat belt when vehicle speed is above 12 mph (20 km/h), the seat belt warning chime will sound for about 35 seconds and the corresponding warning light will blink.

If the rear door is opened whilst driving below 12 mph (20 km/h), the warning light and warning sound will not operate even if vehicle speed is above 12 mph (20 km/h).

# **MARNING**

Riding in an improper position adversely affects the rear passenger's seat belt warning system. It is important for the driver to instruct the passenger to be seated properly as instructed in this manual.

# *i* Information

- Although the rear side passenger seat is not occupied, the seat belt warning light will blink or illuminate for 6 seconds.
- You can find the front passenger's seat belt warning light on the centre fascia panel.
- The rear side passenger's seat belt warning may operate when luggage, laptop or other electronic device is placed on the rear side passenger seat.

# Seat belt restraint system Lap/shoulder belt



To fasten your seat belt:

Pull it out of the retractor and insert the metal tab (1) into the buckle (2). There will be an audible "click" when the tab locks into the buckle.



You should place the lap belt (1) portion across your hips and the shoulder belt (2) portion across your chest.

The seat belt automatically adjusts to the proper length after the lap belt portion is adjusted manually so that it fits snugly around your hips. If you lean forward in a slow, easy motion, the belt will extend and move with you.

If there is a sudden stop or impact, the belt will lock into position. It will also lock if you try to lean forward too quickly.

# NOTICE

If you are not able to smoothly pull enough of the seat belt out from the retractor, firmly pull the seat belt out and release it. After release, you will be able to pull the belt out smoothly.

# **⚠** WARNING



Improperly positioned seat belts may increase the risk of serious injury in an accident. Take the following precautions when adjusting the seat belt:

- Position the lap portion of the seat belt as low as possible across your hips, not on your waist, so that it fits snugly. This allows your strong pelvic bones to absorb the force of the crash, reducing the chance of internal injuries.
- Position one arm under the shoulder belt and the other over the belt, as shown in the illustration.
- Always position the shoulder belt anchor into locked position at the appropriate height.
- Never position the shoulder belt across your neck or face.




To release your seat belt:

Press the release button (1) in the lockina buckle.

When it is released, the belt should automatically draw back into the retractor. If this does not happen, check the belt to be sure it is not twisted, then try again.

## Rear centre seat helt



When using the rear centre seat belt, the buckle with the "CENTER" mark must be used



If you are not able to pull out the safety belt from the retractor, firmly pull the belt out and release it. After release, vou will be able to pull the belt out smoothly.

# Pre-tensioner seat belt (if equipped)



- (1) Retractor pretensioner seat belt
- (2) EFD (Emergency Fastening Device) system (Driver only, if equipped)

Your vehicle is equipped with driver's and front passenger's and rear left side and right side passenger's pre-tensioner seat belts (Retractor Pre-tensioner) and EFD (Emergency Fastening Device)).

The purpose of the pre-tensioner is to make sure the seat belts fit tightly against the occupant's body in certain frontal or side collision(s). The pre-tensioner seat belts may be activated in crashes where the frontal or side collision(s) is severe enough, together with the airbags.

When the vehicle stops suddenly, or if the occupant tries to lean forward too quickly, the seat belt retractor will lock into position.

# **WARNING**

Make sure that the seatback is locked in place when using the rear center seat belt.

If not, the seatback may move when there is a sudden stop or collision, which could result in serious injury.

In certain frontal collisions, the pretensioner will activate and pull the seat belt into tighter contact against the occupant's body.

- Retractor Pretensioner
  - The purpose of the retractor pretensioner is to make sure that the shoulder belts fit in tightly against the occupant's upper body in certain frontal or side collision(s).
- EFD (Emergency Fastening Device) The purpose of the EFD is to make sure that the pelvis belts fit in tightly against the occupant's lower body in certain frontal or side collisions. (if equipped, Driver only)

If the system senses excessive tension on the driver or passenger's seat belt when the pre-tensioner system activates, the load limiter inside the retractor pre-tensioner will release some of the pressure on the affected seat belt.



# ! CAUTION

# If equipped with rollover sensor

The pre-tensioner will activate not only in a frontal collision but also in a side collision or rollover, if the vehicle is equipped with a side or curtain airbag.



# **CAUTION**

#### Without rollover sensor

The pre-tensioner will activate not only in a frontal collision but also in a side collision, if the vehicle is equipped with a side or curtain airbag.

# WARNING ■

- · Always wear your seat belt and sit properly in your seat.
- · Do not use the seat belt if it is loose or twisted. A loose or twisted seat belt will not protect you properly in an accident.
- · Do not place anything near the buckle. This may adversely affect the buckle and cause it to function improperly.
- · Always replace your pre-tensioners after activation or an accident.
- · NEVER inspect, service, repair or replace the pre-tensioners by vourself. We recommend that you have the pre-tensioners inspected, serviced, repaired or replaced by a HYUNDAI authorised repairer.
- Do not hit the seat belt assemblies.




# WARNING

Do not touch the pre-tensioner seat belt assemblies for several minutes after they have been activated. When the pre-tensioner seat belt mechanism deploys during a collision, the pre-tensioner can become hot and can burn vou.




# **CAUTION**

Body work on the front area of the vehicle may damage the pre-tensioner seat belt system. Therefore, we recommend that the system be serviced by a HYUNDAI authorised repairer.



The Pre-Tensioner Seat Belt System consists mainly of the following components. Their locations are shown in the illustration above:

- (1) SRS airbag warning light
- (2) Front retractor pre-tensioner assembly (if equipped)
- (3) SRS control module
- (4) Emergency fastening device(EFD) (Driver only, if equipped)



(5) Rear retractor pre-tensioner assembly (if equipped)

## NOTICE

The sensor that activates the SRS airbag is connected with the pretensioner seat belts. The SRS airbag warning light on the instrument panel will illuminate for about 6 seconds after the ignition switch is placed to the ON position, and then it should turn off.

If the pre-tensioner is not working properly, the warning light will illuminate even if the SRS airbag is not malfunctioning. If the warning light does not illuminate, stays illuminated or illuminates when the vehicle is being driven, we recommend the pre-tensioner seat belts and/or SRS airbags be inspected by a HYUNDAI authorised repairer as soon as possible.

# NOTICE

- Pre-tensioner seat belts may be activated in certain frontal or side collisions or rollovers (if equipped with rollover sensor).
- When the pre-tensioner seat belts are activated, a loud noise may be heard and fine dust, which may appear to be smoke, may be visible in the passenger compartment. These are normal operating conditions and are not hazardous.
- Although it is non-toxic, the fine dust may cause skin irritation and should not be breathed for prolonged periods. Wash all exposed skin areas thoroughly after an accident in which the pre-tensioner seat belts were activated.

# Additional seat belt safety precautions

# Seat belt use during pregnancy

The seat belt should always be used during pregnancy. The best way to protect your unborn child is to protect yourself by always wearing the seat belt.

Pregnant women should always wear a lap-shoulder seat belt. Place the shoulder belt across your chest, routed between your breasts and away from your neck. Place the lap belt below your belly so that it fits SNUGLY across your hips and pelvic bone, under the rounded part of the belly.

# **⚠** WARNING

- Pregnant women or patients are more vulnerable to any impacts on the abdomen during an abrupt stop or accident. If you are in an accident whilst pregnant, consult your doctor.
- To reduce the risk of serious injury or death to an unborn child during an accident, pregnant women should NEVER place the lap portion of the seat belt above or over the area of the abdomen where the unborn child is located.

#### Seat belt use and children

#### Infant and small children

Most countries have child restraint laws which require children to travel in approved child restraint devices, including booster seats. The age at which seat belts can be used instead of child restraints differs among countries, so vou should be aware of the specific requirements in your country, and where you are travelling. Infant and child restraints must be properly placed and installed in a rear seat. For more details, refer to the "Child Restraint Systems" in this chapter.



# WARNING

ALWAYS properly restrain infants and small children in a child restraint appropriate for the child's height and weight.

To reduce the risk of serious injury or death to a child and other passengers, NEVER hold a child in your lap or arms when the vehicle is moving. The violent forces created during an accident will tear the child from your arms and throw the child against the interior of the vehicle.

Small children are best protected from injury in an accident when properly restrained in the rear seat by a child restraint system that meets the requirements of the Safety Standards of your country. Before buying any child restraint system, make sure that it has a label certifying that it meets Safety Standard of your country. The restraint must be appropriate for your child's height and weight. Check the label on the child restraint for this information. Refer to "Child Restraint Systems" in this chapter.

## Larger children

Children under age 13 and who are too large for a booster seat must always occupy the rear seat and use the available lap/shoulder belts. A seat belt should lie across the upper thighs and be snug across the shoulder and chest to restrain the child safely. Check belt fit periodically. A child's squirming could put the belt out of position. Children are afforded the most safety in the event of an accident when they are restrained by a proper restraint system and/or seat belts in the rear seat

If a larger child over age 13 must be seated in the front seat, the child must be securely restrained by the available lap/shoulder belt and the seat should be placed in the rearmost position.

If the shoulder belt portion slightly touches the child's neck or face, try placing the child closer to the centre of the vehicle. If the shoulder belt still touches their face or neck, they need to be returned to an appropriate booster seat in the rear seat.



# **!** WARNING

- · Always make sure larger children's seat belts are worn and properly adjusted.
- NEVER allow the shoulder belt to contact the child's neck or face.
- · Do not allow more than one child to use a single seat belt.

## Seat belt use and injured people

A seat belt should be used when an injured person is being transported. Consult a physician for specific recommendations.

## One person per belt

Two people (including children) should never attempt to use a single seat belt. This could increase the severity of injuries in case of an accident.

#### Do not lie down

Sitting in a reclined position when the vehicle is in motion can be dangerous. Even when buckled up, the protections of your restraint system (seat belts and/ or airbags) is greatly reduced by reclining your seatback.

Seat belts must be snug against your hips and chest to work properly. During an accident, you could be thrown into the seat belt, causing neck or other injuries.

The more the seatback is reclined, the greater chance the passenger's hips will slide under the lap belt or the passenger's neck will strike the shoulder belt.

# ⚠ WARNING

- NEVER ride with a reclined seatback when the vehicle is moving.
- Riding with a reclined seatback increases your chance of serious or fatal injuries in the event of a collision or sudden stop.
- Driver and passengers should always sit well back in their seats with the seatbacks upright and should be belted properly.

## Care of seat belts

Seat belt systems should never be disassembled or modified. In addition, care should be taken to assure that seat belts and belt hardware are not damaged by seat hinges, doors or other abuse.

## Periodic inspection

All seat belts should be inspected periodically for wear or damage of any kind. Any damaged parts should be replaced as soon as possible.

## Keep belts clean and dry

Seat belts should be kept clean and dry. If belts become dirty, they can be cleaned by using a mild soap solution and warm water. Bleach, dye, strong detergents or abrasives should not be used because they may damage and weaken the fabric.

# When to replace seat belts

The entire seat belt assembly or assemblies should be replaced if the vehicle has been involved in an accident. This should be done even if no damage is visible. We recommend that you consult a HYUNDAI authorised repairer.

# **CHILD RESTRAINT SYSTEM (CRS)**

# Our recommendation: Children always in the rear

# **⚠** WARNING

Always properly restrain children in the rear seats of the vehicle, unless the airbag on the front passenger seat is deactivated.

Children of all ages are safer when restrained in the rear seat. A child riding in the front passenger seat can be forcefully struck by an inflating airbag resulting in SERIOUS INJURY or DEATH.

Children under age 13 must always ride in the rear seats and must always be properly restrained to minimise the risk of injury in an accident, sudden stop or sudden manoeuvre. According to accident statistics, children are safer when properly restrained in the rear seats than in the front seat. Children too large for a Child Restraint System must use the seat belts provided.

Most countries have Child Restraint Systems which require children to travel in approved Child Restraint Systems. The laws governing the age or height/weight restrictions at which seat belts can be used instead of Child Restraint System differs among countries, so you should be aware of the specific requirements in your country, and where you are travelling.

Child Restraint Systems must be properly placed and installed in the rear seat. You must use a commercially available Child Restraint System that meets the requirements of the Safety Standards of your country.

Child Restraint Systems are generally designed to be secured in a vehicle seat by lap belt or the lap belt portion of a lap/shoulder belt, or by a top-tether and/or ISOFIX anchorage in the rear seats of the vehicle.

# Child Restraint System (CRS) always in the rear

Infants and younger children must be restrained in an appropriate rearward-facing or forward-facing CRS that has first been properly secured to the rear seat of the vehicle. Read and comply with the instructions for installation and use provided by the manufacturer of the Child Restraint System.

# **⚠** WARNING

- Always follow the Child Restraint System manufacturer's instructions for installation and use.
- Always properly restrain your child in the Child Restraint System.
- Do not use an infant carrier or a child safety seat that "hooks" over a seatback, it may not provide adequate protection in an accident.
- After an accident, we recommend a HYUNDAI dealer check the Child Restraint System, seat belts, ISO-FIX anchorages and top-tether anchorages.


# Selecting a Child Restraint System (CRS)

When selecting a CRS for your child, always:

- Make sure the CRS has a label certifying that it meets applicable Safety Standards of your country.
- Select a Child Restraint System based on your child's height and weight. The required label or the instructions for use typically provide this information.
- Select a Child Restraint System that fits the vehicle seating position where it will be used.
- Read and comply with the warnings and instructions for installation and use provided with the Child Restraint System.

## Child Restraint System types

There are three main types of Child Restraint Systems: rearward-facing seats, forward-facing seats, and booster seats. They are classified according to the child's age, height and weight.



# Rearward-facing Child Restraint System

A rearward-facing Child Restraint System provides restraint with the seating surface against the back of the child. The harness system holds the child in place, and in an accident, acts to keep the child positioned in the Child Restraint Systems and reduce the stress to the fragile neck and spinal cord.

All children under the age of one year must always ride in a rearward-facing Child Restraint System. There are different types of rearward-facing Child Restraint Systems: infant-only Child Restraint Systems can only be used rearward-facing. Convertible and 3-in-1 Child Restraint Systems typically have higher height and weight limits for the rearward-facing position, allowing you to keep your child rearward-facing for a longer period of time.

Keep using Child Restraint Systems in the rearward-facing position as long as children fit within the height and weight limits allowed by the Child Restraint System's manufacturer.



#### Forward-facing Child Restraint System

A forward-facing Child Restraint Svstem provides restraint for the child's body with a harness. Keep children in a forward-facing Child Restraint System with a harness until they reach the top height or weight limit allowed by your Child Restraint System's manufacturer. Once your child outgrows the forwardfacing Child Restraint System, your

child is ready for a booster seat.

#### **Booster seats**

A booster seat is Child Restraint Svstem designed to improve the fit of the vehicle's seat belt system. A booster seat positions the seat belt so that it fits properly over the stronger parts of your child's body. Keep your children in booster seats until they are big enough to fit in a seat belt properly.

For a seat belt to fit properly, the lap belt must lie comfortable across the upper thighs, not the stomach. The shoulder belt should lie comfortable across the shoulder and chest and not across the neck or face. Children under age 13 must always be properly restrained to minimise the risk of injury in an accident, sudden stop or sudden manoeuvre.

# **Installing a Child Restraint** System (CRS)



# WARNING

Before installing your Child Restraint System always:

Read and follow the instructions provided by the manufacturer of the Child Restraint System.

Failure to follow all warnings and instructions could increase the risk of the SERIOUS INJURY or DEATH if an accident occurs.

# **!** WARNING

If the vehicle head restraint prevents installation of a Restraint System, the head restraint of the respective seating position shall be readjusted or entirely removed.

After selecting a proper Child Restraint System and checking that the Child Restraint System fits properly in the rear of this vehicle, you are ready to install the Child Restraint System according to the manufacturer's instruction. There are three general steps in installing the Child Restraint Systems properly:

 Properly secure the Child Restraint System to the vehicle. All Child Restraint System must be secured to the vehicle with the lap belt or lap part of a lap/shoulder belt or with the ISO-FIX top-tether and/or ISOFIX anchorage.

Make sure the Child Restraint System is firmly secured. After installing a Child Restraint System to the vehicle, push and pull the seat forward and from side-to-side to verify that it is securely attached to the seat. A Child Restraint System secured with a seat belt should be installed as firmly as possible. However, some side-to-side movement can be expected.

When installing a Child Restraint System, adjust the vehicle seat (up and down, forward and rearward) so that your child fits in the Child Restraint System in a comfortable manner.

 Secure the child in the Child Restraint System. Make sure the child is properly strapped in the Child Restraint System according to the Child Restraint System manufacturer's instructions

# **A** CAUTION

A Child Restraint System in a closed vehicle can become very hot. To prevent burns, check the seating surface and buckles before placing your child in the Child Restraint System.

# ISOFIX anchorage and top-tether anchorage (ISOFIX anchorages system) for children


The ISOFIX system holds a Child Restraint System during driving and in an accident. This system is designed to make installation of the Child Restraint System easier and reduce the possibility of improperly installing your Child Restraint System.

The ISOFIX system uses anchors in the vehicle and attachments on the Child Restraint System. The ISOFIX system eliminates the need to use seat belts to secure the Child Restraint System to the rear seats.

ISOFIX anchorages are metal bars built into the vehicle. There are two lower anchors for each ISOFIX seating position that will accommodate a Child Restraint System with lower attachments.

To use the ISOFIX system in your vehicle, you must have a Child Restraint System with ISOFIX attachments. (An ISOFIX Child Restraint System may only be installed if it has vehicle-specific or universal approval in accordance with the requirements of ECE-R44 or ECE-R129.)

The Child Restraint System manufacturer will provide you with instructions on how to use the Child Restraint System with its attachments for the ISOFIX anchorages.




ISOFIX anchorages have been provided in the left and right outboard rear seating positions. Their locations are shown in the illustration. There are no ISOFIX anchorages provided for the centre rear seating position.

# **MARNING**

Do not attempt to install a Child Restraint System using ISOFIX anchorages in the rear centre seating position. There are no ISOFIX anchorages provided for this seat. Using the outboard seat anchorages, for the CRS installation on the rear centre seating position, can damage the anchorages.


Type A





Type B





[A]: ISOFIX Anchorage Position Indicator.

[B]: ISOFIX Anchorage

The ISOFIX anchorages symbols are located on the left and right rear seat cushions to identify the position of the ISOFIX anchorages in your vehicle (see arrows in illustration). Both rear outboard seats are equipped with a pair of ISOFIX anchorages as well as a corresponding top-tether anchorage on the back side of the rear seats.

(Child Restraint Systems with universal approval according to ECE-R44 or ECE-R129 need to be fixed additionally with a top-tether connected to the back side of the rear seats.)

ISOFIX anchorages are located between the seatback and the seat cushion of the rear seat left and right outboard seating positions.

To use the ISOFIX anchorages, push the upper portion of the ISOFIX anchorage cover.

#### Securing a Child Restraint System with the "ISOFIX Anchorage System"

To install a ISOFIX-compatible Child Restraint System in either of the rear outboard seating positions:

- 1. Move the seat belt buckle away from the ISOFIX anchorages.
- Move any other objects away from the anchors that could prevent a secure connection between the Child Restraint System and the ISO-FIX anchorages.
- Place the Child Restraint System on the vehicle seat, then attach the seat to the ISOFIX anchorages according to the instructions provided by the Child Restraint System manufacturer.
- Follow the instructions of the Child Restraint System's manufacturer for proper installation and connection of the ISOFIX attachments on the Child Restraint System to the ISOFIX anchorages.

# **MARNING**

Take the following precautions when using the ISOFIX system:

- Read and follow all installation instructions provided with your Child Restraint System.
- To prevent the child from reaching and taking hold of unretracted seat belts, buckle all unused rear seat belts and retract the seat belt webbing behind the child. Children can be strangled if a shoulder belt becomes wrapped around their neck and the seat belt tightens.
- NEVER attach more than one Child Restraint System to a single anchorage. This could cause the anchor or attachment to come loose or break.
- Always have the ISOFIX system inspected by your dealer after an accident. An accident can damage the ISOFIX system and may not properly secure the Child Restraint System.

#### Securing a Child Restraint System seat with "Top-tether Anchorage" system



Top-tether anchorages for Child Restraint Systems are located on the rear of the seatback.



1. Route the Child Restraint System seat strap over the seatback.

For vehicles with adjustable head restraint, route the tether strap under the head restraint and between the head restraint posts, otherwise route the tether strap over the top of the seatback.

 Connect the top-tether to the toptether anchorage, then tighten the top-tether according to the instructions of your Child Restraint System's manufacturer to firmly attach the Child Restraint System to the seat.

## **MARNING**

Take the following precautions when installing the top-tether:

- Read and follow all installation instructions provided with your Child Restraint System.
- NEVER attach more than one Child Restraint System to a single ISOFIX top-tether anchorage. This could cause the anchorage or attachment to come loose or break.
- Do not attach the top-tether to anything other than the correct toptether anchorage. It may not work properly if attached to something else.
- Child Restraint anchorages are designed to withstand only those loads imposed by correctly fitted Child Restraint System.

Do not use them for adult seat belts, harnesses, or for attaching other items or equipment to the vehicle.

# Suitability of each seating position for belted & ISOFIX Child Restraint Systems (CRS)according to UN regulations (Information for use by vehicle users and CRS manufacturers)

Yes: Suitable for fitment of the designated category of CRS

• No : Not suitable for fitment of the designated category of CRS

• "-": Not applicable

• The table is based on LHD vehicle. Except for the front passenger seat, the table is valid for RHD vehicle. For RHD vehicle front passenger of number 1, use information for the seating position number 3.

\*: 5 Seater, if equipped

Based on R-16.06 ANNEX 17-Appendix3

				Seati	Seating positions	suo			
seirosetes SBO	Origo			.,	ဗ				Bomerke
	200	-	7	Airbag ON	Airbag OFF	4	ů,	9	
Universal belted CRS <sup>1)</sup>	£	1		No	Yes <sup>2)</sup> F,R	Yes F,R	Yes <sup>4)</sup> F,R	Yes F,R	F : Forward facing R : Reward facing
i-size CRS		ı		oN	No	Yes F,R		Yes F,R	Size of CRF (1, 2, 3) For example:
Carry-cot (ISOFIX lateral facing CRS)	ISOFIX CRF: L1, L2			No	No	No		No	<ul> <li>"F2" means small size of forward facing CRF for preschooler (age 6-7)</li> </ul>
ISOFIX infant CRS (for example, CRS for a baby)	ISOFIX CRF: R1	ı		No	o N	Yes <sup>3)</sup>	ı	Yes <sup>3)</sup>	1
ISOFIX toddler CRS - small	ISOFIX CRF: F2,F2X,R2,R2X	ı		No	No	Yes <sup>3)</sup> F,R	ı	Yes <sup>3)</sup> F,R	- "R1" means small size of rearward facing CRF for
ISOFIX toddler CRS - large* (*: not booster seats)	ISOFIX CRF : F3,R3	ı		ON	No	Yes <sup>3)</sup> F,R	ı	Yes 3) F,R	infant (age 0-1) - "R2" means middle size of rearward facing CRF for
Booster Seat - reduced Width	ISO CRF: B2			oN	No	Yes		Yes	toddler (age 2-4) - "R3" means large size of
Booster Seat - full Width	ISO CRF: B3			No	°N	Yes		Yes	rearward facing CRF for toddler (age 4-5)

- Note 1): The universal belted CRS applies to all mass groups.
- Note <sup>2)</sup>: Seating position not suitable for child restraint system if the passenger's front airbag is activate.

Note 3): To install a ISOFIX Child Restraint Systems:

- Driver Seat: You should move the seat at mid position and adjust the height of seat to highest and head restraint stay angle to 9° position.
- Front Passenger Seat : You should move the seat at foremost and head restraint stay angle to 9° position.
- Note <sup>4</sup>): The seating position (number 5) is not suitable for fitment of child restraint system with support leg.
- \* Do not use forward facing child restraint system when child's weight is below 13 kg at all seat.
- \* For semi-universal or vehicle specific CRS(ISOFIX or belted CRS), see the vehicle list provided in the manual of CRS.

Seat Number	Position in the vehicle	
1	Front right	
2	Front centre	
3	Front left	
4	2 <sup>nd</sup> row right	
5*	2 <sup>nd</sup> row centre	
6	2 <sup>nd</sup> row left	



#### Recommended Child Restraint Systems (for Europe)

Mass group	Name	Manufacturer	Type of Fixation	ECE-R44/R129 Approval No.
Group 0+	Cabriofix & Familyfix	Maxi Cosi	ISOFIX	E4 04443907
Group I	Duo Plus	Britax Römer	ISOFIX and top-tether	E1 04301133
Group II	KidFix III S	Britax Römer	Forward-facing with ISOFIX and vehicle belt	E1 04301381
Group III	Junior III	Graco	Forward-facing with vehicle belt	E11 03.44.164 E11 03.44.165

**CRS** Manufacturer information

Maxi Cosi Cabriofix & Familyfix http://www.maxi-cosi.com

Britax Römmer http://www.britax.com

Graco http://www.gracobaby.com

<sup>\*: 5</sup> Seater, if equipped


<sup>\*</sup> If the vehicle headrest prevents proper installation of a CRS, the headrest of the seating position shall be readjusted or entirely removed.

# **MARNING**

- Never place a Child Restraint System on the front passenger seat, unless the passenger airbag is deactivated.
- For semi-universal or vehicle specific CRS (ISOFIX or belted CRS), see the vehicle list provided in the manual of CRS.
- It is recommended to remove the head restraint, when CRS is unstable due to head restraint.

#### Securing a Child Restraint System with a lap/shoulder belt

When not using the ISOFIX system, all Child Restraint Systems must be secured to a rear seat with the lap part of a lap/shoulder belt.



Installing a Child Restraint System with a lap/shoulder belt

To install a Child Restraint System on the rear seats, do the following:

 Place the Child Restraint System on a rear seat and route the lap/ shoulder belt around or through the restraint, following the restraint manufacturer's instructions. Make sure the seat belt webbing is not twisted.

## **i** Information

When using the rear centre seat belt, you should also refer to the "Rear Centre Seat Belt" in this chapter.



Fasten the lap/shoulder belt latch into the buckle. Listen for the distinct "click" sound.

## information

Position the release button so that it is easy to access in case of an emergency.




- Remove as much slack from the belt as possible by pushing down on the Child Restraint System whilst feeding the shoulder belt back into the retractor.
- 4. Push and pull on the Child Restraint System to confirm that the seat belt is holding it firmly in place.

If your CRS manufacturer instructs or recommends you use a top-tether anchorage with the lap/shoulder belt, see page 3-36.

To remove the Child Restraint System, press the release button on the buckle and then pull the lap/shoulder belt out of the restraint and allow the seat belt to retract fully.

#### **AIRBAG - SUPPLEMENTAL RESTRAINT SYSTEM**



- 1. Driver's front airbag
- 2. Passenger's front airbag
- 3. Side airbag\*
- 4. Curtain airbag\*
- 5. Front passenger's airbag ON/OFF switch\*
- \*: if equipped

This vehicle is equipped with a Supplemental Airbag System for the driver's seat and front passenger's seats.

The front airbags are designed to supplement the three-point seat belts. For these airbags to provide protection, the seat belts must be worn at all times when driving.

You can be severely injured or killed in an accident if you are not wearing a seat belt. Airbags are designed to supplement seat belts, but do not replace them. Also, airbags are not designed to deploy in every collision. In some accidents, the seat belts are the only restraint protecting you.



#### **Airbag SAFETY PRECAUTIONS**

ALWAYS use seat belts and child restraints - every trip, every time, everyone! Even with airbags, you can be seriously injured or killed in a collision if you are improperly belted or not wearing your seat belt when the airbag inflates.

NEVER place a child in any child restraint or booster seat in the front passenger seat. An inflating airbag could forcefully strike the infant or child causing serious or fatal injuries.

ABC - Always Buckle Children under age 13 in the back seat. It is the safest place for children of any age to ride. If a child age 13 or older must be seated in the front seat, he or she must be properly belted and the seat should be moved as far back as possible.

All occupants should sit upright with the seatback in an upright position, centred on the seat cushion with their seat belt on, legs comfortably extended and their feet on the floor until the vehicle is parked and the engine is turned off. If an occupant is out of position during an accident, the rapidly deploying airbag may forcefully contact the occupant causing serious or fatal injuries.

You and your passengers should never sit or lean unnecessarily close to the airbags or lean against the door or centre console.

Move your seat as far back as possible from front airbags, whilst still maintaining control of the vehicle.

#### Where are the airbags?

# Driver's and passenger's airbags (if equipped)



■ Passenger's front airbag



Your vehicle is equipped with a Supplemental Restraint System (SRS) and lap/shoulder belts at both the driver and passenger seating positions.

The SRS consists of airbags which are located in the center of the steering wheel and the passenger's side front panel pad above the glove box. The airbags are labelled with the letters "AIR-BAG" embossed on the pad covers.

The purpose of the SRS is to provide the vehicle's driver and front passengers with additional protection than that offered by the seat belt system alone in case of a frontal impact of sufficient severity.

# **MARNING**

To reduce the risk of serious injury or death from an inflating front airbags, take the following precautions:

- Seat belts must be worn at all times to help keep occupants positioned properly.
- Move your seat as far back as possible from front airbags, whilst still maintaining control of the vehicle.
- Never lean against the door or centre console.
- Do not allow the front passenger to place their feet or legs on the dashboard.
- No objects (such as crash pad cover, mobile phone holder, cup holder, air fresheners or stickers) should be placed over or near the airbag modules on the steering wheel, instrument panel, windscreen glass, and the front passenger's panel above the glove box. Such objects could cause harm if the vehicle is in a crash severe enough to cause the airbags to deploy.
- Do not attach any objects on front windscreen and inside mirror.
- Hold the steering wheel at the 9 o'clock and 3 o'clock positions, to minimise the risk of injuries to your hands and arms.



Passenger's front airbag ON/OFF switch (if equipped)

The purpose of the switch is to disable the passenger's front airbag in order to transport occupants who are at increased risk for airbag-related injury due to age, size, or medical condition.



To deactivate the passenger's front airbag:

OAC3039017R

Insert the key or a similar rigid device into the passenger's front airbag ON/ OFF switch and turn it to the OFF position. The passenger airbag OFF indicator (※) will illuminate and stay on until the passenger's front airbag is reactivated.



To reactivate the passenger's front airbag:

Insert the key or a similar rigid device into the passenger's front airbag ON/ OFF switch and turn it to the ON position. The passenger airbag ON indicator (③) will illuminate and stay on for 60 seconds.

## **MARNING**

Never allow an adult passenger to ride in the front passenger seat when the passenger airbag OFF indicator is illuminated. During a collision, the airbag will not inflate if the indicator is illuminated. Turn on the passenger's front airbag or have your passenger move to the rear seat.

## **MARNING**

If the passenger's front airbag ON/ OFF switch malfunctions, the following conditions may occur:

- The airbag warning light (\*) on the instrument cluster will illuminate.
- The passenger airbag OFF indicator (※) will not illuminate and the ON indicator (⊗) will come on and go off after about 60 seconds. The passenger's front airbag will inflate in a frontal impact even though the passenger's front airbag ON/OFF switch is set to the OFF position.
- We recommend that a HYUNDAI authorised repairer inspect the passenger's front airbag ON/OFF switch and the SRS airbag system as soon as possible.

#### Side airbags (if equipped)





Your vehicle is equipped with a side airbag in each front seat.

The purpose of the airbag is to provide the vehicle's driver and the front passenger with additional protection than that offered by the seat belt alone.

The side airbags are designed to deploy only during certain side impact collisions, depending on the crash severity. For vehicles equipped with a rollover sensor the side and/or curtain airbags and pre-tensioners on both sides of the vehicle may deploy if a rollover or possible rollover is detected.

The side airbags are not designed to deploy in all side impact or rollover situations.

## ⚠ WARNING

To reduce the risk of serious injury or death from an inflating side airbag, take the following precautions:

- Seat belts must be worn at all times to help keep occupants positioned properly.
- Do not allow passengers to lean their heads or bodies onto doors, put their arms on the doors, stretch their arms out of the window, or place objects between the doors and seats.
- Do not use any accessory seat covers. This could reduce or prevent the effectiveness of the system.
- Do not place any objects over the airbag or between the airbag and yourself. Also, do not attach any objects around the area the airbag inflates such as the door, side door glass, front and rear pillar.
- Do not place any objects between the door and the seat. They may become dangerous projectiles if the side airbag inflates.
- Do not install any accessories on the side or near the side airbags.

- Do not put any objects between the side airbag label and seat cushion. It could cause harm if the vehicle is in a crash severe enough to cause the airbags to deploy.
- Do not cause impact to the doors when the ignition switch is in the ON position or this may cause the side airbags to inflate.
- If the seat or seat cover is damaged, we recommend that the system be serviced by a HYUNDAI authorised repairer.

#### Curtain airbags (if equipped)





Curtain airbags are located along both sides of the roof rails above the front and rear doors.

They are designed to help protect the heads of the front seat occupants and the rear outboard seat occupants in certain side impact collisions.

The curtain airbags are designed to deploy only during certain side impact collisions, depending on the crash severity.

For vehicles equipped with a rollover sensor the side and/or curtain airbags on both sides of the vehicle may deploy if a rollover or possible rollover is detected.

The curtain airbags are not designed to deploy in all side impact or rollover situations.


Do not hang heavy items on the coat hooks for safety reasons.

# **⚠** WARNING

To reduce the risk of serious injury or death from an inflating curtain airbags, take the following precautions:

- All seat occupants must wear seat belts at all times to help keep occupants positioned properly.
- Properly secure child restraints as far away from the door as possible.
- Do not place any objects over the airbag. Also, do not attach any objects around the area the airbag inflates such as the door, side door glass, front and rear pillar, roof side rail.
- Do not hang other objects except clothes, especially hard or breakable objects. In an accident, it may cause vehicle damage or personal injury.
- Do not allow passengers to lean their heads or bodies onto doors, put their arms on the doors, stretch their arms out of the window, or place objects between the doors and seats.
- Do not attempt to open or repair the side curtain airbags yourself. If necessary, we recommend that the airbag be inspected by a HYUNDAI authorised repairer.

# How does the airbags system operate?



The SRS consists of the following components:

- (1) Driver's front airbag module
- (2) Passenger's front airbag module
- (3) Side airbag modules\*
- (4) Curtain airbag modules\*
- (5) Retractor pre-tensioner assemblies\*
- (6) Airbag warning light
- (7) SRS control module (SRSCM)/ Rollover sensor\*
- (8) Front impact sensors
- (9) Side impact sensors\*
- (10) Side pressure sensors\*
- (11) Passenger's front airbag OFF indicator (front passenger's seat only)
- (12) Passenger's front airbag ON/OFF switch \*
- \*: if equipped

The SRSCM continually monitors SRS components whilst the ignition switch is in the ON position to determine if a crash impact is severe enough to require airbag deployment or pre-tensioner seat belt deployment.



#### SRS warning light

The SRS (Supplement Restraint System) airbag warning light on the instrument panel displays the airbag symbol depicted in the illustration. The system checks the airbag electrical system for malfunctions. The light indicates that there is a potential problem with your airbag system, which could include your side and/or curtain airbags used for rollover protection (if equipped with rollover sensor).



#### WARNING

If your SRS malfunctions, the airbag may not inflate properly during an accident, increasing the risk of serious injury or death.

If any of the following conditions occur, your SRS is malfunctioning:

- The light does not turn on for about six seconds when the ignition switch is in the ON position.
- The light stays on after illuminating for about six seconds.
- The light comes on whilst the vehicle is in motion.
- The light blinks when the engine is running.

We recommend that a HYUNDAI authorised repairer inspect the SRS as soon as possible if any of these conditions occur.

During a frontal collision, sensors will detect the vehicle's deceleration. If the rate of deceleration is high enough, the control unit will inflate the front airbags, at the time and with the force needed.

The front airbags help protect the driver and front passenger by responding to frontal impacts in which seat belts alone cannot provide adequate restraint. When needed, the side airbags help provide protection in the event of a side impact or rollover by supporting the side upper body area.

- Airbags are activated (able to inflate if necessary) only when the ignition switch is in the ON position.
- Airbags inflate in the event of certain frontal or side collisions to help protect the occupants from serious physical injury.
- Generally, airbags are designed to inflate based upon the severity of a collision it's direction etc. These two factors determine whether the sensors produce an electronic deployment/inflation signal.
- The front airbags will completely inflate and deflate in an instant. It is virtually impossible for you to see the airbags inflate during an accident. It is much more likely that you will simply see the deflated airbags hanging out of their storage compartments after the collision.

 In addition to inflating in serious side collisions, vehicles equipped with a rollover sensor, side and/or curtain airbags will inflate if the sensing system detects a rollover.

When a rollover is detected, curtain airbags will remain inflated longer to help provide protection from ejection, especially when used in conjunction with the seat belts. (if equipped with a rollover sensor)

To help provide protection, the airbags must inflate rapidly. The speed of airbag inflation is a consequence of extremely short time in which to inflate the airbag between the occupant and the vehicle structures before the occupant impacts those structures. This speed of inflation reduces the risk of serious or life-threatening injuries and is thus a necessary part of airbag design.


However, the rapid airbag inflation can also cause injuries which can include facial abrasions, bruises and broken bones because the inflation speed also causes the airbags to expand with a great deal of force.

 There are even circumstances under which contact with the airbag can cause fatal injuries, especially if the occupant is positioned excessively close to the airbag.

You can take steps to reduce the risk of being injured by an inflating airbag. The greatest risk is sitting too close to the airbag. An airbag needs space to inflate. It is recommended that drivers sit as far as possible between the center of the steering wheel and the chest whilst still maintaining control of the vehicle.



When the SRSCM detects a sufficiently severe impact to the front of the vehicle, it will automatically deploy the front airbags.



Upon deployment, tear seams molded directly into the pad covers will separate under pressure from the expansion of the airbags. Further opening of the covers allows full inflation of the airbags.

A fully inflated airbag, in combination with a properly worn seat belt, slows the driver's or the front passenger's forward motion, reducing the risk of head and chest injury.





After complete inflation, the airbag immediately starts deflating, enabling the driver to maintain forward visibility and the ability to steer or operate other controls

## WARNING

To prevent objects from becoming dangerous projectiles when the passenger's airbag inflates:

- · Do not install or place any objects (drink holder, CD holder, stickers, etc.) on the front passenger's panel above the glove box where the passenger's airbag is located.
- · Do not install a container of liquid air freshener near the instrument cluster or on the instrument panel surface.

#### What to expect after an airbag inflates

After a frontal or side airbag inflates, it will deflate very quickly. Airbag inflation will not prevent the driver from seeing out of the windscreen or being able to steer. Curtain airbags may remain partially inflated for some time after they deploy.

#### ↑ WARNING

After an airbag inflates, take the following precautions:

- · Open your windows and doors as soon as possible after impact to reduce prolonged exposure to the smoke and powder released by the inflating airbag.
- Do not touch the airbag storage area's internal components immediately after an airbag has inflated. The parts that come into contact with an inflating airbag may be very hot.
- Always wash exposed skin areas thoroughly with cold water and mild soap.
- We recommend that a HYUNDAI authorised repairer replace the airbag immediately after deployment. Airbags are designed to be used only once.

# Noise and smoke from inflating airbag


When the airbags inflate, they make a loud noise and may produce smoke and powder in the air inside of the vehicle. This is normal and is a result of the ignition of the airbag inflator. After the airbag inflates, you may feel substantial discomfort in breathing because of the contact of your chest with both the seat belt and the airbag, as well as from breathing the smoke and powder. The powder may aggravate asthma for some people. If you experience breathing problems after an airbag deployment, seek medical attention immediately.

Though the smoke and powder are nontoxic, they may cause irritation to the skin, eyes, nose, throat, etc. If this is the case, wash and rinse with cold water immediately and seek medical attention if the symptoms persist.

# Do not install a child restraint on the front passenger seat



OUI039199F



Never install a child restraint in the front passenger's seat. An inflating airbag can forcefully strike a child or restraint resulting in serious or fatal injury.

# **!** WARI

### WARNING

- Extreme hazard! Do not use a rearward facing child restraint on a seat protected by an airbag in front of it!
- NEVER use a rearward facing child restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.
- Never put a child restraint in the front passenger's seat. If the front passenger airbag inflates, it would cause serious or fatal injuries.

# Why didn't my airbag go off in a collision?

There are certain types of accidents in which the airbag would not be expected to provide additional protection. These include rear impacts, second or third collisions in multiple impact accidents, as well as low speed impacts. Damage to the vehicle indicates a collision energy absorption, and is not an indicator of whether or not an airbag should have inflated.

#### Airbag collision sensors



#### WARNING

To reduce the risk of an airbag deploying unexpectedly and causing serious injury or death:

- Do not hit or allow any objects to impact the locations where airbags or sensors are installed.
- Do not perform maintenance on or around the airbag sensors. If the location or angle of the sensors is altered, the airbags may deploy when they should not or may not deploy when they should.
- Installing bumper guards with non-genuine HYUNDAI or nonequivalent parts may adversely affect the collision and airbag deployment performance.

To ensure correct function of the airbag system, we recommend to replace the bumper with genuine HYUNDAI part or the equivalent (of the genuine part) specified for your vehicle.

- Place the ignition switch to the LOCK/OFF or ACC position, when the vehicle is being towed to prevent inadvertent airbag deployment.
- We recommend that all airbag repairs are performed by a HYUN-DAI authorised repairer.



- 1. SRS control module/ Rollover sensor\*
- 2. Front impact sensor
- 3. Side pressure sensor\*
- 4. Side impact sensor\*
- \*: if equipped

#### Airbag inflation conditions



Front airbags

Front airbags are designed to inflate in a frontal collision depending on the severity of impact of the front collision.





Side and curtain airbags

Side and curtain airbags are designed to inflate when an impact is detected by side collision sensors depending on the severity of impact resulting from a side impact collision. Although the driver's and front passenger's airbags are designed to inflate only in frontal collisions, they also may inflate in other types of collisions if the front impact sensors detect a sufficient impact. Side and curtain airbags are designed to inflate only in side impact collisions or rollover situations (if equipped with rollover sensor), but they may inflate in other collisions if the side impact sensors detect a sufficient impact. If the vehicle chassis is impacted by bumps or objects on unimproved roads, the airbags may deploy. Drive carefully on unimproved roads or on surfaces not designed for vehicle traffic to prevent unintended airbag deployment.

#### Airbag non-inflation conditions



In certain low-speed collisions the airbags may not deploy. The airbags are designed not to deploy in such cases because they may not provide benefits beyond the protection of the seat belts.




Front airbags are not designed to inflate in rear collisions, because occupants are moved backward by the force of the impact. In this case, inflated airbags would not provide any additional benefit.



Front airbags may not inflate in side impact collisions, because occupants move in the direction of the collision, and thus in side impacts, front airbag deployment would not provide additional occupant protection.


However, side and curtain airbags may inflate depending on the severity of impact.



In an angled collision, the force of impact may direct the occupants in a direction where the airbags would not be able to provide any additional benefit, and thus the sensors may not deploy any airbags.



Just before impact, drivers often brake heavily. Such heavy braking lowers the front portion of the vehicle causing it to "ride" under a vehicle with a higher ground clearance. Airbags may not inflate in this "under-ride" situation because deceleration forces that are detected by sensors may be significantly reduced by such "underride" collisions.



Front airbags may not inflate in rollover accidents because front airbag deployment would not provide additional occupant protection.

## *i* Information

Vehicles equipped with rollover sensor

The side and curtain airbags may inflate in a rollover situation, when it is detected by the rollover sensor.

Vehicles not equipped with rollover sensor

The side and/or curtain airbags may inflate when the vehicle is rolled over by a side impact collision, if the vehicle is equipped with side and/or curtain airbags.



Airbags may not inflate if the vehicle collides with objects such as utility poles or trees, where the point of impact is concentrated and the collision energy is absorbed by the vehicle structure.

#### **SRS Care**

The SRS is virtually maintenance-free and there are no parts you can safely service by yourself. If the SRS airbag warning light does not illuminate when the ignition switch is in the ON position, or continuously remains on, we recommend that the system be immediately inspected by a HYUNDAI authorised repairer.

We recommend any work on the SRS system, such as removing, installing, repairing, or any work on the steering wheel, the front passenger's panel, front seats and roof rails be performed by a HYUNDAI authorised repairer. Improper handling of the SRS system may result in serious personal injury.

# **⚠** WARNING

To reduce the risk of serious injury or death take the following precautions:

- Do not attempt to modify or disconnect the SRS components or wiring, including the addition of any kind of badges to the pad covers or modifications to the body structure.
- Do not place objects over or near the airbag modules on the steering wheel, instrument panel, and the front passenger's panel above the glove box.
- Clean the airbag pad covers with a soft cloth moistened with plain water. Solvents or cleaners could adversely affect the airbag covers and proper deployment of the system.
- We recommend that inflated airbags be replaced by a HYUNDAI authorised repairer.
- If components of the airbag system must be discarded, or if the vehicle must be scrapped, certain safety precautions must be observed. We recommend that you consult a HYUNDAI authorised repairer the necessary information. Failure to follow these precautions could increase the risk of personal injury.

#### **Additional safety precautions**

Passengers should not move out of or change seats whilst the vehicle is moving. A passenger who is not wearing a seat belt during a crash or emergency stop can be thrown against the inside of the vehicle, against other occupants, or be ejected from the vehicle.

Do not use any accessories on seat belts. Devices claiming to improve occupant comfort or reposition the seat belt can reduce the protection provided by the seat belt and increase the chance of serious injury in a crash

#### Do not modify the front seats.

Modification of the front seats could interfere with the operation of the supplemental restraint system sensing components or side airbags.


Do not place items under the front seats. Placing items under the front seats could interfere with the operation of the supplemental restraint system sensing components and wiring harnesses.

**Do not cause impact to the doors.** Impact to the doors when the ignition switch is in the ON position may cause the airbags to inflate.

#### Adding equipment to or modifying your airbag equipped vehicle

If you modify your vehicle by changing your vehicle's frame, bumper system, front end or side sheet metal or ride height, this may affect the operation of your vehicle's airbag system.

# Airbag warning labels (if equipped)



Airbag warning labels are attached to alert the driver and passengers of potential risks of the airbag system. Be sure to read all of the information about the airbags that are installed on your vehicle in this Owner's Manual.

# 4. Instrument cluster

Instrument cluster	4-2
Instrument cluster control	
Gauges and meters	4-3
Transmission shift indicator	
Warning and indicator lights	4-8
Cluster display messages	
Cluster display	4-25
Cluster display control	
Cluster display modes	4-26
User settings mode	
Trip computer	

#### **INSTRUMENT CLUSTER**



- 1. Tachometer
- 2. Speedometer
- 3. Engine coolant temperature gauge
- 4. Fuel gauge
- 5. Warning and indicator lights
- 6. Cluster display (including Trip computer)

The actual cluster in the vehicle may differ from the illustration. For more details, refer to the "Gauges and Meters" in this chapter.

#### **Instrument cluster control**



#### WARNING

Never adjust the instrument cluster whilst driving. This could result in loss of control and lead to an accident that may cause death, serious injury, or vehicle damage.

#### **Gauges and meters**

#### Speedometer



The speedometer indicates the speed of the vehicle and is calibrated in miles per hour (MPH).

#### **Tachometer**




The tachometer indicates the approximate number of engine revolutions per minute (RPM).

Use the tachometer to select the correct shift points and to prevent lugging and/or over-revving the engine.

#### NOTICE

Do not operate the engine within the tachometer's RED ZONE. This may cause severe engine damage.

# Engine Coolant Temperature Gauge



This gauge indicates the temperature of the engine coolant when the ignition switch is in the ON position.

#### NOTICE

If the gauge pointer moves beyond the normal range area toward the "130" position, it indicates overheating that may damage the engine.

Do not continue driving with an overheated engine. If your vehicle overheats, refer to "If the Engine Overheats" in chapter 8.



Never remove the radiator cap or reservoir cap when the engine is hot. The engine coolant is under pressure and could cause severe burns. Wait until the engine is cool before adding coolant to the reservoir.

#### Fuel Gauge



This gauge indicates the approximate amount of fuel remaining in the fuel tank.

## i Information

- The fuel tank capacity is given in chapter 2.
- The fuel gauge is supplemented by a low fuel warning light, which will illuminate when the fuel tank is nearly empty.
- On inclines or curves, the fuel gauge pointer may fluctuate or the low fuel warning light may come on earlier than usual due to the movement of fuel in the tank.

# **MARNING**

Running out of fuel can expose vehicle occupants to danger.

You must stop and obtain additional fuel as soon as possible after the warning light comes on or when the gauge indicator comes close to the "0" level.

#### NOTICE

Avoid driving with an extremely low fuel level. Running out of fuel could cause the engine to misfire damaging the catalytic converter.

#### Outside Temperature Gauge

This gauge indicates the current outside air temperatures either in Celsius (°C) or Fahrenheit.

- Temperature range : -40°C-60°C (-40°F-140°F)


The outside temperature on the display may not immediately change like a general thermometer not to distract the driver. The temperature unit (from °C to °F or from °F to °C) can be changed by:



- User Settings mode in the Cluster: You can change the temperature unit in the "User Settings > Other Features > Temperature Unit".
- Automatic climate control system: Whilst pressing the OFF button, press the AUTO button for 3 seconds or more.

The temperature unit of the instrument cluster and climate control system will change at once.

#### **Odometer**



The odometer indicates the total distance that the vehicle has been driven and should be used to determine when periodic maintenance should be performed.

#### Distance to empty




- The distance to empty is the estimated distance the vehicle can be driven with the remaining fuel.
- If the estimated distance is below 1 mi. (1 km), the trip computer will display "---" as distance to empty.

## Information

- If the vehicle is not on level ground or the battery power has been interrupted, the distance to empty function may not operate correctly.
- The distance to empty may differ from the actual driving distance as it is an estimate of the available driving distance.
- The trip computer may not register additional fuel if less than 1.6 gallons (6 liters) of fuel are added to the vehicle.
- The distance to empty may vary significantly based on driving conditions, driving habits, and condition of the vehicle.
- The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

# Transmission shift indicator (if equipped)

#### Automated manual transmission Shift Indicator (if equipped)



This indicator informs the current gear engaged.

Reverse : RNeutral : N

• Drive Mode: D1, D2, D3, D4, D5

• Manual Mode: 1, 2, 3, 4, 5

# Manual Transmission Shift Indicator (if equipped)



This indicator informs which gear is desired whilst driving to save fuel.

Shifting up : ▲2, ▲3, ▲4, ▲5
Shifting down : ▼1, ▼2, ▼3, ▼4

#### For example

- ▲ ☐: Indicates that shifting up to the 3rd gear is desired (currently the shift lever is in the 2nd or 1st gear).
- ■∃: Indicates that shifting down to the 3rd gear is desired (currently the shift lever is in the 4th, 5th gear).

# *i* Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

#### Warning and indicator lights



#### i Information

Make sure that all warning lights are OFF after starting the engine. If any light is still ON, this indicates a situation that needs attention.

#### Airbag Warning Light



This warning light illuminates:

- When you set the ignition switch to the ON position.
  - It illuminates for about 6 seconds and then goes off.
- · When there is a malfunction with the SRS.
- In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

#### Seat Belt Warning Liaht



This warning light informs the driver and front passenger that the seat belt is not fastened

For more details, refer to the "Seat Belts" in chapter 3.

#### Parking Brake & Brake Fluid Warning Light



This warning light illuminates:

- · When you set the ignition switch to the ON position.
  - It illuminates for about 3 seconds.
  - It remains on if the parking brake is applied.
- When the parking brake is applied.
- · When the brake fluid level in the reservoir is low.
  - If the warning light illuminates with the parking brake released, it indicates the brake fluid level in the reservoir is low

If the brake fluid level in the reservoir is low:

- 1. Drive carefully to the nearest safe location and stop your vehicle.
- 2. With the engine stopped, check the brake fluid level immediately and add fluid as required (For more details, refer to "Brake Fluid" in chapter 9). After adding brake fluid. check all brake components for fluid leaks. If a brake fluid leak is found, or if the warning light remains on, or if the brakes do not operate properly. do not drive the vehicle. We recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

#### **Dual-diagonal braking system**

Your vehicle is equipped with dual-diagonal braking systems. This means you still have braking on two wheels even if one of the dual systems should fail.

With only one of the dual systems working, more than normal pedal travel and greater pedal pressure are required to stop the vehicle.

Also, the vehicle will not stop in as short a distance with only a portion of the brake system working.

If the brakes fail whilst you are driving, shift to a lower gear for additional engine braking and stop the vehicle as soon as it is safe to do so.



#### **WARNING**

# Parking Brake & Brake Fluid Warning Light

Driving the vehicle with a warning light ON is dangerous. If the Parking Brake & Brake Fluid Warning Light illuminates with the parking brake released, it indicates that the brake fluid level is low.

In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

#### Anti-lock Brake System (ABS) Warning Light



This warning light illuminates:

- When you set the ignition switch or the Engine Start/Stop button to the ON position.
  - It illuminates for about 3 seconds and then goes off.
- When there is a malfunction with the ABS (The normal braking system will still be operational without the assistance of the anti-lock brake system).
   In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

#### Electronic Brake Force Distribution (EBD) System Warning Light





These two warning lights illuminate at the same time whilst driving:

 When the ABS and regular brake system may not work normally.
 In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

#### **⚠ WARNING**

#### **Electronic Brake Force** Distribution (EBD) System **Warning Light**

When both ABS and Parking Brake & Brake Fluid Warning Lights are on, the brake system will not work normally and you may experience an unexpected and dangerous situation during sudden braking.

In this case, avoid high speed driving and abrupt braking.

We recommend you have the vehicle inspected by a HYUNDAI authorised repairer as soon as possible.



#### Information

#### **Electronic Brake Force Distribution** (EBD) System Warning Light

When the ABS Warning Light is on or both ABS and Parking Brake & Brake Fluid Warning Lights are on, the speedometer, odometer, or tripmeter may not work. Also, the MDPS Warning Light may illuminate and the steering effort may increase decrease.

In this case, we recommend you have the vehicle inspected by a HYUNDAI authorised repairer as soon as possible.

#### Motor Driven Power Steerina (MDPS)



This warning light illuminates:

- · When you set the ignition switch to the ON position.
  - It illuminates for about 3 seconds and then goes off.
- · When there is a malfunction with the MDPS

In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

#### Malfunction Indicator Lamp (MIL)



This warning light illuminates:

- When you set the ignition switch to the ON position.
  - It illuminates for about 3 seconds and then goes off.
- When there is a malfunction with the emission control system.

In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

#### NOTICE

- Driving with the Malfunction Indicator Lamp (MIL) on may cause damage to the emission control system which could affect drivability and/or fuel economy.
- If the enhanced engine protection system becomes activated due to lack of engine oil, engine power will be limited. If such condition continues repeatedly, the Malfunction Indicator Lamp will illuminate.

## **CAUTION**

If the Malfunction Indicator Lamp (MIL) illuminates, potential catalytic converter damage is possible which could result in loss of engine power. In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer as soon as possible.

# Charging System Warning Light



This warning light illuminates:

 When there is a malfunction with either the alternator or electrical charging system.

If there is a malfunction with either the alternator or electrical charging system:

- 1. Drive carefully to the nearest safe location and stop your vehicle.
- Turn the engine off and check the alternator drive belt for looseness or breakage.

If the belt is adjusted properly, there may be a problem in the electrical charging system.

In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer as soon as possible.

#### Engine Oil Pressure Warning Light



This warning light illuminates:

• When the engine oil pressure is low.

#### If the engine oil pressure is low:

- 1. Drive carefully to the nearest safe location and stop your vehicle.
- 2. Turn the engine off and check the engine oil level (For more details, refer to "Engine Oil" in chapter 9). If the level is low, add oil as required. If the warning light remains on after adding oil or if oil is not available, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer as soon as possible.

Continued driving with the warning light on may cause engine failure.

## *i* Information

When engine oil pressure decreases due to insufficient engine oil, etc., the Engine Oil Pressure warning light will illuminate. In addition, the enhanced engine protection system which limits engine power will be activated. If the engine oil pressure is restored, the Engine Oil Pressure warning light and the enhanced engine protection system will turn off.

#### NOTICE

If the engine does not stop immediately after the Engine Oil Pressure Warning Light is illuminated, severe damage could result.

#### Engine Oil Level Warning Light (if equipped)



The engine oil level warning light illuminates when the engine oil level should be checked.

If the warning light comes on, check the engine oil level as soon as possible and add engine oil as required.

Slowly pour the recommended oil little by little into a funnel. (Oil refill capacity : about  $0.6-1.0 \ l$ )

Use only the specified engine oil. (Refer to "Recommended lubricants and capacities" in chapter 2.)

Do not overfill the engine oil. Make sure the oil level is not above F (Full) mark on the dipstick.

## *i* Information

- If you travel about 30-60 mi. (50-100 km) after the engine warms up, after adding the engine oil, the warning light will go off.
- Cycle the ignition from OFF to ON 3 times within 10 seconds, the warning light will go off immediately. However, when you turn off the warning light without adding the engine oil, the light will come on again after travelling about 30-60 mi. (50-100 km) after the engine warms up.

#### NOTICE

If the light comes on continuously after adding the engine oil and travelling about 30-60 mi. (50-100 km) after the engine warms up, we recommend that the system be checked by a HYUNDAI authorised repairer.

Even if this light doesn't come on after the engine has started, the engine oil should be checked and supplied periodically.

# Low Fuel Level Warning Light



This warning light illuminates:

When the fuel tank is nearly empty.
 Add fuel as soon as possible.

#### NOTICE

Driving with the Low Fuel Level warning light on or with the fuel level below "0" can cause the engine to misfire and damage the catalytic converter (if equipped).

#### Master Warning Light



This indicator light illuminates:

- When there is a malfunction in operation in any of the following systems:
  - Forward Collision-Avoidance Assist malfunction (if equipped)
  - Forward Collision-Avoidance Assist camera blocked (if equipped)
  - Lamp malfunction (if equipped)
  - High Beam Assist malfunction (if equipped)
  - Tyre Pressure Monitoring System (TPMS) malfunction (if equipped)

To identify the details of the warning, look at the cluster display.

#### Low Tyre Pressure Warning Light (if equipped)



This warning light illuminates:

- When you set the ignition switch to the ON position.
  - It illuminates for about 3 seconds and then goes off.
- When one or more of your tyres are significantly underinflated (The location of the underinflated tyres are displayed on the cluster display).

For more details, refer to "Tyre Pressure Monitoring System (TPMS)" in chapter 8.

This warning light remains on after blinking for about 60 seconds or repeatedly blinks on and off at about 3 second intervals:

When there is a malfunction with the TPMS.

In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer as soon as possible.

For more details, refer to "Tyre Pressure Monitoring System (TPMS)" in chapter 8.



#### Safe Stopping

- The TPMS cannot alert you to severe and sudden tyre damage caused by external factors.
- If you notice any vehicle instability, immediately take your foot off the accelerator pedal, apply the brakes gradually with light force, and slowly move to a safe position off the road.

#### Exhaust System (GPF) Warning Light (Petrol Engine, if equipped)



This warning light illuminates:

- This warning light illuminates, when accumulated soot reaches a certain amount.
- When this warning light illuminates, it may turn off after driving the vehicle at more than 50 mph(80 km/h) for about 30 minutes (above 3rd gear with 1,500-4,000 engine RPM).

If this warning light blinks in spite of the procedure (at this time cluster display warning message will be displayed), we recommend that you have the GPF system checked by a HYUNDAI authorised repairer.

#### NOTICE

If you continue to drive with the GPF warning light blinking for a long time, the GPF system can be damaged and fuel consumption can worsen.

#### Electronic Stability Control (ESC) Indicator Light



This indicator light illuminates:

- When you set the ignition switch to the ON position.
  - It illuminates for about 3 seconds and then goes off.
- When there is a malfunction with the ESC system.

In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

#### This indicator light blinks:

Whilst the ESC is operating.

For more details, refer to "Electronic Stability Control (ESC)" in chapter 6.

#### Electronic Stability Control (ESC) OFF Indicator Light



This indicator light illuminates:

- When you set the ignition switch to the ON position.
  - It illuminates for about 3 seconds and then goes off.
- When you deactivate the ESC system by pressing the ESC OFF button.

For more details, refer to "Electronic Stability Control (ESC)" in chapter 6.

# AUTO STOP Indicator Light (if equipped)



#### This indicator light illuminates:

- When the engine enters the Idle Stop mode of the ISG (Idle Stop and Go) system.
- When the automatic starting occurs, the AUTO STOP indicator on the cluster will blink for 5 seconds.

For more details, refer to the "ISG (Idle Stop and Go) system" in chapter 6.

## Information

When the engine automatically starts by the ISG system, some warning lights (ABS, ESC, ESC OFF, MDPS or Parking brake warning light) may turn on for a few seconds.

This happens because of low battery voltage. It does not mean the system has malfunctioned.

#### Immobiliser Indicator Light (without smart key) (if equipped)



#### This indicator light illuminates:

- When the vehicle detects the immobiliser in the key with the key ignition in the ON position.
  - At this time, you can start the engine.
  - The indicator light goes off after starting the engine.

#### This indicator light blinks:

• When there is a malfunction with the immobiliser system.

In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

#### Immobiliser Indicator Light (with smart key) (if equipped)



This indicator light illuminates for up to 30 seconds:

- When the vehicle detects the smart key in the vehicle with the Engine Start/Stop button in the ACC or ON position.
  - At this time, you can start the engine.
  - The indicator light goes off after starting the engine.

This indicator light blinks for a few seconds:

- When the smart key is not in the vehicle.
  - At this time, you cannot start the engine.

This indicator light illuminates for 2 seconds and goes off:

 If the smart key is in the vehicle and the Engine Start/Stop button is ON, but the vehicle cannot detect the smart key.

In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

#### This indicator light blinks:

When there is a malfunction with the immobiliser system.

In this case, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

#### Turn Signal Indicator Light



This indicator light blinks:

· When you operate the turn signals.

If any of the following occur, there may be a malfunction with the turn signal system.

- The turn signal indicator light illuminates but does not blink
- The turn signal indicator light blinks rapidly
- The turn signal indicator light does not illuminate at all

If any of these conditions occur, we recommend that you have your vehicle inspected by a HYUNDAI authorised repairer.

#### Low Beam Indicator Light



This indicator light illuminates:

· When the headlights are on.

#### High Beam Indicator Light



This indicator light illuminates:

- When the headlights are on and in the high beam position.
- When the turn signal lever is pulled into the Flash-to-Pass position.

#### High Beam Assist (HBA) indicator light (if equipped)



This warning light illuminates: When the high-beam is on with the light switch in the AUTO light position.

- White: When High Beam Assist is ready to operate.
- Green: When High Beam Assist is operating.

If your vehicle detects oncoming or preceding vehicles, High Beam Assist will switch the high beam to low beam automatically.

For more details, refer to "High Beam Assist (HBA)" in chapter 5.

#### Light ON Indicator Light



This indicator light illuminates:

• When the tail lights is on.

# Front Fog Indicator Light (if equipped)



This indicator light illuminates:

• When the front fog lights are on.

#### Rear Fog Indicator Light (if equipped)



This indicator light illuminates:

• When the rear fog lights are on.

#### Press Brake (for Automated Manual Transmission)



This indicator light illuminates:

- When changing gear position with out depressing brake pedal.
- When trying to start the engine without depressing brake pedal.

#### Parking Brake Engaged (for Automated Manual Transmission)



This indicator light illuminates:

 When engine is turned off without engaging parking brake lever. The indicator light illuminates for about 5 seconds then goes off.

# Cruise Indicator Light (if equipped)



■ Type B

CRUISE

#### This indicator light illuminates:

When Cruise Control system is enabled.

For more details, refer to "Cruise Control" in chapter 7.

Speed Limiter Indicator Light (if equipped)



■ Type B

(F)\*LIMIT

#### This indicator light illuminates:

• When the speed limiter is enabled.

For more details, refer to "Manual Speed Limit Assist (MSLA)" or "Intelligent Speed Limit Assist (ISLA)" in chapter 7.

#### Forward Safety warning light (if equipped)



#### The warning light illuminates:

- When the ignition switch is in the ON position. It illuminates for about 3 seconds and then goes off.
- Yellow: When Forward Safety of Forward Collision-Avoidance Assist is deselected, disabled, or a malfunction is detected.

If the yellow warning light remains on after the sensor has been uncovered or unblocked when Forward Safety is set, we recommend that your vehicle be inspected by an authorized HYUNDAI dealer.

#### This warning light blinks:

• Red: When Forward Safety function is operating.

For more details, refer to "Forward Collision-Avoidance Assist (FCA)" in chapter 7.

#### Lane Safety indicator light (if equipped)



This indicator light illuminates:

- When the ignition switch is in the ON position. It illuminates for about 3 seconds and then goes off.
- Gray: When Lane Keeping Assist operating conditions are not satisfied.
- Green: When Lane Keeping Assist operating conditions are satisfied.
- Yellow: When Lane Safety is deselected, disabled, or a malfunction is detected

If the yellow warning light remains on after the sensor has been uncovered or unblocked when Lane Safety is set, we recommend that your vehicle be inspected by an authorized HYUNDAI dealer.

The indicator light blinks:

Green: When Lane Keeping Assist is operating.

For more details, refer to "Lane Keeping Assist (LKA)" in chapter 7.

## Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

#### Cluster display messages

# Key not in vehicle (for smart key system)

This warning message is displayed if the smart key is not in the vehicle when you open or close door in the ACC position or ON position. The warning sound is heard when you close door without a smart key in vehicle.

When attempting to start the vehicle always have the smart key with you.

# Key not detected (for smart key system)

This warning message is displayed if the smart key is not detected when you press the Engine Start/Stop button.

# Press START button with key (for smart key system)

This warning message is displayed if you press the Engine Start/Stop button whilst the warning message "Key not detected" is displayed.

At this time, the immobiliser indicator light blinks.

# Low Key Battery (for smart key system)

This warning message is displayed if the battery of the smart key is discharged whilst changing the Engine Start/Stop button to the OFF position.

#### Press brake pedal to start engine (for smart key system and Automated Manual Transmission)

This warning message is displayed if the Engine Start/Stop button changes to the ACC position twice by pressing the button repeatedly without depressing the brake pedal.

You can start the vehicle by depressing the brake pedal.

#### Press clutch pedal to start engine (for smart key system and Manual transmission)

This warning message is displayed if the Engine Start/Stop button is in the ACC position twice by pressing the button repeatedly without depressing the clutch pedal.

Depress the clutch pedal to start the engine.

# Press START button again (for smart key system)

This message is displayed if you were unable to start the vehicle when the Engine Start/Stop button was pressed. If this occurs, attempt to start the engine by pressing the Engine Start/Stop button again.

If the warning message appears each time you press the Engine Start/Stop button, we recommend that you have your vehicle inspected by a HYUNDAI authorised repairer.

# Shift to N to start engine (for smart key system and Automated Manual Transmission)

This warning message is displayed if you try to start the engine with the shift button not in the N (Neutral) position.

## *i* Ir

#### Information

You can start the engine with the shift lever in the N (Neutral) position.

#### Check BRAKE SWITCH fuse (for smart key system and Automated manual transmission)

This warning message is displayed if the brake switch fuse is disconnected.

You need to replace the fuse with a new one. If that is not possible, you can start the engine by pressing the Engine Start/Stop button for 10 seconds in the ACC position.

# Door, Bonnet, Tailgate open indicator



This warning is displayed indicating which door, bonnet, or tailgate is open.



Before driving the vehicle, you should confirm that the door/ bonnet/tailgate are fully closed. Also, check there is no door/bonnet/tailgate open warning light or message displayed on the instrument cluster.

#### Low Tyre Pressure (if equipped)



This warning message is displayed if the tyre pressure is low.

For more details, refer to "Tyre Pressure Monitoring System (TPMS)" in chapter 8.

# Heated Steering Wheel turned off (if equipped)

This message illuminates if the heated steering wheel will turn off automatically about 30 minutes after the heated steering wheel is turned on.

For more details, refer to "Heated Steering Wheel" in chapter 5.

#### Low fuel

This warning message is displayed if the fuel tank is almost out of fuel.

When this message is displayed, the low fuel level warning light in the cluster will come on.

It is recommended to look for the nearest fueling station and refuel as soon as possible.

#### Low engine oil (if equipped)

This warning message is displayed when the engine oil level should be checked.

If this warning message is displayed, check the engine oil level as soon as possible and add engine oil as required. Slowly pour the recommended oil little by little into a funnel. (Oil refill capacity: about 0.15-0.26 gal. (0.6-1.0 *l*)

Use only the specified engine oil. (Refer to "Recommended lubricants and capacities" in chapter 2.)

Do not overfill the engine oil. Make sure the oil level is not above F (Full) mark on the dipstick.

#### NOTICE

If the message is displayed continuously after adding the engine oil and travelling about 30-60 mi. (50-100 km) after the engine warms up, we recommend that the system be checked by a HYUNDAI authorised repairer.

# Engine has overheated (if equipped)

This warning message is displayed when the engine coolant temperature is above 120°C (248°F). This means that the engine is overheated and may be damaged.

If your vehicle is overheated, refer to "Overheating" in chapter 8.

#### Check headlight (if equipped)

This warning message is displayed if the headlights are not operating properly.

In addition, if a specific lamp(turn signal lamp etc.) is not operating properly, the warning message according to a specific lamp (turn signal lamp etc.) is displayed. A corresponding bulb may need to be replaced.

Make sure to replace the burned out bulb with a new one of the same wattage rating.

#### Check brake light (if equipped)

This warning message is displayed if the stop lamps are not operating properly. A lamp may need to be replaced. Make sure to replace the burned out bulb with a new one of the same wattage rating.

# Check exhaust system (if equipped)

This warning message illuminates if the GPF system has a malfunction. At this time, GPF warning light also blinks.

In this case, we recommend that you have the GPF system checked by a HYUNDAI authorised repairer.

GPF: Petrol Particulate Filter


For more details, refer to "Warning lights" in this chapter.

## *i* Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

#### **CLUSTER DISPLAY**

#### **Cluster display control**



The cluster display modes can be changed by using the control buttons.

(1) 1 : MODE button for changing modes

(2)  $\land$ ,  $\lor$  : MOVE switch for changing items

(3) OK: SELECT/RESET button for setting or resetting the selected item

## **Cluster display modes**

Modes	Symbol	Explanation	
Trip Computer		This mode displays driving information such as the tripmeter, fuel economy, etc. For more information, refer to the "Trip Computer" in this chapter.	
Turn By Turn (TBT)	r	This mode displays the state of the navigation.	
Driving Assist		This mode displays the status of the vehicle's Driver Assistance systems.	
User Settings	<b>\$</b>	In this mode, you can change settings of the doors, lamps, etc.	
Warning	$\overline{\mathbb{V}}$	This mode displays warning messages related to the lamp malfunction, etc. This mode displays information related to the tire pressure (TPMS), the state of driving force distribution.	

The information provided may differ depending on which functions are applicable to your vehicle.

#### Trip computer mode



The trip computer mode displays information related to vehicle driving parameters including fuel economy, tripmeter information and vehicle speed.

For more details, refer to "Trip Computer" in this chapter.

#### Driving Assist mode



#### LKA

This mode displays the state of Lane Keeping Assist.

For more details, refer to each system information in chapter 7.

#### Master warning mode



This warning light informs the driver the following situations.

- Forward Collision-Avoidance Assist malfunction (if equipped)
- Forward Collision-Avoidance Assist camera blocked (if equipped)
- Lamp malfunction (if equipped)
- High Beam Assist malfunction (if equipped)
- Tyre Pressure Monitoring System (TPMS) malfunction (if equipped)

The Master Warning Light illuminates if one or more of the above warning situations occur.

At this time, a Master Warning icon (企) will appear beside the User Settings icon (齿), on the cluster display.

If the warning situation is solved, the master warning light will be turned off and the Master Warning icon will disappear.

## *i* Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

#### User settings mode

In this mode, you can change the settings of the instrument cluster, doors, lamps, etc.

- 1. Driver assistance
- 2. Cluster
- 3. Lights
- 4. Door
- 5. Convenience
- 6. Unit
- 7. Language
- 8. Reset

The information provided may differ depending on which functions are applicable to your vehicle.

Engage parking brake to edit settings

This warning message illuminates if you try to select an item from the User Settings mode whilst driving.

For your safety, change the User Settings after parking the vehicle, applying the parking brake and pressing the P (Park) button.

#### Quick guide (Help)

This mode provides quick guides for the systems in the User Settings mode. Select an item, press and hold the OK button.

For more details about each system, refer to this Owner's Manual.

#### 1. Driver Assistance

Items	Explanation
Speed Limit	To set the properties of the Speed Limit system.  Select country: Selects the country for the Speed Limit System.  Speed limit assist: Adjusts the vehicle set speed based on the current speed limit of the road.  Speed limit warning: Provides a warning when the speed limit is exceeded.  Speed Limit information: Provides information on speed limits and additional sign without audible warning  Off: Disables Speed Limit functions that use the current speed limit.
Warning Methods	To set the volume of the warning sound.  • Warning Volume > High / Medium / Low
DAW (Driver Attention Warning)	To set the properties of Driver Attention Warning.  • Leading vehicle departure alert: Alerts the driver during a stop, when the leading vehicle departs.
Driving Safety	To set the properties of the Driving Safety system.  • Forward safety: Provides a warning and vehicle control when a risk of forward collision is detected.  • Forward Safety Warning Timing: Sets the warning timing of the Forward Safety system.  • Lane safety: Automatically assists with steering to help prevent the vehicle from leaving the lane.

 $<sup>^{\</sup>star}$  The information provided may differ depending on which functions are applicable to your vehicle.

#### 2. Cluster

Items	Explanation
Theme Selection	• Theme A • Theme B • Theme C
Wiper/Light Display	To activate or deactivate the Wiper/ Light mode. When activated, the cluster display shows the selected Wiper/Light mode whenever you changed the mode.
Traffic Signs	To set the traffic signs displayed.
Icy Road Warning	To activate or deactivate the icy road warning function.
Welcome Sound	To activate or deactivate the welcome sound.

## 3. Lights

Items	Explanation
Illumination	To adjust the illumination level Level 1~20
One Touch Turn Signal	<ul> <li>Off: The one touch turn signal function will be deactivated.</li> <li>3, 5, 7 Flashes: The turn signal indicator will blink 3, 5, or 7 times when the turn signal lever is moved slightly.</li> <li>For more information, refer to the "Lighting" in chapter 5.</li> </ul>
Ambient Light Brightness	To adjust the ambient light brightness level.  • Level 1-4  • Off
Headlight Delay	• To activate or deactivate the headlight delay function. For more information, refer to the "Lighting" in chapter 5.
High Beam Assist	• To activate or deactivate High Beam Assist. For more information, refer to the "High Beam Assist (HBA)" in chapter 5.

#### 4. Door

Items	Explanation
Automatically Lock	Enable on Speed: All doors will be automatically locked when the vehicle speed exceeds 15 km/h (9.3mph).     Off: The auto door lock operation will be deactivated.
Automatically Unlock	On key out/Vehicle Off: All doors will be automatically unlocked when the ignition key is removed from the ignition switch or the Start/Stop button is set to the OFF position.  Off: The auto door unlock operation will be canceled.

#### 5. Convenience

Items	Explanation
Rear Occupant Alert	• To activate or deactivate the rear occupant alert system. For more information, refer to the "Rear Occupant Alert (ROA)" in chapter 5.
Service Interval	Enable Service Interval     Adjust Interval     Reset
Welcome Mirror/ Light	<ul> <li>On door unlock: The outside rearview mirrors are unfolded and the welcome light turns on automatically when the doors are unlocked.</li> <li>On driver approach: The outside rearview mirrors are unfolded and the welcome light turns on automatically when the vehicle is approached with the smart key.</li> <li>For more information, refer to the "Welcome System" in chapter 5.</li> </ul>
Wireless Charging System	To activate or deactivate the wireless charging system. For more information, refer to the "Wireless smartphone charging system" in chapter 5.
Auto Rear Wiper (in R)	To activate or deactivate the Auto Rear Wiper function.

# *i* Information

To use the service interval menu, we recommend that you consult a HYUNDAI authorised repairer.

If the service interval is activated and the time and distance is adjusted, messages are displayed in the following situations each time the vehicle is turned on.

- Service in: Displayed to inform the driver the remaining mileage and days to service.
- Service required: Displayed when the mileage and days to service has been reached or passed.

## *i* Information

If any of the following conditions occur, the mileage and number of days to service may be incorrect.

- The battery cable is disconnected.
- The fuse switch is turned off.
- The battery is discharged.

#### 6. Units

Items	Explanation
Speed Unit	To select the speed unit. (km/h, MPH)
Temperature Unit	To select the temperature unit. (°C,°F)
Fuel Econ. Unit	To select the fuel economy unit. (km/L, L/100km, US gallon, UK gallon)

## 7. Language (if equipped)

Items	Explanation
Language	Choose the language. You can choose the language in infotainment system. (if equipped)

#### 8. Reset

Items	Explanation
Reset	You can reset the menus in the User Settings Mode. All menus in the User Settings Mode are reset to factory settings, except language and service interval.

#### **Trip computer**


The trip computer is a microcomputer-controlled driver information system that displays information related to driving.

# *i* Information

Some driving information stored in the trip computer (for example, trip distance) resets if the battery is disconnected.


#### Trip modes

# Drive info Trip distance Total driving time Average fuel economy Since refuelling Trip distance Total driving time Average fuel economy Accumulated info Trip distance Total driving time Average fuel economy Accumulated info Trip distance Total driving time Average fuel economy Accumulated info Trip distance Total driving time Average fuel economy



To change the trip mode, toggle the "\land \times \" switch on the steering wheel.

#### Drive Info




Trip distance (1), total driving time (2) and average fuel economy (3) are displayed.

The information is combined for each ignition cycle. However, when the driver's door is opened after turning off the engine or the engine is turned on after 3 minutes have passed, the Drive Info screen will reset.

To reset manually, press the OK switch on the steering wheel for more than 1 second when 'Drive Info' is displayed.

#### Since refuelina



Trip distance (1), total driving time (2), and average fuel economy (3) after the vehicle has been refueled are displayed.

To reset manually, press the OK switch on the steering wheel for more than 1 second when 'Since refuelling' is displaved.

#### Accumulated info



Accumulated trip distance (1), total driving time (2), and average fuel economy (3) are displayed.

To reset manually, press the OK switch on the steering wheel for more than 1 second when 'Accumulated info' is displayed.

#### Auto stop (if equipped)



AUTO STOP display shows the elapsed time of engine stop by Idle Stop and Go system.

For more information, refer to the "Idle Stop and Go (ISG)" section in chapter 6.

# 5. Convenience features

Accessing your vehicleRemote keyRemote key precautions	5-5
Smart key Smart key precautions Immobiliser system	5-11
Door locks Operating door locks from outside the vehicle Operating door locks from inside the vehicle Deadlocks Auto door lock/unlock features Child-protector rear door locks How to lock the door in case of emergency	5-14 5-16 5-17 5-18
Rear Occupant Alert (ROA)	
Theft-alarm system	5-21 5-21 5-22 5-23
Mirrors Inside rearview mirror Outside rearview mirror	5-24
WindowsPower windows	
Exterior features  Bonnet  Tailgate  Fuel filler door	5-32 5-33

Lighting Exterior lights Interior lights	5-38
High Beam Assist (HBA)High Beam Assist settingsHigh Beam Assist operationHigh Beam Assist malfunction and limitations	5-46 5-46
Wipers and washers	5-49 5-50
Manual climate control system  Heating and air conditioning  System operation  System maintenance	5-53 5-57
Automatic climate control system	5-62 5-63 5-67
Windscreen defrosting and defogging Automatic climate control system Defroster	5-73
Storage compartment  Centre console storage	5-75
Tray	5-76

# 5. Convenience features

Interior features	5-77
Ashtray	5-77
Cup holder	5-77
Sunvisor	5-78
Power outlet	5-79
USB charger	5-80
Wireless mobile phone charging system	5-81
Clock	5-84
Coat hook	5-84
Floor mat anchor(s)	5-85
Luggage net (holder)	5-86
Cargo area cover	5-86
Infotainment system	5-87
USB port	
Antenna	5-87
Steering wheel audio control	5-88
Audio / Video / Navigation system	5-89
Bluetooth® Wireless Technology hands-free	5-90
How vehicle radio works	5-90
Audio (Without Touch Screen)	5-94
System layout – control panel	5-94
System layout – steering wheel remote control	
Turning the system on or off	
Turning the display on or off	
Getting to know the basic operations	

Radio Turning on the radio Changing the radio mode Scanning for available radio stations Searching for radio stations Saving radio stations Listening to saved radio stations	5-102 5-105 5-105 5-105
Media player Using the media player Using the USB mode	5-107
Bluetooth  Connecting Bluetooth devices  Using a Bluetooth audio device  Using a Bluetooth phone	5-110 5-113
Pan-European eCall	5-120
System status icons	5-122 5-122
Trademarks	
Declaration of conformity	

# ACCESSING YOUR VEHICLE Remote key (if equipped)



Your HYUNDAI uses a remote key, which you can use to lock or unlock a door (and tailgate) and even start the engine.

- (1) Door Lock
- (2) Door Unlock
- (3) Tailgate Unlock

#### Locking

To lock:

- 1. Close all doors, engine bonnet and tailgate.
- 2. Press the Door Lock button (1) on the remote key.
- The doors will lock. The hazard warning lights will blink once. Also, the outside rearview mirror will fold if 'Convenience > Welcome mirror > On door unlock or On driver approach' is selected from the User Settings mode on the instrument cluster (or infotainment system). For more information, refer to the "Cluster Display" section in chapter 4.
- 4. Make sure the door are locked by pulling on the door handle.

# **MARNING**

Do not leave the keys in your vehicle with unsupervised children. Unattended children could place the key in the ignition switch and may operate power windows or other controls, or even make the vehicle move, which could result in serious injury or death.

#### Unlocking

To unlock:

- 1. Press the Door Unlock button (2) on the remote key.
- The doors will unlock. The hazard warning lights will blink two times. Also, the outside rearview mirror will unfold if 'Convenience > Welcome mirror > On door unlock or On driver approach' is selected from the User Settings mode on the instrument cluster (or infotainment system). For more information, refer to the "Cluster Display" section in chapter 4.

# *i* Information

After unlocking the doors, the doors will lock automatically after 30 seconds unless a door is opened.

#### Tailgate unlocking

To unlock:

- Press the Tailgate Unlock button (3) on the remote key for more than one second.
- The hazard warning lights will blink two times. Once the tailgate is opened and then closed, the tailgate will lock automatically.

## *i* Information

- After unlocking the tailgate, the tailgate will lock automatically.
- The word "HOLD" is written on the button to inform you that you must press and hold the button for more than one second.

#### Start-up

For detailed information refer to "Key Ignition Switch" in chapter 6.

#### NOTICE

To prevent damaging the remote key:

- Keep the remote key away from water or any liquid and fire. If the inside of the remote key gets damp (due to drinks or moisture), or is heated, internal circuit may malfunction, excluding the car from the warranty.
- Avoid dropping or throwing the remote key.
- Protect the remote key from extreme temperatures.

#### Mechanical key





If the remote key does not operate normally, you can lock or unlock the door by using the mechanical key.

#### Type B

To unfold the key, press the release button then the key will unfold automatically.

To fold the key, fold the key manually whilst pressing the release button.

#### NOTICE

Do not fold the key without pressing the release button. This may damage the key.

#### **Remote key precautions**

The remote key will not work if any of the following occur:

- The key is in the ignition switch.
- You exceed the operating distance limit (about 90 ft. [30 m]).
- The remote key battery is weak.
- Other vehicles or objects may be blocking the signal.
- The weather is extremely cold.
- The remote key is close to a radio transmitter such as a radio station or an airport which can interfere with normal operation of the remote key.

When the remote key does not work correctly, open and close the door with the mechanical key. If you have a problem with the remote key, it is recommended that you contact a HYUNDAI authorised repairer.

If the remote key is in close proximity to your mobile phone, the signal could be blocked by your mobile phones normal operational signals. This is especially important when the phone is active such as making and receiving calls, text messaging, and/or sending/receiving emails. Avoid placing the remote key and your mobile phone in the same pants or jacket pocket and always try to maintain an adequate distance between the two devices.

## *i* Information

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. If the keyless entry system is inoperative due to changes or modifications not expressly approved by the party responsible for compliance, it will not be covered by your manufacturer's vehicle warranty.

#### NOTICE

Keep the remote key away from electromagnetic materials that blocks electromagnetic waves to the key surface.

#### Battery replacement

If the remote key is not working properly, try replacing the battery with a new one.

#### Type A



Battery type: CR2032 To replace the battery:

- 1. Insert a slim tool into the slot and gently pry open the cover.
- Remove the old battery and insert the new battery. Make sure the battery position is correct.
- 3. Reinstall the rear cover of the remote key.

Type B



Battery type: CR2032 To replace the battery:

- 1. Insert a slim tool into the slot and gently pry open the cover.
- 2. Using a screw driver remove the battery cover (A).
- Remove the old battery (B) and insert a new battery. Make sure the battery position is correct.

 Reinstall the battery cover and key cover in the reverse order of removal.

## **⚠** WARNING

# THIS PRODUCT CONTAINS A BUTTON BATTERY.

If swallowed, a lithium button battery can cause severe or fatal injuries within 2 hours. Keep batteries out of reach of children.

If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.

## *i* Information



An inappropriately disposed battery can be harmful to the environment and human health. Dispose the battery according to your local law(s) and regulation.

#### **Smart key (if equipped)**



Your HYUNDAI uses a Smart Key, which you can use to lock or unlock a door (and tailgate) and even start the engine.

- (1) Door Lock
- (2) Door Unlock
- (3) Tailgate Unlock

#### Locking



#### To lock:

- 1. Close all doors, engine bonnet and tailgate.
- Either press the door handle button or press the Door Lock button (1) on the smart key.

- The door will lock. The hazard warning lights will blink once. Also, the outside rearview mirror will fold if 'Convenience > Welcome mirror > On door unlock or On driver approach' is selected from the User Settings mode on the instrument cluster (or infotainment system). For more information, refer to the "Cluster Display" section in chapter 4.
- 4. Make sure the door are locked by pulling on the door handle.

## *i* Information

The door handle button will only operate when the smart key is within 28-40 in. (0.7-1 m) from the outside door handle.

Even though you press the outside door handle button, the doors will not lock and the chime will sound for three seconds if any of the following occur:

- The Smart Key is in the vehicle.
- The Engine Start/Stop button is in ACC or ON position.
- Any door except the tailgate is open.

## **MARNING**

Do not leave the Smart Key in your vehicle with unsupervised children. Unattended children could press the Engine Start/Stop button and may operate power windows or other controls, or even make the vehicle move, which could result in serious injury or death.

## Unlocking



#### To unlock:

- 1. Carry the Smart Key.
- Either press the door handle button or press the Door Unlock button (2) on the smart key.
- 3. The doors will unlock. The hazard warning lights will blink two times. Also, the outside rearview mirror will unfold if 'Convenience > Welcome mirror > On door unlock or On driver approach' is selected from the User Settings mode on the instrument cluster (or infotainment system). For more information, refer to the "Cluster Display" section in chapter 4.

## *i* Information

- The door handle button will only operate when the smart key is within 40 in. (1 m) from the outside door handle. Other people can also open the doors without the smart key in possession.
- After unlocking the doors, the doors will lock automatically after 30 seconds unless a door is opened.

## Tailgate unlocking

To unlock:

- 1. Carry the smart key.
- Either press the tailgate handle button or press the Tailgate Unlock button (3) on the smart key for more than one second.
- The hazard warning lights will blink two times.

Once the tailgate is opened and then closed, the tailgate will lock automatically.

# Information

After unlocking the tailgate, the tailgate will lock automatically after 30 seconds unless the tailgate is opened.

#### Start-up

You can start the engine without inserting the key. For detailed information refer to the Engine Start/Stop button in chapter 6.

## NOTICE

To prevent damaging the smart key:

- Keep the smart key away from water or any liquid and fire. If the inside of the smart key gets damp (due to drinks or moisture), or is heated, internal circuit may malfunction, excluding the car from the warranty.
- Avoid dropping or throwing the smart key.
- Protect the smart key from extreme temperatures.

## NOTICE

Always have the smart key with you when leaving the vehicle. If the smart key is left near the vehicle, the vehicle battery may be discharged.

### Mechanical key

If the Smart Key does not operate normally, you can lock or unlock the door by using the mechanical key.



Press and hold the release button (1) and remove the mechanical key (2). Insert the mechanical key into the key hole on the door.

To reinstall the mechanical key, put the key into the hole and push it until a click sound is heard.

## Loss of a smart key

A maximum of two smart keys can be registered to a single vehicle. If you happen to lose your smart key, it is recommended that you should immediately take the vehicle and remaining key to your HYUNDAI authorised repairer or tow the vehicle, if necessary.

## **Smart key precautions**

The smart key will not work if any of the following occur:

- The smart key is close to a radio transmitter such as a radio station or an airport which can interfere with normal operation of the transmitter.
- The smart key is near a mobile two way radio system or a mobile phone.
- Another vehicle's smart key is being operated close to your vehicle.

When the smart key does not work correctly, open and close the door with the mechanical key. If you have a problem with the smart key, it is recommended that you contact a HYUNDAI authorised repairer.

If the smart key is in close proximity to your mobile phone, the signal could be blocked by your mobile phones normal operational signals. This is especially important when the phone is active such as making and receiving calls, text messaging, and/or sending/receiving emails. Avoid placing the smart key and your mobile phone in the same pants or jacket pocket and always try to maintain an adequate distance between the two devices.

# *i* Information

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. If the keyless entry system is inoperative due to changes or modifications not expressly approved by the party responsible for compliance, it will not be covered by your manufacturer's vehicle warranty.

#### NOTICE

Keep the smart key away from electromagnetic materials that blocks electromagnetic waves to the key surface.

### Battery replacement



If the Smart Key is not working properly, try replacing the battery with a new one.

Battery Type: CR2032 To replace the battery:

- 1. Pry open the rear cover of the smart key.
- Remove the old battery and insert the new battery. Make sure the battery position is correct.
- 3. Reinstall the rear cover of the smart key.

If you suspect your smart key might have sustained some damage, or you feel your smart key is not working correctly, it is recommended that you contact a HYUNDAI authorised repairer.

# **⚠** WARNING

# THIS PRODUCT CONTAINS A BUTTON BATTERY.

If swallowed, a lithium button battery can cause severe or fatal injuries within 2 hours. Keep batteries out of reach of children.

If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.

# *i* Information



An inappropriately disposed battery can be harmful to the environment and human health. Dispose the battery according to your local law(s) and regulation.

# Immobiliser system (if equipped)

The immobiliser system protects your vehicle from theft. If an improperly coded key (or other device) is used, the engine's fuel system is disabled.

When the ignition switch is placed in the ON position, the immobiliser system indicator should come on briefly, then go off. If the indicator starts to blink, the system does not recognise the coding of the key.

Place the ignition switch to the LOCK/ OFF position, then place the ignition switch to the ON position again.

The system may not recognise your key's coding if another immobiliser key or other metal object (for example, key chain) is near the key. The engine may not start because the metal may interrupt the transponder signal from transmitting normally.

If the system repeatedly does not recognise the coding of the key, it is recommended that you contact your HYUNDAI dealer.

Do not attempt to alter this system or add other devices to it. Electrical problems could result that may make your vehicle inoperable.

# **MARNING**

In order to prevent theft of your vehicle, do not leave spare keys anywhere in your vehicle. Your immobiliser password is a customer unique password and should be kept confidential.

## NOTICE

The transponder in your key is an important part of the immobiliser system. It is designed to give years of trouble-free service, however you should avoid exposure to moisture, static electricity and rough handling. Immobiliser system malfunction could occur.

#### **DOOR LOCKS**

# Operating door locks from outside the vehicle

## Mechanical key





- 1. Press the lever located under the cover with mechanical key. (1)
- Whilst pushing the lever so that the mechanical key does not fall out of the cover hole, slowly push it upward of the vehicle and remove the cover.
   (2)
- After removing the cover, only driver's door can be locked or unlocked by using mechanical key.
- 4. Turn the key toward the front of the vehicle to unlock and toward the rear of the vehicle to lock. (3)

If you lock/unlock the driver's door with a key, the all doors will lock/unlock automatically.

Once the doors are unlocked, they may be opened by pulling the door handle.

When closing the door, push the door by hand. Make sure that doors are closed securely.

## *i* Information

- Be careful when locking the door by mechanical key operation, only the driver's door can be locked/ unlocked.
- When all doors are locked with the mechanical key, lock all doors by using the central door lock switch inside the vehicle. Open the door using the driver's inner door handle, and then close the door and lock the driver's door with mechanical key operation.
- To lock from inside the vehicle, Refer to "Operating door locks from inside the vehicle" in this chapter.

## *i* Information

- When removing the cover, be careful not to lose cover and any scratches.
- When the key cover freezes and does not open, lightly tap or indirectly warm(hand temperature, etc.) it.
- Do not apply excessive force to the door and door handle. It may be damaged.

## Remote key



To lock the doors, press the Door Lock button (1) on the remote key.

To unlock the doors, press the Door Unlock button (2) on the remote key. Once the doors are unlocked, they may be opened by pulling the door handle. When closing the door, push the door by hand. Make sure that doors are closed securely.

## *i* Information

- In cold and wet climates, door lock and door mechanisms may not work properly due to freezing conditions.
- If the door is locked/unlocked multiple times in rapid succession with either the vehicle key or door lock switch, the system may stop operating temporarily in order to protect the circuit and prevent damage to system components.

## Smart key





- (1) Door Lock
- (2) Door Unlock
- (3) Tailgate Unlock

To lock the doors, press the button on the outside door handle whilst carrying the smart key with you or press the door lock button on the smart key.

To unlock the doors, press the button on the outside door handle whilst carrying the smart key with you or press the door unlock button on the smart key.

Once the doors are unlocked, they may be opened by pulling the door handle.

When closing the door, push the door by hand. Make sure that doors are closed securely.

## *i* Information

- In cold and wet climates, door lock and door mechanisms may not work properly due to freezing conditions.
- If the door is locked/unlocked multiple times in rapid succession with either the vehicle key or door lock switch, the system may stop operating temporarily in order to protect the circuit and prevent damage to system components.

# Operating door locks from inside the vehicle

#### With the door handle



- Front doors
   If the inner door handle is pulled (1)
  - when the door is locked, the door will unlock and open.
- · Rear doors
  - If the inner door handle is pulled once when the door is locked, the door will unlock.

If the inner door handle is pulled once more, the door will open.

### With the central door lock switch



- When you press the door lock/unlock switch, all vehicle doors will lock and the indicator light on the switch will illuminate for about 60 seconds (If the key is in the ignition switch, the indicator light on the switch will continuously illuminate).
  - If any door is opened when the switch is pressed, all doors will not lock.
- If any door is unlocked, the indicator of the door lock switch will blink. If you press the switch when the indicator blinks, all doors will lock.
- When you press the door lock/unlock switch again, all vehicle doors will unlock and the indicator light on the switch will not illuminate.

## **!** WARNING

- The doors should always be fully closed and locked whilst the vehicle is in motion. If the doors are unlocked, the risk of being thrown from the vehicle in a crash is increased.
- Do not pull the inner door handle of the driver's or passenger's door whilst the vehicle is moving.

# **MARNING**

Do not leave the elderly, children or animals unattended in your vehicle. An enclosed vehicle can become extremely hot, causing death or serious injury to the elderly, unattended children or animals who cannot escape from the vehicle. Children might operate features of the vehicle that could injure them, or they could encounter other harm, possibly from someone gaining entry to the vehicle.

# **⚠** WARNING

Always secure your vehicle Leaving your vehicle unlocked can allow theft or entry into the vehicle.

To secure your vehicle, whilst depressing the brake, move the shift lever to the N (Neutral) position (for Automated manual transmission) or first gear or R (Reverse, for Manual transmission), engage the parking brake, and place the ignition switch in the LOCK/OFF position, close all windows, lock all doors, and always take the key with you.

# **MARNING**

If you stay in the vehicle for a long time whilst the weather is very hot or cold, there are risks of injuries or danger to life. Do not lock the vehicle from the outside when someone is in the vehicle.

# **MARNING**

Opening a door when something is approaching may cause damage or injury. Be careful when opening doors and watch for vehicles, motorcycles, bicycles or pedestrians approaching the vehicle in the path of the door.

## **Deadlocks (if equipped)**

Some vehicles are equipped with a deadlock system. Deadlocks prevent opening of a door from either inside or outside the vehicle once the deadlocks have been activated providing an additional measure of vehicle security.

To lock the vehicle using the deadlock function, the doors must be locked by using the remote key or smart key. To unlock the vehicle, the transmitter or smart key must be used again.

# **MARNING**

Do not lock the doors with the remote key or the smart key with anybody left in the vehicle. The passenger in the vehicle cannot unlock the doors with the door lock button. For example, if the door is locked with the remote key, the passenger in the vehicle cannot unlock the door without the transmitter.

## Auto door lock/unlock features Impact sensing door unlock system (if equipped)

All doors will be automatically unlocked when an impact causes the airbags to deploy.

## Speed sensing door lock system (if equipped)

All doors will be automatically locked when vehicle speed exceeds 9 mph (15 km/h).

You can activate or deactivate the Auto Door Lock/Unlock features from the User Settings mode on the instrument cluster.For more information, refer to the "Cluster Display" section in chapter 4.

## Child-protector rear door locks (if equipped)



The child safety lock is provided to help prevent children seated in the rear from accidentally opening the rear doors.

The rear door safety locks should be used whenever children are in the vehicle.

The child safety lock is located on the edge of each rear door. When the child safety lock is in the lock position, the rear door will not open if the inner door handle is pulled.

To lock the child safety lock, insert a key (or screwdriver) (1) into the hole and turn it to the lock position.

To allow a rear door to be opened from inside the vehicle, unlock the child safetv lock.

## WARNING

If children accidently open the rear doors whilst the vehicle is in motion. they could fall out of the vehicle. The rear door safety locks should always be used whenever children are in the vehicle

## How to lock the door in case of emergency



In case of an emergency (battery discharge, etc.) you can manually lock the door using the emergency key.

- 1. Open the door
- 2. Insert the key into the emergency door lock hole and turn it clockwise for left side door, or turn it counterclockwise for right side door.
- 3 Close the door

## REAR OCCUPANT ALERT (ROA)

Rear Occupant Alert prevents the driver from leaving a passenger in the rear seats



When the driver turns off the engine and opens the driver's door after opening and closing a rear door, a warning message "Check rear seats" appears on the cluster display.

## **WARNING**

Rear Occupant Alert provides information to the driver to check the rear seats but it does not detect whether there is an object or pas-senger. Always check the rear seats when leaving the vehicle.



## Information

The open and close history of the rear door is initialized if the driver turns off the engine and lock vehicle doors. However, the alarm may sound again whenever the driver's door is opened if the previous history of the rear door is not initialized.

#### THEFT-ALARM SYSTEM

This system helps to protect your vehicle and valuables. The horn will sound and the hazard warning lights will blink continuously if any of the following occur:

- A door is opened without using the remote key or smart key.
- The tailgate is opened without using the remote key or smart key.
- The engine bonnet is opened.

The alarm continues for 30 seconds. then the system resets. To turn off the alarm, unlock the doors with the remote key or smart key.

The Theft Alarm System automatically sets 30 seconds after you lock the doors and the tailgate. For the system to activate, you must lock the doors and the tailgate from outside the vehicle with the remote key or smart key or by pressing the button on the outside of the door handles with the smart key in vour possession.

The hazard warning lights will blink and the chime will sound once to indicate the system is armed.

Once the security system is set, opening any door, the tailgate, or the bonnet without using the remote key or smart key will cause the alarm to activate.

The Theft Alarm System will not set if the bonnet, the tailgate, or any door is not fully closed. If the system will not set, check the bonnet, the tailgate, or the doors are fully closed.

Do not attempt to alter this system or add other devices to it.

## *i* Information

- Do not lock the doors until all passengers have left the vehicle. If the remaining passenger leaves the vehicle when the system is armed, the alarm will be activated.
- If the vehicle is not disarmed with the remote key or smart key, open the doors by using the mechanical key and place the ignition switch in the ON position (for remote key) or start the engine (for smart key) and wait for 30 seconds.
- When the system is disarmed but a door or tailgate is not opened within 30 seconds, the system will be rearmed.



We recommend that you receive the services related to the burglar alarm system be checked by a HYUNDAI authorised repairer. Arbitrary modification or alteration of the burglar alarm system may result in a malfunction. A failure caused by arbitrary alteration or modification is not covered by the warranty.



## Information

Vehicles equipped with a theft alarm system will have a label attached to the vehicle with the following words:

- 1. WARNING
- 2. SECURITY SYSTEM

#### STEERING WHEEL

# Motor Driven Power Steering (MDPS)

The system assists you with steering the vehicle. If the engine is off or if the power steering system becomes inoperative, the vehicle may still be steered, but it will require increased steering effort.

Also, the steering effort becomes heavier as the vehicle's speed increases and becomes lighter as the vehicle's speed decreases for better control of the steering wheel.

Should you notice any change in the effort required to steer during normal vehicle operation, we recommend that the system be checked by a HYUNDAI authorised repairer.

### NOTICE

If the Electric Power Steering System does not operate normally, the warning light (⊚!) will illuminate on the instrument cluster. The steering wheel may become difficult to control or operate. We recommend that you take your vehicle to a HYUNDAI authorised repairer or to a service station and have the system checked as soon as possible.

## *i* Information

The following symptoms may occur during normal vehicle operation:

- After placing the ignition switch in the ON position, the steering effort may be high immediately that happens as the system performs the MDPS system diagnostics. When the diagnostics are completed, the steering wheel will return to its normal condition.
- When the battery voltage is low, you might have to put more steering effort. However, it is a temporary condition so that it will return to normal condition after charging the battery.
- A click noise may be heard from the MDPS relay after the ignition switch is placed in the ON or LOCK/OFF position.
- Motor noise may be heard when the vehicle is at a stop or at a low driving speed.
- When you operate the steering wheel in low temperatures, abnormal noise may occur. If the temperature rises, the noise will disappear. This is a normal condition.
- When the vehicle is stationary, if you turn the steering wheel all the way to the left or right continuously, the steering wheel effort increases. This is not a system malfunction. As time passes, the steering wheel effort will return to its normal condition.

## Tilt steering / Telescope steering



## WARNING


Never adjust the steering wheel whilst driving. You may lose steering control and cause severe personal injury, death or accidents.



## Information

After adjustment, sometimes the lockrelease lever may not lock the steering wheel.

It is not a malfunction. This occurs when two gears are not engaged correctly. In this case, adjust the steering wheel again and then lock the steering wheel.



To change the steering wheel angle and height:

- 1. Pull down the lock-release lever (1).
- 2. Adjust the steering wheel to the desired angle (2) and height (3, if equipped). Move the steering wheel, so it points toward vour chest, not toward your face. Make sure you can see the instrument panel warning lights and gauges.
- 3. Pull up the lock-release lever to lock the steering wheel in place.

Push the steering wheel both up and down to be certain it is locked in position



## **CAUTION**

Whilst adjusting the steering wheel height, please do not push or pull it hard since the fixture can be damaged.

# Heated steering wheel (if equipped)



When the ignition switch is in the ON position or when the engine is running, press the heated steering wheel button to warm the steering wheel. The indicator on the button will illuminate.

To turn the heated steering wheel off, press the button again. The indicator on the button will turn off.

# Information

The heated steering wheel will turn off automatically about 30 minutes after the heated steering wheel is turned on.

## NOTICE

Do not install any cover or accessory on the steering wheel. This cover or accessory could cause damage to the heated steering wheel system.

#### Horn



To sound the horn, press the area indicated by the horn symbol on your steering wheel (see illustration). The horn will operate only when this area is pressed.

## NOTICE

Do not strike the horn severely to operate it, or hit it with your fist. Do not press on the horn with a sharp-pointed object.

#### **MIRRORS**

#### Inside rearview mirror

Before you start driving, adjust the rearview mirror to the centre on the view through the rear window.



## WARNING

Make sure your line of sight is not obstructed. Do not place objects in the rear seat, cargo area, or behind the rear head restraints which could interfere with your vision through the rear window.



## WARNING

To prevent serious injury during an accident or deployment of the airbag, do not modify the rearview mirror and do not install a wide mirror.




## WARNING

NEVER adjust the mirror whilst driving. This may cause loss of vehicle control resulting in an accident.

## NOTICE

When cleaning the mirror, use a paper towel or similar material dampened with glass cleaner. Do not spray glass cleaner directly on the mirror as that may cause the liquid cleaner to enter the mirror housing.

# Day/night rearview mirror (if equipped)



[A] : Day, [B] : Night

Make this adjustment before you start driving and whilst the day/night lever is in the day position.

Pull the day/night lever towards you to reduce glare from the headlights of the vehicles behind you during night driving.

Remember that you lose some rearview clarity in the night position.

### **Outside rearview mirror**



Be sure to adjust mirror angles before driving.

Your vehicle is equipped with both lefthand and right-hand outside rearview mirrors.

The mirror heads can be folded to prevent damage during an automatic car wash or when passing through a narrow street.

When vehicle speed is over 9 mph (15 km/h), the outside rearview mirror will not fold.

## **⚠** WARNING

- The left and right outside rearview mirror is convex. Objects seen in the mirror are closer than they appear.
- Use your interior rearview mirror or turn your head and look to determine the actual distance of following vehicles when changing lanes.


# **MARNING**

Do not adjust or fold the outside rearview mirrors whilst driving. This may cause loss of vehicle control resulting in an accident.

## NOTICE

- Do not scrape ice off the mirror face; this may damage the surface of the glass.
- If the mirror is jammed with ice, do not adjust the mirror by force. Use an approved de-icer (not radiator antifreeze) spray, or a sponge or soft cloth with very warm water, or move the vehicle to a warm place and allow the ice to melt.

## Adjusting the rearview mirror



## Manual type

To adjust an outside mirror, move the control lever.



## Electric type

Move the lever (1) to the L (Left) or R (Right) to select the outside rearview mirror you would like to adjust.

Use the mirror adjustment control to position the selected mirror up, down, left or right.

#### NOTICE

- The mirrors stop moving when they reach the maximum adjusting angles, but the motor continues to operate whilst the switch is pressed. Do not press the switch longer than necessary, the motor may be damaged.
- Do not attempt to adjust the outside rearview mirror by hand or the motor may be damaged.

# Folding the outside rearview mirror



### Manual type

To fold the outside rearview mirror, grasp the housing of the mirror and then fold it toward the rear of the vehicle.



## Electric type

The outside rearview mirror can be folded or unfolded by pressing the switch.

## NOTICE


The electric type outside rearview mirror operates even though the ignition switch is in the LOCK/OFF position. However, to prevent unnecessary battery discharge, do not adjust themirrors longer than necessary while the engine is not running.

## NOTICE

Do not fold the electric type out-side rearview mirror by hand. It could cause motor failure.

## **WINDOWS**

## **Power windows (if equipped)**



- (1) Driver's door power window switch\*
- (2) Front passenger's door power window switch\*
- (3) Rear door power window switch (Right)\*
- (4) Rear door power window switch (Left)\*
- (5) Window opening and closing
- (6) Automatic power window\*
- (7) Power window lock switch\*

\*: if equipped

The ignition switch must be in the ON position to be able to raise or lower the windows. Each door has a Power Window switch to control that door's window. The driver has a Power Window Lock switch which can block the operation of rear passenger windows. The power windows will operate for about 3 minutes after the ignition switch is placed in the ACC or LOCK/OFF position. However, if the front doors are opened, the Power Windows cannot be operated even within the 3 minutes period.

## A

## **WARNING**

To avoid serious injury or death, do not extend your head, arms or body outside the windows whilst driving.

## **information**

- In cold and wet climates, power windows may not work properly due to freezing conditions.
- Whilst driving with the rear windows down or with the sunroof (if equipped) opened (or partially opened), your vehicle may demonstrate a wind buffeting or pulsation noise. This noise is normal and can be reduced or eliminated by taking the following actions. If the noise occurs with one or both of the rear windows down, partially lower both front windows about 2.5 cm (one inch).

If you experience the noise with the sunroof open, slightly close the sunroof.

## Window opening and closing



To open or close a window, press down or pull up the front portion of the corresponding switch to the first detent position (5).

# Auto up/down window (if equipped) (Driver's window)



Pressing or pulling up the power window switch momentarily to the second detent position (6) completely lowers orlifts the window even when the switch is released. To stop the window at the desired position while the window is in operation, pull up or press down and release the switch

## To reset the power windows

If the power windows do not operate normally, the automatic power window system must be reset as follows:

- 1. Place the ignition switch to the ON position.
- Close the window and continue pulling up on the power window switch for at least one second.

If the power windows do not operate properly after resetting, it is recommended that the system be checked by a HYUNDAI authorised repairer.

# **WARNING**

The automatic reverse feature doesn't activate whilst resetting power window system. Make sure body parts or other objects are safely out of the way before closing the windows to avoid injuries or vehicle damage.

## Automatic reverse (if equipped)



If a window senses any obstacle whilst it is closing automatically, it will stop and lower about 12 in. (30 cm) to allow the object to be cleared. If the window detects the resistance whilst the power window switch is pulled up continuously, the window will stop upward movement then lower about 1 in. (2.5 cm).

If the power window switch is pulled up continuously again within 5 seconds after the window is lowered by the automatic window reverse feature, the automatic window reverse will not operate.

## information

The automatic reverse feature is only active when the "Auto Up" feature is used by fully pulling up the switch to the second detent.

# **MARNING**

Make sure body parts or other objects are safely out of the way before closing the windows to avoid injuries or vehicle damage.

Objects less than 0.16 in. (4 mm) in diameter caught between the window glass and the upper window channel may not be detected by the automatic reverse window and the window will not stop and reverse direction.

## NOTICE

Do not install any accessories on the windows. The automatic reverse feature may not operate.

#### Power window lock switch



The driver can disable the power window switches on the rear passengers' doors by pressing the power window lock switch.

When the power window lock switch is pressed:

- The driver's master control can operate all the power windows.
- The front passenger's control can operate the front passenger's power window.
- The rear passenger's control cannot operate the rear passengers' power window.

## NOTICE

- To prevent possible damage to the power window system, do not open or close two windows or more at the same time. This will also ensure the longevity of the fuse.
- Never try to operate the main switch on the driver's door and the individual door window switch in opposite directions at the same time. If this is done, the window will stop and cannot be opened or closed.

# **MARNING**

- NEVER leave the keys in your vehicle with unsupervised children, when the engine is running.
- NEVER leave any child unattended in the vehicle. Even very young children may inadvertently cause the vehicle to move, entangle themselves in the windows, or otherwise injure themselves or others.
- Always double check to make sure arms, hands, head and other obstructions are safely out of the way before closing a window.
- Do not allow children to play with the power windows. Keep the driver's door power window lock switch in the LOCK position (pressed). Serious injury can result from unintentional window operation by the child.
- Do not extend your head, arms or body outside the windows whilst driving.

#### **EXTERIOR FEATURES**

#### **Bonnet**


### Opening the bonnet



- Make sure the shift lever is in N (Neutral, for Automated manual transmission) or first gear or R (Reverse, for Manual transmission) and set the parking brake.
- Pull the release lever to unlatch the bonnet. The bonnet should pop up slightly.



 Go to the front of the vehicle, raise the bonnet slightly, push up the secondary hood release lever (1) inside of the bonnet centre and lift the bonnet (2).



- Pull out the stay-rod from the bonnet.
- 5. Hold the bonnet opened with the stay rod.

### Closing the bonnet

- Before closing the bonnet, check the following:
  - All filler caps in engine compartment must be correctly installed.
  - Gloves, rags or any other combustible material must be removed from the engine compartment.
- Return the support rod to its clip location for preventing it from rattling.
- 3. Lower the bonnet halfway (lifted about 1 ft. (30 cm) from the closed position) and push down to securely lock in place. Then double check to be sure the bonnet is secure.

If the bonnet can be raised slightly, it is not securely locked. Open it again and close it with more force

# **MARNING**

- Before closing the bonnet, ensure all obstructions are removed from around the bonnet opening.
- Always double check to be sure that the bonnet is firmly latched before driving away. Check there is no bonnet open warning light or message displayed on the instrument cluster. Driving with the bonnet opened may cause a total loss of visibility, which might result in an accident.
- Do not move the vehicle with the bonnet in the raised position, as vision is obstructed, which might result in an accident, and the bonnet could fall or be damaged.

# Tailgate Opening the tailgate



- The tailgate is locked or unlocked by turning the key to the "Lock" or "Unlock" position. (if equipped)
- The tailgate is locked or unlocked when all doors are locked or unlocked with the remote key, smart key or central door lock/unlock switch. (if quipped with central door lock function)
- If unlocked, the tailgate can be opened by pulling up the tailgate outside handle.

# *i* Information

In cold and wet climates, door lock and door mechanisms may not work properly due to freezing conditions.

# **MARNING**

The tailgate swings upward. Make sure no objects or people are near the rear of the vehicle when opening the tailgate.

## NOTICE

Make certain that you close the tailgate before driving your vehicle. Possible damage may occur to the tailgate lift cylinders and attaching hardware if the tailgate is not closed prior to driving.

### Closing the tailgate

To close the tailgate, lower and push down the tailgate firmly. Make sure that the tailgate is securely latched.



Make sure your hands, feet and other parts of your body are safely out of the way before closing the tailgate.

## **CAUTION**

Make sure nothing is near the tailgate latch and striker whilst closing the tailgate. It may damage the tailgate's latch.

# **MARNING**

#### **Exhaust fumes**

If you drive with the tailgate opened, you will draw dangerous exhaust fumes into your vehicle which can cause serious injury or death to vehicle occupants.

If you must drive with the tailgate opened, keep the air vents and all windows open so that additional outside air comes into the vehicle.

# **MARNING**

Always keep the tailgate lid completely closed whilst the vehicle is in motion. If it is left open or ajar, poisonous exhaust gases containing carbon monoxide (CO) may enter the vehicle and serious illness or death may result.

## **MARNING**

#### Rear cargo area

Occupants should never ride in the rear cargo area where no restraints are available. To avoid injury in the event of an accident or sudden stops, occupants should always be properly restrained.

## **MARNING**



Do not hold the part (gas lifter) that supports the tailgate. Be aware that the deformation of the part may cause vehicle damage and a risk of safety accident.

# Fuel filler door Opening the fuel filler door



The fuel filler door must be opened from inside the vehicle by pulling up the fuel filler door opener.

- Stop the engine.
- 2. Pull the fuel filler door opener up.



- 3. Pull the fuel filler door out (1) to fully open.
- To remove the fuel tank cap (2), turn it counterclockwise. You may hear a hissing noise as the pressure inside the tank equalizes.
- 5. Place the cap on the fuel filler door (3).

## *i* Information

If the fuel filler door does not open because ice has formed around it, tap lightly or push on the door to break the ice and release the door. Do not pry on the door. If necessary, spray around the door with an approved de-icer fluid (do not use radiator anti-freeze) or move the vehicle to a warm place and allow the ice to melt.

## Closing the fuel filler door

- 1. To install the fuel tank cap, turn it clockwise until it "Clicks".
- 2. Close the fuel filler door until it is latched securely.

# **MARNING**

Petrol is highly flammable and explosive. Failure to follow these guidelines may result in SERIOUS INJURY or DEATH:

- Read and follow all warnings posted at the gas station.
- Before refuelling, note the location of the Emergency Petrol Shut-Off, if available, at the gas station.
- Before touching the fuel nozzle, you should eliminate the potential build-up of static electricity by touching a metal part of the vehicle, a safe distance away from the fuel filler neck, nozzle, or other gas source, with your bare hand.
- Do not use mobile phones whilst refuelling. Electric current and/or electronic interference from mobile phones can potentially ignite fuel vapours and cause a fire.

- Do not get back into a vehicle once vou have begun refuelling. You can generate a build-up of static electricity by touching, rubbing or sliding against any item or fabric capable of producing static electricity. Static electricity discharge can ignite fuel vapours causing a fire. If you must re-enter the vehicle, you should once again eliminate potentially dangerous static electricity discharge by touching a metal part of the vehicle, away from the fuel filler neck, nozzle or other petrol source, with your bare hand.
- When refuelling, always move the shift lever to the N (Neutral, for Automated manual transmission) or first gear or R (Reverse, for Manual transmission) position, set the parking brake, and place the ignition switch to the LOCK/OFF position. Sparks produced by electrical components related to the engine can ignite fuel vapours causing a fire.
- When using an approved portable fuel container, be sure to place the container on the ground prior to refuelling. Static electricity discharge from the container can ignite fuel vapours causing a fire. Once refuelling has begun, contact between your bare hand and the vehicle should be maintained until the filling is complete.
- Use only approved portable plastic fuel containers designed to carry and store petrol.

- Do not use matches or a lighter and do not smoke or leave a lit cigarette in your vehicle whilst at a gas station, especially during refuelling.
- Do not over-fill or top-off your vehicle tank, which can cause petrol spillage.
- If a fire breaks out during refuelling, leave the vicinity of the vehicle, and immediately contact the manager of the gas station and then contact the local fire department. Follow any safety instructions they provide.
- If pressurized fuel sprays out, it can cover your clothes or skin and thus subject you to the risk of fire and burns. Always remove the fuel cap carefully and slowly. If the cap is venting fuel or if you hear a hissing sound, wait until the condition stops before completely removing the cap.
- Always check that the fuel cap is installed securely to prevent fuel spillage in the event of an accident.

## Information

Make sure to refuel your vehicle according to the "Fuel Requirements" suggested in the Introduction chapter.


## NOTICE

- Do not spill fuel on the exterior surfaces of the vehicle. Any type of fuel spilled on painted surfaces may damage the paint.
- If the fuel filler cap requires replacement, use only a genuine HYUNDAI cap or the equivalent specified for your vehicle. An incorrect fuel filler cap can result in a serious malfunction of the fuel system or emission control system.

#### **LIGHTING**

## **Exterior lights**

## Lighting control



To operate the lights, turn the knob at the end of the control lever to one of the following positions:

- (1) OFF (O)
- (2) AUTO light (if equipped)
- (3) Position light
- (4) Headlight



## **AUTO** headlight (if equipped)

When the light switch is in the AUTO position, the position light and headlight will be turned ON or OFF automatically depending on the amount of light outside the vehicle.

Even with the AUTO light feature in operation, it is recommended to manually turn ON the lights when driving at night or in a fog, or when you enter dark areas, such as tunnels and parking facilities.

## NOTICE

- Do not cover or spill anything on the sensor (1) located on the instrument panel.
- Do not clean the sensor using a window cleaner, the cleanser may leave a light film which could interfere with sensor operation.
- If your vehicle has window tint or other types of metallic coating on the front windscreen, the AUTO headlight system may not work properly.



## Position light (⊅Œ)

The position light, license plate light and instrument panel light are turned ON.



## Headlight (₺)

The headlight, position light, license plate light and instrument panel light are turned ON.



## Information

The ignition switch must be in the ON position to turn on the headlight.

## High beam operation



To turn on the high beam headlight, push the lever away from you.

The high beam indicator will light when the headlight high beams are switched on.

To turn off the high beam headlight, pull the lever towards you. The low beams will turn on.




## WARNING

Do not use high beam when there are other vehicles approaching you. Using high beam could obstruct the other driver's vision.



To flash the high beam headlight, pull the lever towards you, then release the lever. The high beams will remain ON as long as you hold the lever towards you.

# Turn signals and lane change signals



To signal a turn, push down on the lever for a left turn or up for a right turn in position (A). To signal a lane change, move the turn signal lever slightly and hold it in position (B).

The lever will return to the OFF position when released or when the turn is completed.

If an indicator stays on and does not flash or if it flashes abnormally, one of the turn signal bulbs may be burned out and will require replacement.

## One-touch turn signal function

To activate a one-touch turn signal function, move the turn signal lever slightly and then release it. The lane change signals will blink 3, 5 or 7 times. You can activate or deactivate the One Touch Turn Signal function or choose the number of blinks (3, 5, or 7) from the User Settings Mode on the cluster display. For more details, refer to "Cluster Display Modes" in chapter 4.

## Front fog light (if equipped)



Fog lights are used to provide improved visibility when visibility is poor due to fog, rain or snow, etc.

- 1. Turn on the park light.
- 2. Move the light switch (1) to the front fog light position.
- 3. To turn off the front fog light, turn the light switch to the front fog light position again or turn off the Parking (Position) light

## NOTICE

When in operation, the fog lights consume large amounts of vehicle electrical power. Only use the fog lights when visibility is poor.

## Rear fog light (if equipped)



Vehicle with front fog light To turn on the rear fog light:

Position the light switch in the Position light position, turn the light switch to the front fog light position, and then turn the light switch (1) to the rear fog light position.



Vehicle without front fog light To turn on the rear fog light:

Position the light switch in the headlight position, and then turn the light switch (1) to the rear fog light position.

To turn the rear fog lights off, do one of the following:

- Turn the light switch to the rear fog light position again.
- When the light switch is in the Position light position, if you turn off the front fog light.

## Battery saver function

The purpose of this feature is to prevent the battery from being discharged. The system automatically turns off the position light when the driver turns the engine off and opens the driver-side door.

With this feature, the position lights will turn off automatically if the driver parks on the side of road at night.

However, the position lights stay ON even when the driver-side door is opened if the headlight switch is turned to the position light or AUTO (if equipped) position after the engine is turned off.

If necessary, to keep the lights on turn the position lights OFF and ON again using the headlight switch on the steering column after the engine is turned off.

# Headlight delay function (if equipped)

If you place the ignition switch in the ACC or LOCK/OFF position with the headlights ON, the headlights (and/or position lights) remain on for about 5 minutes. However, with the engine off if the driver's door is opened and closed, the headlights (and/or position lights) are turned off after 15 seconds.

The headlights (and/or position lights) can be turned off by pressing the lock button on the remote key or smart key twice or turning the light switch to the OFF or AUTO position. However, if you turn the light switch to the AUTO position when it is dark outside, the headlights will not be turned off.

## NOTICE

If the driver exits the vehicle through another door besides the driver door, the battery saver function does not operate and the headlight delay function does not turn OFF automatically.

This may cause the battery to discharge. To avoid battery discharge, turn OFF the headlights manually from the headlight switch before exiting the vehicle.

# Daytime running light (DRL) (if equipped)

The Daytime Running Lights (DRL) can make it easier for others to see the front of your vehicle during the day, especially after dawn and before sunset.

The DRL system will turn the dedicated light OFF when:

- 1. The parking brake is applied.
- 2. The engine is turned off.

## Headlight levelling device



To adjust the headlight beam level according to the number of the passengers and loading weight in the luggage area, turn the beam levelling switch.

The higher the number on the switch position, the lower the headlight beam level. Always keep the headlight beam at the proper levelling position, or headlights may dazzle other road users.

Listed below are examples of appropriate switch settings for varying loads. For loading conditions other than those listed, adjust the switch position to the most similar situation.

Loading condition	Switch position
Driver only	0
Driver + Front pas- senger	0
Full passengers (including driver)	1
Full passengers (including driver) + Maximum permissible loading	2
Driver + Maximum permissible loading	3

# Low Beam Assist-Static light (if equipped)

Whilst driving a corner, for greater visibility and safety, either the left or right side Low Beam Assist-Static light will turn on automatically. The Low Beam Assist-Static light will turn on when one of the following conditions occur.

- Vehicle speed is less than 6 mph (10 km/h) and steering wheel angle is turned about 80 degrees with the low beam on.
- Vehicle speed is between 6 mph (10 km/h) to 56 mph (90 km/h) and steering wheel angle is turned about 35 degrees with the low beam on.
- When the vehicle is in reverse with one of the conditions above satisfied, the light opposite to the direction the steering wheel is turned will turn on.

## **Interior lights**

## NOTICE

Do not use the interior lights for extended periods when the engine is turned off or the battery will discharge.

## Interior light AUTO cut

The interior lights will automatically go off about 20 minutes after the engine is turned off and the doors are closed. If a door is opened, the light will go off 25 minutes after the engine is turned off. If the doors are locked by the remote key or smart key and the vehicle enters the armed stage of the theft alarm system, the lights will go off five seconds later.

### Front Room lamp



come on when the front or rear doors are opened if the engine is running or not. When doors are unlocked by the remote key or smart key, the front and rear lights come on for about 30 seconds as long as any door is not opened. The front and rear room lamps go out gradually after about 30 seconds if the door is closed. However, if the ignition switch is in the ON position or all doors are locked, the

front and rear lights will turn off. If a door is opened with the ignition switch in the ACC position or the LOCK/OFF position, the front and rear lights stay on for

: With the Front Room lamp in this position, the front and rear room lamps remain on at all times.

about 10 minutes.

: With the Front Room lamp in this position the front and rear room lamps remain off at all times.

## Luggage compartment lamp



The luggage compartment lamp comes on when the tailgate is opened.

### NOTICE

The luggage compartment comes on as long as the tailgate lid is open. To prevent unnecessary charging system drain, close the tailgate lid securely after using the tailgate.

## Glove box lamp (if equipped)



The glove box lamp comes on when the glove box is opened.

The parking lights or headlights must be ON for the glove box lamp to function.

## Foot lamp



Foot lamp (A): The light turns on when a door is opened and turns off when the door is closed.

#### **HIGH BEAM ASSIST (HBA) (IF EQUIPPED)**



Hight Beam Assist will automatically switch between high beam and low beam depending on the detected brightness from the lamps of oncoming vehicles or vehicles in front.

#### **Detecting sensor**



(1): Front view camera

The front view camera is used as a detecting sensor to detect ambient light and brightness while driving.

Refer to the illustration above for the detailed location of the detecting sensor.

#### NOTICE

- Always keep the front view camera in good condition to maintain optimal performance of High Beam Assist.
- · For more information on the precautions of the front view camera. refer to the "Forward Collision-Avoidance Assist (FCA)" section in chapter 7.

#### **High Beam Assist settings**

With the engine on, select 'Lights→ High Beam Assist (or HBA (High Beam Assist))' from the Settings menu to turn on High Beam Assist and deselect to turn off the function.

#### WARNING

For your safety, change the Settings after parking the vehicle at a safe location.

#### Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

### **High Beam Assist operation** Display and control

- · After selecting High Beam Assist in the Settings menu, High Beam Assist will operate by following the procedure below.
  - Place the headlight switch in the AUTO position and push the headlight lever towards the instrument cluster. The High Beam Assist ( ) indicator light will illuminate on the instrument cluster and High Beam Assist will be enabled
  - When High Beam Assist is enabled. high beam will turn on when vehicle speed is above 20 mph (30 km/h). When vehicle speed is below 12 mph (20 km/h), high beam will turn off.
  - The High Beam (**■**) indicator light will illuminate on the instrument cluster when high beam is on.

- When High Beam Assist is operating, if the headlight lever or switch is used, High Beam Assist operates as follow:
  - If the headlight lever is pulled towards you when the high beam is off, the high beam will turn on without High Beam Assist cancelled. When you let go of the headlight lever, the switch will move to the middle and the high beam will turn off.
  - If the headlight switch is pulled towards you when the high beam is on by High Beam Assist, low beam will turn on and High Beam Assist will turn off.
  - If the headlight switch is placed from AUTO to another position (headlight/position/off), High Beam Assist will turn off and the corresponding light will turn on.
- When High Beam Assist is operating, high beam switches to low beam if any of the following conditions occur:
  - When the headlight of an oncoming vehicle is detected.
  - When the tail light of a vehicle in front is detected.
  - When the headlight or tail light of a motorcycle or a bicycle is detected.
  - When the surrounding ambient light is bright enough that high beams are not required.
  - When streetlights or other lights are detected.

# High Beam Assist malfunction and limitations

#### High Beam Assist malfunction



OAC3069028TU

When High Beam Assist is not working properly, the warning message will appear and  $\wedge$  warning light will illuminate on the instrument cluster. We recommend that the vehicle be inspected by an authorized HYUNDAI dealer.

#### Limitations of High Beam Assist

High Beam Assist may not work properly in the following situations:

- Light from an oncoming or front vehicle is not detected because of lamp damage, or because it is hidden from sight, etc.
- Headlight of an oncoming or front vehicle is covered with dust, snow or water.
- A front vehicle's headlights are off but the fog lights are on and etc.
- There is a lamp that has a similar shape as a vehicle's lamp.
- Headlights have been damaged or not repaired properly.
- Headlights are not aimed properly.
- Driving on a narrow-curved road, rough road, uphill or downhill.
- Vehicle in front is partially visible on a crossroad or curved road.
- There is a traffic light, reflecting sign, flashing sign or mirror ahead.
- There is a temporary reflector or flash ahead (construction area).
- The road conditions are bad such as being wet, iced or covered with snow.
- A vehicle suddenly appears from a curve.
- The vehicle is tilted from a flat tire or is being towed.
- Light from an oncoming or front vehicle is not detected due to obstacles in the air such as exhaust fume, smoke, fog, snow, or water spay or blizzard on the road, or fogging in the lamp, etc.


### *i* Information


For more information on the limitations of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in chapter 7.

## ⚠ WARNING

- At times, High Beam Assist may not work properly. The function is for your convenience only. It is the responsibility of the driver for safe driving practices and always check the road conditions for your safety.
- When High Beam Assist does not operate normally, change the headlight position manually between high beam and low beam.
- High Beam Assist may not operate for 15 seconds after the vehicle is started, or the front view camera is initialized.

#### WIPERS AND WASHERS





#### A: Wiper speed control

- · (√) Single wipe
- · (O) Off
- · (---) Intermittent wipe (if equipped)
- · (1) Low wiper speed
- · (2) High wiper speed
- B: Intermittent wipe time adjustment
- C: Wash with brief wipes (front) (pull lever towards you)
- D: Rear wiper control\*
  - · 2 High wiper speed
  - · 1 Low wiper speed
  - O Off
- E: Wash with brief wipes (rear) (push lever away from you)
- \*: if equipped

#### Windscreen wipers

Operates as follows when the ignition switch is in the ON position.

- (V): For a single wiping cycle, push the lever upward and release. The wipers will operate continuously if the lever is held in this position.
- (O): Wiper is not in operation.
- (---): Wiper operates intermittently at the same wiping intervals. To vary the speed setting, turn the speed control knob (B).
- (1): The wiper runs at a lower speed.
- (2): The wiper runs at a higher speed.

## *i* Information

If there is heavy accumulation of snow or ice on the windscreen, defrost the windscreen for about 10 minutes, or until the snow and/or ice is removed before using the windscreen wipers to ensure proper operation.

If you do not remove the snow and/or ice before using the wiper and washer, it may damage the wiper and washer system.

#### Windscreen washers



In the OFF (O) position, pull the lever gently toward you to spray washer fluid on the windscreen and to run the wipers 1-3 cycles. The spray and wiper operation will continue until you release the lever. If the washer does not work. vou may need to add washer fluid to the washer fluid reservoir.

#### **WARNING**

When the outside temperature is below freezing, ALWAYS warm the windscreen using the defroster to prevent the washer fluid from freezing on the windscreen and obscuring your vision which could result in an accident and serious injury or death.

#### **CAUTION**

- To prevent possible damage to the washer pump, do not operate the washer when the fluid reservoir is emptv.
- To prevent possible damage to the wipers or windscreen, do not operate the wipers when the windscreen is dry.
- To prevent damage to the wiper arms and other components, do not attempt to move the wipers manually.
- To prevent possible damage to the wipers and washer system, use anti-freezing washer fluids in the winter season or cold weather.

# Rear window wiper and washer switch (if equipped)



The rear window wiper and washer switch is located at the end of the wiper and washer switch lever.

Turn the switch to desired position to operate the rear wiper and washer.

- · 2 High wiper speed
- · 1 Low wiper speed
- · O Off



Push the lever away from you to spray rear washer fluid and to run the rear wipers 1~3 cycles. The spray and wiper operation will continue until you release the lever

#### Auto rear wiper

The rear wiper will operate while the vehicle is in R (reverse) with the front wipers ON by selecting the function on the cluster display.

Go to 'User Settings > Convenience > Auto rear wiper (reverse)'

### MANUAL CLIMATE CONTROL SYSTEM (IF EQUIPPED)



- 1. Temperature control knob
- 2. Fan speed control knob
- 3. Mode selection knob
- Air intake control button (recirculated air position or outside (fresh) air position)
- 5. A/C (Air conditioning) button (if equipped)
- 6. Rear window defroster button (if equipped)

### Heating and air conditioning

- 1. Start the engine.
- 2. Set the mode to the desired position. To improve the effectiveness of heating and cooling :

- Heating: 🕶

- 3. Set the temperature control to the desired position.
- 4. Set the air intake control to Fresh mode.
- 5. Set the fan speed control to the desired speed.
- 6. If air conditioning is desired, turn the air conditioning system on.

#### Mode selection





The mode selection knob controls the direction of the air flow through the ventilation system.

Air can be directed to the floor, dashboard outlets, or windscreen. Five symbols are used to represent Face, Bi-Level, Floor, Floor-Defrost and Defrost air position.



Face-Level (B, D)

Air flow is directed toward the upper body and face. Additionally, each outlet can be controlled to direct the air discharged from the outlet.



Bi-Level (B, C, D)

Air flow is directed towards the face and the floor.



Floor-Level (A, C, D)

Most of the air flow is directed to the floor, with a small amount of the air being directed to the windscreen, side window defrosters and side vents.



Floor/Defrost-Level (A, C, D)

Most of the air flow is directed to the floor and the windscreen with a small amount directed to the side window defrosters and side vents.



Defrost-Level (A, D)

Most of the air flow is directed to the windscreen with a small amount of air directed to the side yents



#### **Instrument panel vents**

The instrument panel vent air flow can be directed up/down or left/right using the vent adjustment lever.

To close the vent adjustment lever, rotate it to the outer side till the end. To open the vent, rotate it to the inner side.

#### Temperature control



The temperature will increase by turning the knob to the right.

The temperature will decrease by turning the knob to the left.

#### Air intake control



The air intake control button is used to select either Fresh mode (outside air) or Recirculation mode (cabin air).

#### **Recirculation mode**



When Recirculation mode is selected, air from the passenger compartment will be recirculated through the system and heated or cooled according to the function selected.

#### Fresh mode



When Fresh mode is selected, air enters the vehicle from outside and is heated or cooled according to the function selected.

#### i Information

Operating the system primarily in Fresh mode is recommended. Use Recirculation mode temporarily only when needed.

Prolonged operation of the heater in Recirculation mode and without the A/C ON can cause fogging of the windscreen.

In addition, prolonged use of the A/C ON in Recirculation mode may result in excessively dry, dehumidified air in the cabin and may promote formation of musty vent odor due to stagnant air.

#### **⚠ WARNING**

- · Continued use of the climate control system operation in Recirculation mode for a prolonged period of time may cause drowsiness to the occupants in the cabin. This may lead to loss of vehicle control which may lead to an accident.
- · Continued use of the climate control system operation in Recirculation mode with the A/C OFF may allow humidity to increase inside the cabin.

This may cause condensation to accumulate on the windscreen and obscure visibility.

· Do not sleep in your vehicle or remain parked in your vehicle with the windows up and either the heater or the air conditioning ON for prolonged periods of time. Doing so may increase the levels of carbon dioxide in the cabin which may lead to serious injury or death.

#### Fan speed control



Turn the knob to the right to increase the fan speed and airflow. Turn the knob to the left to decrease fan speed and airflow.

Setting the fan speed control knob to the "0" position turns off the fan.

#### NOTICE

Operating the fan speed when the ignition switch is in the ON position could cause the battery to discharge. Operate the fan speed when the engine is running.

### Air conditioning



Press the A/C button to turn the air conditioning system on (indicator light will illuminate). Press the button again to turn the air conditioning system off.

#### **System operation**

#### Ventilation

- 1. Select the Face Level " mode.
- 2. Set the air intake control to fresh mode.
- 3. Set the temperature control to the desired position.
- 4. Set the fan speed control to the desired speed.

#### Heating

- 1. Select the Floor Level with mode.
- 2. Set the air intake control to fresh mode.
- 3. Set the temperature control to the desired position.
- 4. Set the fan speed control to the desired speed.
- If desired, turn the air conditioning ON with the temperature control knob set to heat in order to dehumidify the air before it enters into the cabin.

If the windscreen fogs up, select the Floor & Defrost mode or press the Front Defrost mode.

### **Operation Tips**

 To keep dust or unpleasant fumes from entering the vehicle through the ventilation system, temporarily set the air intake control to the recirculation mode. Be sure to return the control to fresh mode position when the irritation has passed to keep fresh air in the vehicle. This will help keep the driver alert and comfortable.  To prevent interior fog on the windscreen, set the air intake control to fresh mode and fan speed to the desired position, turn on the air conditioning system, and adjust the temperature control to desired temperature.

#### Air conditioning

HYUNDAI Air Conditioning Systems are filled with R-134a or R1234yf refrigerant

- 1. Start the engine.
- 2. Push the air conditioning button.
- Select the Face Level mode.
- 4. Set the air intake control to Recirculation mode temporarily to allow the cabin to cool quickly. When the desired temperature in the cabin is reached, change the air intake control back to Fresh mode.
- Adjust the fan speed control and temperature control to maintain maximum comfort.

#### NOTICE

- The refrigerant system should only be serviced by trained and certified technicians to insure proper and safe operation.
- The refrigerant system should be serviced in a well-ventilated place.

### *i* Information

- When using the air conditioning system, monitor the temperature gauge closely whilst driving up hills or in heavy traffic when outside temperatures are high. Air conditioning system operation may cause engine overheating. Continue to use the blower fan but turn the air conditioning system off if the temperature gauge indicates engine overheating.
- When opening the windows in humid weather, air conditioning may create water droplets inside the vehicle. Since excessive water droplets may cause damage to electrical equipment, air conditioning should only be used with the windows closed.


# Air conditioning system operation tips

- If the vehicle has been parked in direct sunlight during hot weather, open the windows for a short time to let the hot air inside the vehicle escape.
- After sufficient cooling has been achieved, switch back from recirculation mode to fresh mode.
- To help reduce moisture inside of the windows on rainy or humid days, decrease the humidity inside the vehicle by operating the air conditioning system with the windows and sunroof closed.
- During air conditioning system operation, you may occasionally notice a slight change in engine speed as the air conditioning compressor cycles. This is a normal system operation characteristic.

- Use the air conditioning system every month only for a few minutes to ensure maximum system performance.
- When using the air conditioning system, you may notice clear water dripping (or even puddling) on the ground under the passenger side of the vehicle. This is a normal system operation characteristic.
- If you operate the air conditioner excessively, the difference bet-ween the temperature of the outside air and that of the windscreen could cause the outer surface of the windscreen to fog up, causing loss of visibility. In this case, set the mode selection button to the position and set the fan speed control knob to the lowest speed setting.

#### **System maintenance**

#### Climate control air filter



- [A] : Outside air, [B] : Recirculated air
- [C]: Climate control air filter. [D]: Blower
- [E]: Evaporator core, [F]: Heater core

This filter is installed behind the glove box. It filters the dust or other pollutants that enter the vehicle through the heating and air conditioning system. We recommend that the climate control air filter be replaced by a HYUNDAI authorised repairer according to the maintenance schedule. If the vehicle is being driven in severe conditions such as dusty or rough roads, more frequent climate control filter inspections and changes are required.

If the air flow rate suddenly decreases. we recommend the system be checked at a HYUNDAI authorised repairer.

## Information

- Replace the filter according to the Maintenance Schedule.
  - If the car is being driven in severe conditions such as dusty, rough roads, more frequent climate control air filter inspections and changes are required.
- When the air flow rate suddenly decreases, we recommend that the system be checked by a HYUNDAI authorised repairer.

#### Checking the amount of air conditioner refrigerant and compressor lubricant

When the amount of refrigerant is low, the performance of the air conditioning is reduced. Overfilling also has a bad influence on the air conditioning system.

Therefore, if abnormal operation is found, we recommend that the system be inspected by a HYUNDAI authorised repairer.

#### NOTICE

It is important that the correct type and amount of oil and refrigerant is used. Otherwise, damage to the compressor and abnormal system operation may occur. To prevent damage, the air conditioning system in your vehicle should only be serviced by trained and certified technicians.

### ! WARNING

Vehicles equipped with R-134a



Since the refrigerant is operated at very high pressure, the air conditioning system should only be serviced

trained and certified technicians.

All refrigerants should be reclaimed with proper equipment.

Venting refrigerants directly to the atmosphere is harmful to individuals and environment. Failure to heed these warnings can lead to serious injuries.

## **MARNING**

#### Vehicles equipped with R-1234yf





Since the refrigerant is mildly flammable and operated at high pressure, the air conditioning system should only be serviced by trained and certified technicians. It is important that the correct type and amount of oil and refrigerant are used.


All refrigerants should be reclaimed with proper equipment.

Venting refrigerants directly to the atmosphere is harmful to individuals and environment. Failure to heed these warnings can lead to serious injuries.



Air Conditioning refrigerant label (if equipped)

You can find out which air conditioning refrigerant is applied to your vehicle on the label located inside of the bonnet.



Each symbols and specification on the air conditioning refrigerant label is represented as below:

SAE J639 J2842 J2845

OHYK059001

- 1. Classification of refrigerant
- 2. Amount of refrigerant
- Classification of compressor lubricant
- 4. Caution
- 5. Flammable refrigerant
- 6. To require registered technician to service air conditioning system
- 7. Service manual

### **AUTOMATIC CLIMATE CONTROL SYSTEM (IF EQUIPPED)**



- 1. Fan speed control knob
- 2. A/C (Air conditioning) button
- 3. Recirculation mode/Fresh mode
- 4. Mode selection button
- 5. Rear window defroster button (if equipped)
- 6. Front windscreen defroster button
- 7. OFF button
- 8. Temperature control knob
- 9. AUTO (automatic control) button
- 10. Climate control screen

# Automatic heating and air conditioning



#### 1. Press the AUTO button.

The modes, fan speeds, air intake and air-conditioning will be controlled automatically according to the temperature setting you select.



 Turn the temperature control knob to set the desired temperature. If the temperature is set to the lowest setting (Lo), the air conditioning system will operate continuously.

- To turn the automatic operation off, select any button of the following:
  - Mode selection button
  - Front windscreen defroster button (Press the button one more time to deselect the front windscreen defroster function. The 'AUTO' sign will illuminate on the information screen once again.)
  - Fan speed control toggle switch The selected function will be controlled manually whilst other functions operate automatically.
- For your convenience, use the AUTO button and set the temperature to 22°C (72°F).



### *i* Information

Never place anything near the sensor to ensure better control of the heating and cooling system.

# Manual heating and air conditioning

The heating and cooling system can be controlled manually by pushing buttons other than the AUTO button. In this case, the system works sequentially according to the order of buttons selected. When pressing any button except the AUTO button whilst using automatic operation, the functions not selected will be controlled automatically.

- 1. Start the engine.
- Set the mode to the desired position.To improve the effectiveness of heating and cooling, select the mode according to the following:

- Heating : 🕶

- 3. Set the temperature control to the desired position.
- 4. Set the air intake control to fresh mode.
- 5. Set the fan speed control to the desired speed.
- 6. If air conditioning is desired, turn the air conditioning system on.
- Press the AUTO button in order to convert to full automatic control of the system.

#### Mode selection





The mode selection button controls the direction of the air flow through the ventilation system.

The air flow outlet direction is cycled as follows:





Air flow is directed toward the upper body and face. Additionally, each outlet can be controlled to direct the air discharged from the outlet.

Air flow is directed towards the face and the floor.

Most of the air flow is directed to the floor, with a small amount of the air being directed to the windscreen and side window defrosters



### Floor & Defrost (A, C, D)

Most of the air flow is directed to the floor and the windscreen with a small amount directed to the side window defrosters.



#### Defrost-Level (A, D)

Most of the air flow is directed to the windscreen with a small amount of air directed to the side window defrosters.



#### **Instrument panel vents**

The instrument panel vent air flow can be directed up/down or left/right using the vent adjustment lever.

To close the vent adjustment lever. rotate it to the outer side till the end. To open the vent, rotate it to the inner side.

#### Temperature control



The temperature will increase by turning the knob to the right.

The temperature will decrease by turning the knob to the left.

The temperature will increase or decrease by 0.5°C (1°F) for each incremental location. When set to the lowest temperature setting, the air conditioning will operate continuously.

#### **Temperature conversion**

If the battery has been discharged or disconnected, the temperature mode display will reset to Centigrade.

To change the temperature unit from  $^{\circ}$ C to  $^{\circ}$ F or  $^{\circ}$ F to  $^{\circ}$ C :

- Automatic climate control system
   Press the AUTO button for 3 seconds whilst pressing the OFF button.
- Instrument cluster
   Go to User Settings > Other Features
   Temperature Unit.

The temperature unit on both the cluster display and the climate control screen will change.

#### Air intake control



This is used to select the outside (fresh) air position or recirculated air position. To change the air intake control position, push the control button.

#### Recirculated air position



With the recirculated air position selected, air from the passenger compartment will be drawn through the heating system and heated or cooled according to the function selected.

#### Outside (fresh) air position



With the outside (fresh) air position selected, air enters the vehicle from outside and is heated or cooled according to the function selected.

## *i* Information

Operating the system primarily in Fresh mode is recommended. Use Recirculation mode temporarily only when needed.

Prolonged operation of the heater in Recirculation mode and without the A/C ON can cause fogging of the windscreen.

In addition, prolonged use of the A/C ON in Recirculation mode may result in excessively dry, dehumidified air in the cabin and may promote formation of musty vent odor due to stagnant air.

### **⚠** WARNING

- Continued use of the climate control system operation in Recirculation mode for a prolonged period of time may cause drowsiness to the occupants in the cabin. This may lead to loss of vehicle control which may lead to an accident.
- Continued use of the climate control system operation in Recirculation mode with the A/C OFF may allow humidity to increase inside the cabin.

This may cause condensation to accumulate on the windscreen and obscure visibility.

 Do not sleep in your vehicle or remain parked in your vehicle with the windows up and either the heater or the air conditioning ON for prolonged periods of time. Doing so may increase the levels of carbon dioxide in the cabin which may lead to serious injury or death.

#### Fan speed control



Turn the knob to the right to increase the fan speed and airflow. Turn the knob to the left to decrease fan speed and airflow.

#### NOTICE

Operating the fan speed when the ignition switch is in the ON position could cause the battery to discharge. Operate the fan speed when the engine is running.


#### Air conditioning



Push the A/C button to manually turn the air conditioning system on (indicator light will illuminate).

Push the button again to turn the air conditioning system off.

#### OFF mode



Push the OFF button of the front to turn off the air climate control system. However, you can still operate the mode and air intake buttons as long as the ignition switch is in the ON position.

#### **System operation**

#### Ventilation

- 1. Select the Face Level 🖈 mode.
- 2. Set the air intake control to fresh mode.
- 3. Set the temperature control to the desired position.
- 4. Set the fan speed control to the desired speed.

#### Heating

- 1. Select the Floor Level vi mode.
- 2. Set the air intake control to fresh mode.
- 3. Set the temperature control to the desired position.
- 4. Set the fan speed control to the desired speed.
- If desired, turn the air conditioning ON with the temperature control knob set to heat in order to dehumidify the air before it enters into the cabin.

If the windscreen fogs up, select the Floor & Defrost mode or press the Front Defrost mode.

#### **Operation Tips**

- To keep dust or unpleasant fumes from entering the vehicle through the ventilation system, temporarily set the air intake control to the recirculation mode. Be sure to return the control to fresh mode position when the irritation has passed to keep fresh air in the vehicle. This will help keep the driver alert and comfortable.
- To prevent interior fog on the windscreen, set the air intake control to fresh mode and fan speed to the desired position, turn on the air conditioning system, and adjust the temperature control to desired temperature.

#### Air conditioning

HYUNDAI Air Conditioning Systems are filled with R-134a or R1234yf refrigerant.

- 1. Start the engine.
- 2. Push the air conditioning button.
- 3. Select the Face Level 🔰 mode.
- 4. Set the air intake control to Recirculation mode temporarily to allow the cabin to cool quickly. When the desired temperature in the cabin is reached, change the air intake control back to Fresh mode.
- Adjust the fan speed control and temperature control to maintain maximum comfort.

### NOTICE

- The refrigerant system should only be serviced by trained and certified technicians to insure proper and safe operation.
- The refrigerant system should be serviced in a well-ventilated place.

## *i* Information


- When using the air conditioning system, monitor the temperature gauge closely whilst driving up hills or in heavy traffic when outside temperatures are high. Air conditioning system operation may cause engine overheating. Continue to use the blower fan but turn the air conditioning system off if the temperature gauge indicates engine overheating.
- When opening the windows in humid weather, air conditioning may create water droplets inside the vehicle. Since excessive water droplets may cause damage to electrical equipment, air conditioning should only be used with the windows closed.

# Air conditioning system operation tips

- If the vehicle has been parked in direct sunlight during hot weather, open the windows for a short time to let the hot air inside the vehicle escape.
- After sufficient cooling has been achieved, switch back from recirculation mode to fresh mode.
- To help reduce moisture inside of the windows on rainy or humid days, decrease the humidity inside the vehicle by operating the air conditioning system with the windows and sunroof closed.
- During air conditioning system operation, you may occasionally notice a slight change in engine speed as the air conditioning compressor cycles. This is a normal system operation characteristic.
- Use the air conditioning system every month only for a few minutes to ensure maximum system performance.
- When using the air conditioning system, you may notice clear water dripping (or even puddling) on the ground under the passenger side of the vehicle. This is a normal system operation characteristic.
- If you operate the air conditioner excessively, the difference between the temperature of the outside air and that of the windscreen could cause the outer surface of the windscreen to fog up, causing loss of visibility. In this case, set the mode selection button to the position and set the fan speed control knob to the lowest speed setting.

### System maintenance

#### Climate control air filter



[A]: Outside air, [B]: Recirculated air

[C]: Climate control air filter, [D]: Blower

[E]: Evaporator core, [F]: Heater core

The climate control air filter installed behind the glove box filters the dust or other pollutants that come into the vehicle from the outside through the heating and air conditioning system. If dust or other pollutants accumulate in the filter over a period of time, the air flow from the air vents may decrease, resulting in moisture accumulation on the inside of the windscreen even when the outside (fresh) air position is selected.

If this happens, we recommend that the climate control air filter be replaced by a HYUNDAI authorised repairer.

## i Information

• Replace the filter according to the Maintenance Schedule.

If the car is being driven in severe conditions such as dusty, rough roads, more frequent climate control air filter inspections and changes are required.

• When the air flow rate suddenly decreases, we recommend that the system be checked by a HYUNDAI authorised repairer.

#### Checking the amount of air conditioner refrigerant and compressor lubricant

When the amount of refrigerant is low. the performance of the air conditioning is reduced. Overfilling also has a bad influence on the air conditioning system.

Therefore, if abnormal operation is found, we recommend that the system be inspected by a HYUNDAI authorised repairer.

### NOTICE

It is important that the correct type and amount of oil and refrigerant is used. Otherwise, damage to the compressor and abnormal system operation may occur. To prevent damage, the air conditioning system in your vehicle should only be serviced by trained and certified technicians.



#### Vehicles equipped with R-134a



Since the refrigerant is operated at very high pressure, the air conditioning system should only be serviced by

trained and certified technicians.

All refrigerants should be reclaimed with proper equipment.

Venting refrigerants directly to the atmosphere is harmful to individuals and environment. Failure to heed these warnings can lead to serious iniuries.



### **⚠ WARNING**

#### Vehicles equipped with R-1234vf



Since the refrigerant is mildly flammable and operated at high pressure, the air conditioning system should only be serviced by trained and certified technicians. It is important that the correct type and amount of oil



and refrigerant are used.


All refrigerants should be reclaimed with proper equipment.

Venting refrigerants directly to the atmosphere is harmful to individuals and environment. Failure to heed these warnings can lead to serious injuries.



Air Conditioning refrigerant label (if equipped)

You can find out which air conditioning refrigerant is applied to your vehicle on the label located inside of the bonnet.





Each symbols and specification on the air conditioning refrigerant label is represented as below:

- 1. Classification of refrigerant
- 2. Amount of refrigerant
- 3. Classification of compressor lubricant
- 4. Caution
- 5. Flammable refrigerant
- 6. To require registered technician to service air conditioning system
- 7. Service manual

#### WINDSCREEN DEFROSTING AND DEFOGGING



#### **⚠** WARNING


#### Windscreen heating

Do not use the wor or my position during cooling operation in extremely humid weather. The difference between the temperature of the outside air and that of the windscreen could cause the outer surface of the windscreen to fog up, causing loss of visibility. In this case, set the mode selection knob or button to the position and fan speed control knob or button to lower speed.

- For maximum defrost performance, set the temperature control knob to highest temperature (rotated all the way to the right) and the fan speed control to the highest settina.
- · If warm air to the floor is desired whilst defrosting or defogging, set the mode to the floor-defrost position.
- · Before driving, clear all snow and ice from the windscreen, rear window, outside rear view mirrors, and all side windows
- Clear all snow and ice from the bonnet and air inlet in the cowl grill to improve heater and defroster efficiencv and to reduce the probability of fogging up inside of the windscreen.
- If the engine temperature is still cold after starting, then a brief engine warm up period may be required for the vented air flow to become warm or hot

# Automatic climate control system

#### To defog inside windscreen




- 1. Select desired fan speed.
- 2. Select desired temperature.
- 3. Press the defroster button ( ).
- The air-conditioning will turn on according to the detected ambient temperature, outside (fresh) and higher fan speed will be selected automatically.

If the air-conditioning, outside (fresh) air position and higher fan speed are not selected automatically, adjust the corresponding button or knob manually.

If the most position is selected, lower fan speed is adjusted to higher fan speed.

#### To defrost outside windscreen



- 1. Set the fan speed to the highest position.
- 2. Set the temperature to the extreme hot (HI) position.
- 3. Press the defroster button ( ).
- The air-conditioning will turn on according to the detected ambient temperature and outside (fresh) mode will be selected automatically.

If the position is selected, lower fan speed is adjusted to higher fan speed

#### **Defroster**

#### NOTICE

To prevent damage to the conductors bonded to the inside surface of the rear window, never use sharp instruments or window cleaners containing abrasives to clean the window.

## information

If you want to defrost and defog the front windscreen, refer to "Windscreen Defrosting and Defogging" in this chapter.

#### Rear window defroster



The defroster heats the window to remove frost, fog and thin ice from the interior and exterior of the rear window, whilst engine is running.

- To activate the rear window defroster, press the rear window defroster button located in the centre facia switch panel. The indicator on the rear window defroster button illuminates when the defroster is ON.
- To turn off the defroster, press the rear window defroster button again.

## Information

- If there is heavy accumulation of snow on the rear window, brush it off before operating the rear defroster.
- The rear window defroster automatically turns off after about 20 minutes or when the ignition switch is in the LOCK/OFF position.

#### STORAGE COMPARTMENT



### **⚠** WARNING

Never store cigarette lighters, propane cylinders, or other flammable/ explosive materials in the vehicle. These items may catch fire and/or explode if the vehicle is exposed to hot temperatures for extended periods.




#### WARNING

ALWAYS keep the storage compartment covers closed securely whilst driving. Items inside your vehicle are moving as fast as the vehicle. If you have to stop or turn quickly, or if there is a crash, the items may fly out of the compartment and may cause an injury if they strike the driver or a passenger.

### NOTICE

To avoid possible theft, do not leave valuables in the storage compartments.

### Centre console storage



These compartments can be used to store small item.



#### WARNING

Do not place the heavy, sharp or breakable objects in the tray. Such objects can be thrown from the trav in the event of a sudden stop or an accident, possibly injuring the passengers in the vehicle.

#### Glove box



To open the glove box, pull the lever and the glove box will automatically open. Close the glove box after use.



ALWAYS close the glove box door after use.

An open glove box door can cause serious injury to the passenger in an accident, even if the passenger is wearing a seat belt.

#### **TRAY**



## **⚠** WARNING

Do not place the heavy, sharp or breakable objects in the tray. Such objects can be thrown from the tray in the event of a sudden stop or an accident, possibly injuring the passengers in the vehicle.

# INTERIOR FEATURES Ashtray (if equipped)



To use the ashtray, open the cover. To clean or empty the ashtray, pull the ashtray out.

Do not use the vehicle's ashtray as waste receptacles.



#### Ashtray use

Putting lit cigarettes or matches in an ashtray with other combustible materials may cause a fire.

#### **Cup holder (if equipped)**



Cups or small beverages cups may be placed in the cup holders.



- Avoid abrupt starting and braking when the cup holder is in use to prevent spilling your drink. If hot liquid spills, you could be burned. Such a burn to the driver could cause loss of vehicle control resulting in an accident.
- Do not place uncovered or unsecured cups, bottles, cans, etc., in the cup holder containing hot liquid whilst the vehicle is in motion. Injuries may result in the event of sudden stop or collision.
- Only use soft cups in the cup holders. Hard objects can injure you in an accident.




Keep cans or bottles out of direct sun light and do not put them in a hot vehicle. It may explode.

#### NOTICE

- Keep your drinks sealed whilst driving to prevent spilling your drink. If liquid spills, it may get into the vehicle's electrical/electronic system and damage electrical/ electronic parts.
- When cleaning spilled liquids, do not dry the cup holder using hot temperatures. This may damage the cup holder.

#### **Sunvisor**





To use a sunvisor, pull it downward.

To use a sunvisor for a side window, pull it downward, unsnap it from the bracket (1) and swing it to the side (2). Use the ticket holder (3) to hold tickets. To use the vanity mirror, pull down the

To use the vanity mirror, pull down the sunvisor (4).

Close the vanity mirror cover securely and return the sunvisor to its original position after use.



For your safety, do not block your view when using the sunvisor.

#### NOTICE

Do not put several tickets in the ticket holder at one time. This could cause damage to the ticket holder.

#### **Power outlet**



The power outlet is designed to provide power for mobile telephones or other devices designed to operate with vehicle electrical systems.

The devices should draw less than 180 W(Watts) with the engine running.



Avoid electrical shocks. Do not place your fingers or foreign objects (pin, etc.) into a power outlet or touch the power outlet with a wet hand.


#### NOTICE

To prevent damage to the Power Outlets:

- Use the power outlet only when the engine is running and remove the accessory plug after use.
   Using the accessory plug for prolonged periods of time with the engine off could cause the battery to discharge.
- Only use 12 V electric accessories which are less than 180 W(Watts) in electric capacity.
- Adjust the air-conditioner or heater to the lowest operating level when using the power outlet.
- · Close the cover when not in use.
- Some electronic devices can cause electronic interference when plugged into a vehicle's power outlet. These devices may cause excessive audio static and malfunctions in other electronic systems or devices used in your vehicle.
- Push the plug in as far as it will go.
  If good contact is not made, the
  plug may overheat and the fuse
  may open.
- Plug in battery equipped electrical/ electronic devices with reverse current protection. The current from the battery may flow into the vehicle's electrical/electronic system and cause system malfunction.

#### **USB** charger





The USB charger is located inside the console box between the driver's seat and the front passenger's seat. Insert the USB charger into the USB port, and re-charge a smart phone or a tablet PC.

- A charging status/charging completion message is displayed on a screen of a smart phone or a tablet PC.
- A smart phone or a tablet PC may get warmer during the re-charging process. It does not indicate any malfunction with the charging system.
- A smart phone or a tablet PC, which adopts a different re-charging method, may not be properly re-charged. In this case, use an exclusive charger of your device.
- The charging terminal is only to recharge a device. Do not use the charging terminal either to turn ON an audio or to play media on the Infotainment system.

# Wireless mobile phone charging system (if equipped)



[A]: Indicator, [B]: Charging pad

There is a wireless mobile phone charger inside the front console.

The system is available when all doors are closed, and when the ignition switch is in the ON position.

### To charge a mobile phone

The wireless mobile phone charging system charges only the Qi-enabled mobile phones (**Qi**). Read the label on the mobile phone accessory cover or visit your mobile phone manufacturer's website to check whether your mobile phone supports the Qi technology.

The wireless charging process starts when you put a Qi-enabled mobile phone on the wireless charging unit.

- Remove other items, including the smart key, from the wireless charging unit. If not, the wireless charging process may be interrupted. Place the mobile phone on the centre of charging pad.
- The indicator light is orange when the mobile phone is charging. The indicator light turns green when phone charging is complete.
- You can turn ON or OFF the wireless charging function in the User Settings mode on the instrument cluster. For further information, refer to the "Cluster Display Modes" in this chapter.

If your mobile phone is not charging:

- Slightly change the position of the mobile phone on the charging pad.
- Make sure the indicator light is orange.

The indicator light will blink orange for 10 seconds if there is a malfunction in the wireless charging system.

In this case, temporarily stop the charging process, and re-attempt to wirelessly charge your mobile phone again.

The system warns you with a message on the cluster display if the mobile phone is still on the wireless charging unit after the engine is turned OFF and the front door is opened.

For some manufacturers' mobile phones, the system may not warn you even though the mobile phone is left on the wireless charging unit. This is due to the particular characteristic of the mobile phone and not a malfunction of the wireless charging.

## NOTICE

- The wireless mobile phone charging system may not support certain mobile phones, which are not verified for the Qi specification (Qi).
- When placing your mobile phone on the charging mat, position the phone in the middle of the mat for optimal charging performance. If your cell phone is off to the side, the charging rate may be less and in some cases the cell phone may experience higher heat conduction.
- In some cases, the wireless charging may stop temporarily when the Remote Key or Smart Key is used, either when starting the vehicle or locking/unlocking the doors, etc.
- When charging certain mobile phones, the charging indicator may not change to green when the cell phone is fully charged.
- The wireless charging process may temporarily stop, when temperature abnormally increases inside the wireless mobile phone charging system. The wireless charging process restarts, when temperature falls to a certain level.
- The wireless charging process may temporarily stop when there is any metallic item, such as a coin, between the wireless mobile phone charging system and a mobile phone.

- When charging some mobile phones with a self-protection feature, the wireless charging speed may decrease and the wireless charging may stop.
- If the mobile phone has a thick cover, the wireless charging may not be possible.
- If the mobile phone is not completely contacting the charging pad, wireless charging may not operate properly.
- Some magnetic items (credit cards, phone cards, passbook and tickets) may be damaged whilst using the wireless charging process.
- When any mobile phone without a wireless charging function or a metallic object is placed on the charging pad, a small noise may sound. This small sound is due to the vehicle discerning compatibility of the object placed on the charging pad. It does not affect your vehicle or the mobile phone in any way.

# **i** Information

If the ignition switch is in the LOCK/OFF position, the charging also stops.

### Clock



### ↑ WARNING

Do not adjust the clock whilst driving. You may lose your steering control and cause severe personal injury or accidents.

For more details, please refer to the manual that was supplied with vour vehicle.



### i Information


The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

## Coat hook (if equipped)



These hooks are not designed to hold large or heavy items.

# **!** WARNING



Do not hang other objects such as hangers or hard objects except clothes. Also, do not put heavy, sharp or breakable objects in the clothes pockets. In an accident or when the curtain airbag is inflated, it may cause vehicle damage or personal injury.

# Floor mat anchor(s) (if equipped)



ALWAYS use the Floor Mat Anchors to attach the front floor mats to the vehicle. The anchors on the front floor carpet keep the floor mats from sliding forward.

**MARNING** 

The following must be observed when installing ANY floor mat to the vehicle.

- Ensure to remove a protective film attached on the carpet before attaching a floor mat on the front floor carpet. Otherwise, the floor mat may move freely on the protective film and it could result in unintentional braking or accelerating.
- Ensure that the floor mats are securely attached to the vehicle's floor mat anchor(s) before driving the vehicle.
- Do not use ANY floor mat that cannot be firmly attached to the vehicle's floor mat anchors.

 Do not stack floor mats on top of one another (for example, allweather rubber mat on top of a carpeted floor mat). Only a single floor mat should be installed in each position.

IMPORTANT - Your vehicle was manufactured with driver's side floor mat anchors that are designed to securely hold the floor mat in place. To avoid any interference with pedal operation, HYUNDAI recommends that the HYUNDAI floor mat designed for use in your vehicle be installed.

## Luggage net (holder) (if equipped)



To keep items from shifting in the cargo area, you can use the four holders located in the cargo area to attach the luggage net.

If necessary, we recommend that you contact a HYUNDAI authorised repairer to obtain a luggage net.



### **CAUTION**

To prevent damage to the goods or the vehicle, care should be taken when carrying fragile or bulky objects in the luggage compartment.



# WARNING

To avoid eye injury, DO NOT overstretch the luggage net. ALWAYS keep your face and body out of the luggage net's recoil path. DO NOT use the luggage net when the strap has visible signs of wear or damage.

# Cargo area cover (if equipped)



Use the cargo area cover to hide items stored in the cargo area.

The cargo area cover can be uprighted or removed



## **⚠** WARNING

- Do not place objects on the cargo area cover. Such objects may be thrown about inside the vehicle and possibly injure vehicle occupants during an accident or braking.
- · Never allow anyone to ride in the luggage compartment. designed for luggage only.

## NOTICE

Do not put luggage on the cover since it may be damaged or malformed.

### **INFOTAINMENT SYSTEM**

# *i* Information

- If you install an aftermarket HID headlight, your vehicle's audio and electronic device may malfunction.
- Prevent chemicals such as perfume, cosmetic oil, sun cream, hand cleaner, and air freshener from contacting the interior parts because they may cause damage or discolouration.

## **USB** port



You can use an USB port to plug in an USB

# Information

When using a portable audio device connected to the power outlet, noise may occur during playback. If this happens, use the power source of the portable audio device.

### **Antenna**



The roof antenna receives DAB (if equipped) and both AM and FM broadcast signals. Rotate the roof antenna in a counterclockwise direction to remove it. Rotate it in a clockwise direction to reinstall it.

### NOTICE

- Before entering a place with a low height clearance, be sure that the antenna is removed.
- Be sure to remove the antenna before washing the vehicle in an automatic car wash or it may be damaged.
- When reinstalling your antenna, it is important that it is fully tightened and adjusted to the upright position to ensure proper reception. But it could be removed when parking the vehicle.

## NOTICE

Installation of aftermarket antenna may result in water leakage, wind noise, rattling & improper radio operation. We recommend to use the antenna available with a HYUNDAI authorised repairer.

# *i* Information

Some models do not have audio (plastic blanking cover) system, and will not supply radio main cable. Thus if you want to insert Aftermarket audio or OEM audio to listen radio broadcasting service, we recommend to use the feeder cable available with a HYUNDAI authorised repairer.

# Steering wheel audio control (if equipped)







The steering wheel audio control switches are installed for your convenience.

## NOTICE

Do not operate audio remote control buttons simultaneously.

### VOLUME ( ◀ + / ┫ − ) (1)

- Press the up button (+) to increase volume.
- Press the down button (-) to decrease volume.

### SEEK/PRESET ( $\land$ / $\lor$ ) (2)

If the SEEK/PRESET toggle switch is moved up or down and held for 0.8 second or more, it will function in the following modes.

#### RADIO mode

It will function as the AUTO SEEK select switch. It will SEEK until you release the switch.

#### MEDIA mode

It will function as the FF/REW switch. If the SEEK/PRESET toggle switch is moved up or down, it will function in the following modes.

#### RADIO mode

It will function as the PRESET STA-TION UP/DOWN switch.

### **MEDIA** mode

It will function as the TRACK UP/DOWN switch.

### **MODE** (○) (3)

Press the MODE button to select RADIO/MEDIA/Bluetooth Audio, etc.

### MUTE (或) (4, if equipped)

- · Press the button to mute the sound.
- Press the button again to activate the sound.

# *i* Information

Detailed information for audio control buttons are described in the following pages in this chapter.

# Audio / Video / Navigation system (if equipped)

Detailed information for the navigation system is described in a separately supplied manual.

# *i* Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

### Bluetooth® Wireless Technology hands-free (if equipped)






You can use the phone wirelessly by using the Bluetooth® Wireless Technology.

- (1) Call / Answer button
- (2) Call end button
- (3) Microphone
- Audio: For detailed information, refer to "AUDIO" in this chapter.
- Navigation: Detailed information for the Bluetooth® Wireless Technology hands-free is described in the manual supplied separately.

# How vehicle radio works FM reception




AM and FM radio signals are broadcast from transmitter towers located around your city. They are intercepted by the radio antenna on your vehicle. This signal is then received by the radio and sent to your vehicle speakers.

When a strong radio signal has reached your vehicle, the precise engineering of your audio system ensures the best possible quality reproduction. However, in some cases the signal coming to your vehicle may not be strong and clear.


This can be due to factors, such as the distance from the radio station, closeness of other strong radio stations or the presence of buildings, bridges or other large obstructions in the area.

### AM (MW, LW) reception



AM broadcasts can be received at greater distances than FM broadcasts. This is because AM radio waves are transmitted at low frequencies. These long, low frequency radio waves can follow the curvature of the earth rather than travelling straight out into the atmosphere. In addition, they curve around obstructions so that they can provide better signal coverage.


### FM radio station



FM broadcasts are transmitted at high frequencies and do not bend to follow the earth's surface. Because of this, FM broadcasts generally begin to fade at short distances from the station. Also, FM signals are easily affected by buildings, mountains, or other obstructions. These can result in certain listening conditions which might lead you to believe a problem exists with your radio. The following conditions are normal and do not indicate radio trouble:



- Fading As your vehicle moves away from the radio station, the signal will weaken and sound will begin to fade. When this occurs, we suggest that you select another stronger station.
- Flutter/Static Weak FM signals or large obstructions between the transmitter and your radio can disturb the signal causing static or fluttering noises to occur. Reducing the treble level may lessen this effect until the disturbance clears.



- Station Swapping As a FM signal weakens, another more powerful signal near the same frequency may begin to play. This is because your radio is designed to lock onto the clearest signal. If this occurs, select another station with a stronger signal.
- Multi-Path Cancellation Radio signals being received from several directions can cause distortion or fluttering. This can be caused by a direct and reflected signal from the same station, or by signals from two stations with close frequencies. If this occurs, select another station until the condition has passed.

### Using a mobile phone or a twoway radio

When a mobile phone is used inside the vehicle, noise may be produced from the audio system. This does not mean that something is wrong with the audio equipment. In such a case, use the mobile phone at a place as far as possible from the audio equipment.

## NOTICE

When using a communication system such as a mobile phone or a radio set inside the vehicle, a separate external antenna must be fitted. When a mobile phone or a radio set is used with an internal antenna alone, it may interfere with the vehicle's electrical system and adversely affect safe operation of the vehicle.



Do not use a mobile phone whilst driving. Stop at a safe location to use a mobile phone.

## **AUDIO (WITHOUT TOUCH SCREEN)**

## System layout - control panel



### (1) RADIO button

- Press to display the radio mode selection window.
- When the mode selection window displays, turn the [TUNE] knob to select the desired mode and then press the knob.
- When the Mode popup is not selected in [MENU/CLOCK] ► Mode popup, press the [RADIO] button on the control panel to change the mode. Each time you press the [RADIO] button on the control panel, the mode switches to radio FM ► AM in order.

### (2) MEDIA button

 Play content from a media storage device.

### (3) FAV button

 Whilst listening to the radio, press to move to next page of the preset list.

### (4) POWER button/VOL knob

- Press to turn the system on or off.
- Turn to the left or right to adjust the system sound volume.

### (5) SEEK/TRACK button

- Change the station/track/file.
- Whilst listening to the radio, press and hold to search for a station.
- Whilst playing media, press and hold to rewind or fast forward.

<sup>\*</sup> The system's actual appearance and layout may differ depending on the vehicle model and specification.



### (6) MENU button/CLOCK button

- Press to access the menu screen for the current mode.
- Press and hold to access the time setup screen.

# (7) TUNE knob/FILE knob/ENTER button

- Whilst listening to the radio, turn to adjust the frequency.
- Whilst playing media, turn to search for a track/file.
- Whilst searching by turning the knob, press to select the current track/file.

### (8) Number buttons (1 RPT~ 4 BACK)

- Whilst listening to the radio, press to listen to a saved radio station.
- Whilst listening to the radio, press and hold to save the current radio station to the preset.
- In the USB mode, press the [1 RPT] button to change the repeat play mode. Press the [2 SHFL] button to change the shuffle play mode.
- Press the [4 BACK] button to return to the previous screen (except for the radio preset list).

\* The system's actual appearance and layout may differ depending on the vehicle model and specification.



(With Bluetooth® Wireless Technology)

### (1) AUDIO button

- Press to display the radio/media mode selection window.
- When the mode selection window displays, turn the [TUNE] knob to select the desired mode and then press the knob.
- When the Mode popup is not selected in [MENU/CLOCK] ► Mode popup, press the [AUDIO] button on the control panel to change the mode. Each time you press the [AUDIO] button on the control panel, the mode switches to radio ► media in order.

### (2) PHONE button

- Press to start connecting a mobile phone via Bluetooth.
- After a Bluetooth phone connection is made, press to access the Bluetooth phone menu.

### (3) FAV button

 Whilst listening to the radio, press to move to next page of the preset list.

### (4) POWER button/VOL knob

- · Press to turn the system on or off.
- Turn to the left or right to adjust the system sound volume.

### (5) SEEK/TRACK button

- Change the station/track/file.
- Whilst listening to the radio, press and hold to search for a station.
- Whilst playing media, press and hold to rewind or fast forward (except for the Bluetooth audio mode).

\* The system's actual appearance and layout may differ depending on the vehicle model and specification.



#### (With Bluetooth® Wireless Technology)

### (6) MENU button/CLOCK button

- Press to access the menu screen for the current mode.
- Press and hold to access the time setup screen.

# (7) TUNE knob/FILE knob/ENTER button

- Whilst listening to the radio, turn to adjust the frequency.
- Whilst playing media, turn to search for a track/file (except for the Bluetooth audio mode).
- Whilst searching by turning the knob, press to select the current track/file (except for the Bluetooth audio mode).

### (8) Number buttons (1 RPT~ 4 BACK)

- Whilst listening to the radio, press to listen to a saved radio station.
- Whilst listening to the radio, press and hold to save the current radio station to the preset.
- In the USB/Bluetooth audio modes, press the [1 RPT] button to change the repeat play mode. Press the [2 SHFL] button to change the shuffle play mode.
- Press the [4 BACK] button to return to the previous screen (except for the radio preset list).

<sup>\*</sup> The system's actual appearance and layout may differ depending on the vehicle model and specification.

# System layout – steering wheel remote control





(Bluetooth® equipped model)

\* The system's actual appearance and layout may differ depending on the vehicle model and specification.

### (1) MODE button

- Press to switch between radio and media modes.
- Press and hold to turn the system on or off.

### (2) Volume lever

Push up or down to adjust the volume.

### (3) Up/Down lever

- Change the station/track/file.
- Whilst listening to the radio, push to listen to the previous/next saved radio station
- Whilst listening to the radio, push and hold to search for a station.
- Whilst playing media, push and hold to rewind or fast forward (except for the Bluetooth audio\* mode).
- \*: if equipped

### (4) MUTE button

- Press to mute or unmute the system.
- During a call, press to mute or unmute the microphone.
- Whilst playing media, press to pause or resume playback. (if equipped)

### (5) Call/Answer button (if equipped)

- Press to start connecting a mobile phone via Bluetooth.
- After a Bluetooth phone connection is made, press to access your call history. Press and hold to dial the most recent phone number. When a call comes in, press to answer the call.
- During a call, press to switch between the active call and the held call. Press and hold to switch the call between the system and the mobile phone.

### (6) Call end button (if equipped)

# MARNING - About driving

- Do not operate the system whilst driving. Driving whilst distracted may result in a loss of vehicle control, potentially leading to an accident, severe personal injury, or death. The driver's primary responsibility is the safe and legal operation of a vehicle, and any handheld devices, equipment, or vehicle systems which divert the driver's attention from this responsibility should never be used during operation of the vehicle.
- Avoid watching the screen whilst driving. Driving whilst distracted may lead to a traffic accident. Stop your vehicle in a safe location before using functions that require multiple operations.
- Stop your vehicle first before using your mobile phone. Using a mobile phone whilst driving may lead to a traffic accident. If necessary, use the Bluetooth Handsfree feature to make calls and keep the call as short as possible.
- Keep the volume low enough to hear external sounds. Driving without the ability to hear external sounds may lead to a traffic accident. Listening to a loud volume for a long time may cause hearing damage.

# **⚠** WARNING

- About handling the system
- Do not disassemble or modify the system. Doing so may result in an accident, fire, or electric shock.
- Do not allow liquids or foreign substances to enter the system. Liquids or foreign substances may cause noxious fumes, a fire, or a system malfunction.
- Stop using the system if it malfunctions, such as no audio output or display. If you continue using the system when it is malfunctioning, it may lead to a fire, electric shock, or system failure.
- Do not touch the antenna during thunder or lightning because such an act may cause electric shock.

## NOTICE

Manufacturer: HYUNDAI MOBIS Co., Ltd.

203, Teheran-ro, Gangnam-gu, Seoul, 06141 , Korea Tel: +82-31-260-2707

# *i* Information

## - About operating the system

- Use the system with the engine running. Using the system for a long time when the engine is stopped may discharge the battery.
- Do not install unapproved products.
   Using unapproved products may cause an error whilst using the system. System errors caused by installing unapproved products are not covered under the warranty.

# i Information

## - About handling the system

- Do not apply excessive force to the system. Excessive pressure on the screen may damage the LCD panel or the touch panel.
- When cleaning the screen or button panel, make sure to stop the engine and use a soft, dry cloth. Wiping the screen or buttons with a rough cloth or using solvents (alcohol, benzene, paint thinner, etc.) may scratch or chemically damage the surface.
- If you attach a liquid-type air freshener to the fan louvre, the surface of the louvre may become deformed due to the flowing air.
- If you want to change the position of the installed device, please inquire with your place of purchase or service maintenance centre. Technical expertise is required to install or disassemble the device.

## NOTICE

- If you experience any problems with the system, contact your place of purchase or dealer.
- Placing the infotainment system within an electromagnetic environment may result in noise interference.

### Turning the system on or off

To turn on the system, start the engine.

- If you do not want to use the system whilst driving, you can turn off the system by pressing the [POWER] button on the control panel. To use the system again, press the [POWER] button again. After you have turned off the engine, the system will automatically turn off after a whilst or as soon as you open the driver's door.
- Depending on the vehicle model or specifications, the system may turn off as soon as you turn off the engine.
- When you turn back on the system, the previous mode and settings will remain intact.

# **MARNING**

- Some functions may be disabled for safety reasons whilst the vehicle is moving. They work only when the vehicle stops. Park your vehicle in a safe location before using any of them.
- Stop using the system if it malfunctions, such as no audio output or display. If you continue using the system when it is malfunctioning, it may lead to a fire, electric shock, or system failure.

# Information

You can turn on the system when the key ignition switch is placed in the "ACC" or "ON" position. Using the system for an extended period without the engine running drains the battery. If you plan on using the system for a long time, start the engine.

## Turning the display on or off

To prevent glare, you can turn off the screen. The screen can be turned off only whilst the system is on.

- 1. On the control panel, press the [MENU/CLOCK] button.
- When the option selection window displays, turn the [TUNE] knob to select Display off, and then press the knob.
  - To turn the screen back on, press any of the control panel buttons.

# Getting to know the basic operations

You can select an item or adjust the settings by using the number buttons and the [TUNE] knob on the control panel.

### Selecting an item

### **Numbered items**

Press the corresponding number button.



#### Numberless items


Turn the **[TUNE]** knob to select the desired item, and then press the knob.



### Adjusting the settings

Turn the [**TUNE**] knob to adjust the value, and then press the knob to save changes.

Turn the [TUNE] knob to the right to increase the value and turn the [TUNE] knob to the left to decrease the value.



### **RADIO**

### Turning on the radio

- 1. On the control panel, press the [RADIO] / [AUDIO] button.
- When the mode selection window displays, turn the [TUNE] knob to select the desired radio mode and then press the knob.

### FM/AM Mode



- (1) Current radio mode
- (2) Radio station information
- (3) Preset list


Press the [MENU/CLOCK] button on the control panel to access the following menu options:

- Autostore: Save radio stations to the preset list.
- Scan: The system searches for radio stations with strong radio signals and plays each radio station for about five seconds.
- Sound settings: You can change the settings related to sounds, such as location where sound will be concentrated and the output level for each range.
  - Position: Select a location where sound will be concentrated in the vehicle. Select Fade (Fader) or Balance, turn the [TUNE] knob to select the desired position, and then press the knob. To set sound to be centred in the vehicle, select Centre (Center).

- **Equaliser** (**Tone**): Adjust the output level for each sound tone mode.
- Speed dependent vol.: Set the volume to be adjusted automatically according to your driving speed. (if equipped)

- Depending on vehicle models or specifications, available options may vary.
- Depending on the system or amplifier specifications applied to your vehicle, available options may vary.
- Mode popup: Set to display mode selection window when the [RADIO] / [AUDIO] button is pressed on the control panel.
- Date/Time: You can change the date and time that are shown on the system display.
  - Set date: Set date to display on the system display.
  - Set time: Set time to display on the system display.
  - Time format: Select to display time in the 12 hour format or the 24 hour format.
  - Display (Power Off): Set to display the clock when the system power is off.
- Language: You can change the display language.

### FM/AM Mode (With RDS)



- (1) Current radio mode
- (2) Radio station information
- (3) Preset list


Press the [MENU/CLOCK] button on the control panel to access the following menu options:

- Traffic announcement: Activate or deactivate traffic announcements. Announcements and programmes will be received automatically if available.
- Autostore: Save radio stations to the preset list.
- Scan: The system searches for radio stations with strong radio signals and plays each option for about five seconds.
- Sound settings: You can change the settings related to sounds, such as location where sound will be concentrated and the output level for each range.
  - Position: Select a location where sound will be concentrated in the vehicle. Select Fade (Fader) or Balance, turn the [TUNE] knob to select the desired position, and then press the knob. To set sound to be centred in the vehicle, select Centre (Center).

- **Equaliser** (**Tone**): Adjust the output level for each sound tone mode.
- Speed dependent vol.: Set the volume to be adjusted automatically according to your driving speed. (if equipped)

- Depending on vehicle models or specifications, available options may vary.
- Depending on the system or amplifier specifications applied to your vehicle, available options may vary.
- Mode popup: Set to display mode selection window when the [RADIO] / [AUDIO] button is pressed on the control panel.
- Date/Time: You can change the date and time that are shown on the system display.
  - **Set date**: Set date to display on the system display.
  - **Set time**: Set time to display on the system display.
  - Time format: Select to display time in the 12 hour format or the 24 hour format.
  - Display (Power Off): Set to display the clock when the system power is off.
- Language: You can change the display language.

#### **DAB Mode**



- (1) Current radio mode
- (2) Radio station information
- (3) Preset list

Press the [MENU/CLOCK] button on the control panel to access the following menu options:

- Traffic announcement: Activate or deactivate traffic announcements. Announcements and programmes will be received automatically if available.
- List: Display all available radio stations.
- Scan: The system searches for radio stations with strong radio signals and plays each option for about five seconds.
- Sound settings: You can change the settings related to sounds, such as location where sound will be concentrated and the output level for each range.
  - Position: Select a location where sound will be concentrated in the vehicle. Select Fade (Fader) or Balance, turn the [TUNE] knob to select the desired position, and then press the knob. To set sound to be centred in the vehicle, select Centre (Center).

- **Equaliser** (**Tone**): Adjust the output level for each sound tone mode.
- Speed dependent vol.: Set the volume to be adjusted automatically according to your driving speed. (if equipped)

- Depending on vehicle models or specifications, available options may vary.
- Depending on the system or amplifier specifications applied to your vehicle, available options may vary.
- Mode popup: Set to display mode selection window when the [AUDIO] button is pressed on the control panel.
- Date/Time: You can change the date and time that are shown on the system display.
  - Set date: Set date to display on the system display.
  - **Set time**: Set time to display on the system display.
  - Time format: Select to display time in the 12 hour format or the 24 hour format.
  - Display (Power Off): Set to display the clock when the system power is off.
- Language: You can change the display language.

## Changing the radio mode

- On the control panel, press the [RADIO] / [AUDIO] button.
- When the mode selection window displays, turn the [TUNE] knob to select the desired radio mode and then press the knob.
  - Each time you press the [MODE] button on the steering wheel, the radio mode switches to FM ► AM in order.

### NOTICE

When the Mode popup is not selected in [MENU/CLOCK] ▶ Mode popup, press the [RADIO] / [AUDIO] button on the control panel to change the radio mode.

Each time you press the [RADIO] / [AUDIO] button on the control panel, the radio mode switches to FM ▶ DAB (if equipped) ▶ AM in order.

# Scanning for available radio stations

You can listen to each radio station for a few seconds to test the reception and select the one you want.

- From the radio screen, press the [MENU/CLOCK] button on the control panel.
- When the option selection window displays, turn the [TUNE] knob to select Scan, and then press the knob.
  - The system searches for radio stations with strong radio signals and plays each radio station for about five seconds.
- When you find the radio station you want to listen to, press the [TUNE] knob.
  - You can continue listening to the selected station.

## Searching for radio stations

To search for the previous or next available radio station, press the [< SEEK] button / [TRACK >] button on the control panel.

 You can also press and hold the [< SEEK] button / [TRACK >] button to search for frequencies quickly. When you release the button, a radio station with a strong signal is selected automatically.

If you know the exact frequency of the radio station you want to listen to, turn the [TUNE] knob on the control panel to change the frequency.

### Saving radio stations

You can save your favorite radio stations and listen to them by selecting them from the preset list.

### Saving the current radio station

Whilst listening to the radio, press and hold the desired number button on the control panel.

- The radio station you are listening to will be added to the selected number.
- To save the next page of the preset list, press the [FAV] button.

### NOTICE

- You can save up to 12 radio stations in each mode.
- If a station is already saved to the selected preset number, the station will be replaced by the station you are listening to.

### Using the auto save function

You can search for radio stations in your area where there is a strong signal. The results of your search can be saved to the preset list automatically.

- From the radio screen, press the [MENU/CLOCK] button on the control panel.
- When the option selection window displays, turn the [TUNE] knob to select Autostore, and then press the knob.

# Listening to saved radio stations

#### FM/AM Mode

- Confirm the preset number for the radio station you want to listen to.
  - To view the next page of the preset list, press the [FAV] button.
- On the control panel, press the desired number button.
  - Alternatively, Push the Up/Down lever on the steering wheel to change the station.

### **MEDIA PLAYER**

## Using the media player

You can play music stored in various media storage devices, such as USB storage devices, smartphones.

- 1. Connect a device to the USB port in your vehicle.
  - Playback may start immediately depending on the device that you connect to the system.
- 2. On the control panel, press the [MEDIA] / [AUDIO] button.
- When the mode selection window displays, turn the [TUNE] knob to select the desired mode and then press the knob.

### NOTICE

- To start the media player, press the [MEDIA] / [AUDIO] button on the control panel.
- You can also change the mode by press the [MODE] button repeatedly on the steering wheel.
- Make sure to connect or disconnect external USB devices with the system power turned off.
- When the Mode popup is not selected in [MENU/CLOCK] ► Mode popup, press the [AUDIO] button on the control panel to change the media player.
  - Each time you press the [AUDIO] button on the control panel, the media mode switches to USB ▶ Bluetooth audio\* in order.
- Depending on vehicle models and specifications, available buttons or the appearance and layout of the USB port in your vehicle may vary.

- Do not connect a smartphone or an MP3 device to the system via multiple methods such as USB and Bluetooth simultaneously. Doing so may cause a distorted noise or a system malfunction.
- When the equaliser function of the connected device and Tone settings of the system are both activated, the effects may interfere with each other and may lead to sound degradation or distortion. Deactivate the device's equaliser function if possible.
- \*: if equipped

## Using the USB mode

You can play media files stored in portable devices, such as USB storage devices and MP3 players. Check compatible USB storage devices and file specifications before using the USB mode.

Connect your USB device to the USB port in the vehicle.

- · Playback starts immediately.
- Press the [MEDIA] / [AUDIO] button on the control panel to display the mode selection window, turn the [TUNE] knob to select USB and then press the knob.



- Current file number and total number of files
- (2) Playback time
- (3) Information about the song currently playing

Press the [MENU/CLOCK] button on the control panel to access the following menu options:

- · List: Access the file list.
- · Folder list: Access the folder list.
- **Information**: Display information about the song currently playing.
- Sound settings: You can change the settings related to sounds, such as location where sound will be concentrated and the output level for each range.
  - Position: Select a location where sound will be concentrated in the vehicle. Select Fade (Fader) or Balance, turn the [TUNE] knob to select the desired position, and then press the knob. To set sound to be centred in the vehicle, select Centre (Center).
  - **Equaliser** (**Tone**): Adjust the output level for each sound tone mode.
  - Speed dependent vol.: Set the volume to be adjusted automatically according to your driving speed. (if equipped)

### NOTICE

- Depending on vehicle models or specifications, available options may vary.
- Depending on the system or amplifier specifications applied to your vehicle, available options may vary.
- Song information (Media Display): Select information such as Folder/ File or Artist/Title/Album to display when playing MP3 files.
- Mode popup: Set to display mode selection window when the [MEDIA] / [AUDIO] button is pressed on the control panel.
- Date/Time: You can change the date and time that are shown on the system display.
  - **Set date**: Set date to display on the system display.
  - Set time: Set time to display on the system display.
  - Time format: Select to display time in the 12 hour format or the 24 hour format.
  - Display (Power Off): Set to display the clock when the system power is off.
- Language: You can change the display language.

## Rewinding/Fast forwarding

On the control panel, press and hold the [< SEEK] button / [TRACK >] button.

 You can also push and hold the Up/ down lever on the steering wheel.

### Restarting the current playback

On the control panel after the song has played for 2 seconds, press the [< SEEK] button.

• You can also push the Up lever on the steering wheel.

# Playing the previous or next song

To play the previous song on the control panel within the first 2 seconds of the current song, press the [< SEEK] button. To play the next song, press the [TRACK >] button on the control panel.

- If more than 2 seconds of playback have elapsed, press the [< SEEK] button on the control panel twice to play the previous song.
- You can also push the Up/down lever on the steering wheel.

### NOTICE

Press the [MENU] button on the control panel to display the mode selection window, turn the [TUNE] knob to find the desired song and press the knob to play the file.

## Playing repeatedly

On the control panel, press the [1 RPT] button. The repeat play mode changes each time you press it. The corresponding mode icon will be displayed on the screen.

## Playing in random order

On the control panel, press the [2 SHFL] button. The shuffle play mode is activated or deactivated each time you press it. When you activate the shuffle mode, the corresponding mode icon will be displayed on the screen.

### NOTICE

Depending on the connected Bluetooth device or mobile phone, RPT & SHFL features may not be supported.

### Searching folders

- 1. On the control panel, press the [MENU/CLOCK] button.
- When the option selection window displays, turn the [TUNE] knob to select the Folder list and then press the knob.
- Navigate to the desired folder in the Folder list and then press the [TUNE] knob.
  - The first song in the selected folder will be played.

# *i* Information

- Start the engine of your vehicle before connecting a USB device to your system. Starting the engine with a USB device connected to the system may damage the USB device.
- Be careful of static electricity when connecting or disconnecting a USB device. A static discharge may cause a system malfunction.
- Be careful not to let your body or external objects contact the USB port. Doing so may cause an accident or a system malfunction.
- Do not connect and disconnect a USB connector repeatedly in a short time. Doing so may cause an error in the device or a system malfunction.
- Do not use a USB device for purposes other than playing files. Using USB accessories for charging or heating may cause poor performance or a system malfunction.

### NOTICE

- When connecting a USB storage device, do not use an extension cable. Connect it directly to the USB port. If you use a USB hub or an extension cable, the device may not be recognised.
- Fully insert a USB connector into the USB port. Failure to do so may cause a communication error.
- When you disconnect a USB storage device, a distorted noise may
- · The system can play only files encoded in a standard format.
- The following types of USB devices may not be recognised or work correctly:
  - Encrypted MP3 players
  - USB devices not recognised as removable disks
- · A USB device may not be recognised depending on its condition.
- · Some USB devices may be incompatible with your system.
- · Depending on the USB device's type, capacity, or the format of files, USB recognition time may be longer.
- · Image and video playback are not supported.

## **BLUETOOTH (IF EQUIPPED)**

### **Connecting Bluetooth devices**

Bluetooth is a short-range wireless networking technology. Via Bluetooth, you can connect nearby mobile devices wirelessly to send and receive data between connected devices. This enables you to use your devices effectively. To use Bluetooth, you must first connect a Bluetooth-enabled device to your system, such as a mobile phone or an MP3 player. Ensure that the device you want to connect supports Bluetooth.



# ! WARNING

Park your vehicle in a safe location before connecting Bluetooth devices. Distracted driving can cause a traffic accident and lead to personal injury or death.

- On your system, you can use only Bluetooth Handsfree and Audio features. Connect a mobile device that supports both features.
- Some Bluetooth devices may cause malfunctions to the infotainment system or make interference noises. In this case, storing the device in a different location may resolve the problem.
- · Depending on the connected Bluetooth device or mobile phone. some functions may not be supported.
- · If the system is not stable due to a vehicle-Bluetooth device communication error, delete the paired devices and connect the Bluetooth devices again.


- If Bluetooth connection is not stable, follow these steps to try again.
  - Deactivate Bluetooth and reactivate it on the device. Then, reconnect the device.
  - 2. Turn the device off and on. Then, reconnect it.
  - Remove the battery from the device and reinstall it. Then, turn the device on and reconnect it.
  - Unregister the Bluetooth pairing on both the system and the device and then re-register and connect them.
- The Bluetooth connection is unavailable when the device's Bluetooth function is turned off. Be sure to turn on the device's Bluetooth function.

### Pairing devices with your system

For Bluetooth connections, first pair your device with your system to add it to the system's list of Bluetooth devices. You can register up to five devices.

- From the control panel, press the [PHONE] button, and then select Phone settings ► Add new device
  - If you are pairing a device with your system for the first time, you can also press the Call/Answer button on the steering wheel.

- On the Bluetooth device you want to connect, activate Bluetooth, search for your vehicle's system, and then select it.
  - Check the system's Bluetooth name, which is displayed in the new registration pop-up window on the system screen.



- Enter or confirm the passkey to confirm the connection.
  - If the passkey input screen is displayed on the Bluetooth device screen, enter the passkey '0000' which is displayed on the system screen.
  - If the 6-digit passkey is displayed on the Bluetooth device screen, ensure that the Bluetooth passkey displayed on the Bluetooth device is the same as the passkey on the system screen and confirm the connection from the device.

- The screen image in this manual is an example. Check your system screen for the exact vehicle name and Bluetooth device name.
- The default passkey is '0000'.
- It may take a whilst for the system to connect with the device after you permit the system to access the device. When a connection is made, the Bluetooth status icon appears at the top of the screen.

- You can change the permission settings via the mobile phone's Bluetooth settings menu. For more information, refer to your mobile phone's user guide.
- To register a new device, repeat steps 1 to 3.
- If you use the automatic Bluetooth connection function, a call may be switched to the vehicle's Handsfree when you are taking on the phone near the vehicle whilst the vehicle's engine is on. If you do not want the system to connect with the device automatically, deactivate Bluetooth on your device.
- When a device is connected to the system via Bluetooth, the device's battery may discharge faster.

### Connecting a paired device

To use a Bluetooth device on your system, connect the paired device to the system. Your system can connect with only one device at a time.

- From the control panel, press the [PHONE] button, and then select Phone settings ► Paired devices.
  - If there is no connected device, press the Call/Answer button on the steering wheel.
- Turn the [TUNE] knob to select the device to connect, and then press the knob.
  - If another device is already connected to your system, disconnect it. Select the connected device to disconnect.

### NOTICE

- If a connection ends because a device is out of the connection range or a device error occurs, the connection will be restored automatically when the device enters the connection range or when the error is cleared.
- Depending on auto connection priority, connection to a device may take time.

### Disconnecting a device

If you want to stop using a Bluetooth device or connect another device, disconnect your currently connected device.

- From the control panel, press the [PHONE] button, and then select Phone settings ► Paired devices.
- Turn the [TUNE] knob to select your currently connected device and then press the knob.
- Press the [1 RPT] button to select Yes.

## Deleting paired devices

If you no longer want a Bluetooth device paired or if you want to connect a new device when the Bluetooth device list is full, delete paired devices.

- From the control panel, press the [PHONE] button, and then select Phone settings ▶ Delete devices.
- Turn the [TUNE] knob to select the device to delete, and then press the knob.
- 3. Press the [1 RPT] button to select Yes.

### NOTICE

- When you delete a paired device, the Call history and Contacts stored in the system are also deleted.
- To re-use a deleted device, you must pair the device again.

## Using a Bluetooth audio device

You can listen to music stored in the connected Bluetooth audio device via your vehicle's speakers.

- 1. On the control panel, press the [AUDIO] button.
- When the mode selection window displays, turn the [TUNE] knob to select Bluetooth audio and then press the knob.



- Information about the song currently playing
- Press the [MENU/CLOCK] button on the control panel to access the following a menu option.
- 2. Turn the **[TUNE]** knob to select option and then press the knob.

- Sound settings: You can change the settings related to sounds, such as location where sound will be concentrated and the output level for each range.
  - Position: Select a location where sound will be concentrated in the vehicle. Select Fade (Fader) or Balance, turn the [TUNE] knob to select the desired position, and then press the knob. To set sound to be centred in the vehicle, select Centre (Center).
  - Equaliser (Tone): Adjust the output level for each sound tone mode.
  - Speed dependent vol.: Set the volume to be adjusted automatically according to your driving speed.

- Depending on vehicle models or specifications, available options may vary.
- Depending on the system or amplifier specifications applied to your vehicle, available options may vary.
  - Mode popup: Set to display mode selection window when the [AUDIO] button is pressed on the control panel.
  - Date/Time: You can change the date and time that are shown on the system display.
    - **Set date**: Set date to display on the system display.
    - **Set time**: Set time to display on the system display.

- Time format: Select to display time in the 12 hour format or the 24 hour format.
- **Display** (**Power Off**): Set to display the clock when the system power is off.
  - Language: You can change the display language.

### Pausing/Resuming playback

To pause playback, press the [TUNE] knob on the control panel. To resume playback, press the [TUNE] knob again.

 You can also press the Mute button on the steering wheel remote control.

### Playing repeatedly

On the control panel, press the [1 RPT] button. The repeat play mode changes each time you press it. The corresponding mode icon will be displayed on the screen.

## Playing in random order

On the control panel, press the [2 SHFL] button. The shuffle play mode is activated or deactivated each time you press it. When you activate the shuffle mode, the corresponding mode icon will be displayed on the screen.

## NOTICE

Depending on the connected Bluetooth device or mobile phone, RPT & SHFL features may not be supported.

- Depending on the connected Bluetooth device, mobile phone, or the music player you are using, playback controls may differ.
- Depending on the music player you are using, streaming may not be supported.
- Depending on the connected Bluetooth device or mobile phone, some functions may not be supported.
- If a Bluetooth enabled phone is being used to play music and it receives or makes a phone call, the music will stop.
- Receiving an incoming call or making an outgoing call whilst playing Bluetooth audio may result in audio interference.
- If you use the Bluetooth phone mode whilst using Bluetooth audio, playback may not automatically resume after you end the call depending on the connected mobile phone.
- Moving the track up/down whilst playing Bluetooth audio mode may result in pop noises with some mobile phones.
- The Rewinding/Fast forwarding function is not supported in the Bluetooth audio mode.
- The playlist feature is not supported in the Bluetooth audio mode.
- If the Bluetooth device is disconnected, Bluetooth audio mode will end.

## **Using a Bluetooth phone**

You can use Bluetooth to talk on the phone hands free. View call information on the system screen, and make or receive calls safely and conveniently via the vehicle's built-in microphone and speakers.

# **⚠** WARNING

- Park your vehicle in a safe location before connecting Bluetooth devices. Distracted driving can cause a traffic accident and lead to personal injury or death.
- Never dial a phone number or pick up your mobile phone whilst driving. Use of a mobile phone may distract your attention, making it difficult to recognise external conditions and reducing the ability to cope with unexpected situations, which may lead to an accident. If necessary, use the Bluetooth Handsfree feature to make calls and keep the call as short as possible.

- You cannot access the Phone screen if there is no connected mobile phone. To use the Bluetooth phone function, connect a mobile phone to the system.
- The Bluetooth Handsfree function may not work when you are passing out of the mobile service coverage area, such as when you are in a tunnel, underground, or in a mountainous area.
- Call quality may be degraded in the following environments:
  - The reception of the mobile phone is poor
  - The inside of the vehicle is noisy
  - The mobile phone is placed near metallic objects, such as a beverage can.
- Depending on the connected mobile phone, the volume and sound quality of the Bluetooth Handsfree may vary.

### Making a call

If your mobile phone is connected to the system, you can make a call by selecting a name from your call history or contacts list.

- 1. On the control panel, press the [PHONE] button.
  - Alternatively, press the Call/ Answer button on the steering wheel.
- 2. Select a phone number.
  - To select a phone number from your favourites list, select Favourites.
  - To select a phone number from your call history, select Call historv.
  - To select a phone number from the contacts list downloaded from the connected mobile phone, select Contacts.
- 3. To end the call, press the [2 SHFL] button on the control panel.
  - Alternatively, press the Call end button on the steering wheel.


### Registering the favourites list

You can more easily use Bluetooth to talk on the phone hands-free by registering phone numbers as your favourites.

- On the Phone screen, turn the [TUNE] knob on the control panel to select Favourites and press the knob.
- Select [MENU/CLOCK] ► Add new favourites.
- 3. Press the [1 RPT] button, and select the desired phone number.

### Using the favourites list

- From the Phone screen, turn the [TUNE] knob on the control panel to select Favourites, and then press the knob.
- 2. Turn the [TUNE] knob to select the desired contact, and then press the knob to make a phone call.



Press the [MENU/CLOCK] button on the control panel to access the following menu options:

- Add new favourites: Add a frequently used phone number to favourites.
- Delete items: Delete a selected favourites item.
- Delete all: Delete all favourites items.


- You can register up to 20 favourites for each device.
- You must first download the contacts to the system to register favourites.
- The favourites list saved on the mobile phone is not downloaded to the system.

- Even if the contact information on the mobile phone is edited, the favourites on the system are not automatically edited. Delete and add the item to favourites again.
- When you connect a new mobile phone, your favourites set for the previous mobile phone will not be displayed, but they will remain in your system until you delete the previous phone from the device list.

### Using your call history

- From the Phone screen, turn the [TUNE] knob on the control panel to select Call history, and then press the knob.
- Turn the [TUNE] knob to select the desired entry, and then press the knob to make a phone call.

Press the [MENU/CLOCK] button on the control panel to access the follow-



#### ing menu options:


- Download: Download your call history.
- · All calls: View all call records.
- Dialled calls: View only dialed calls.
- Received calls: View only received calls.
- Missed calls: View only missed calls.

### NOTICE

- Some mobile phones may not support the download function.
- The call history is accessed only after downloading the call history when the mobile phone is connected to the system.
- Calls from restricted IDs are not saved on the call history list.
- Up to 50 call records will be downloaded per individual list.
- Call duration and time information will not be displayed on the system screen.
- Permission is required to download your call history from the mobile phone. When you attempt to download data, you may need to permit the download on the mobile phone. If the download fails, check the mobile phone screen for any notification or the mobile phone's permission setting.
- When you download your call history, any old data will be deleted.

## Using the contacts list

- From the Phone screen, turn the [TUNE] knob on the control panel to select Contacts, and then press the knob.
- 2. Turn the [TUNE] knob to select the desired group of alphanumeric characters, and then press the knob.
- 3. Turn the [TUNE] knob to select the desired contact, and then press the knob to make a phone call.



Press the [MENU/CLOCK] button on the control panel to access the following a menu option:

• **Download**: Download your mobile phone contacts.


#### NOTICE

- Contacts can be viewed only when the Bluetooth device is connected.
- Only contacts in the supported format can be downloaded and displayed from the Bluetooth device. Contacts from some applications will not be included.
- Up to 2,000 contacts can be downloaded from your device.
- Some mobile phones may not support the download function.
- Depending on the system's specifications, some of the downloaded contacts may be lost.
- Contacts stored both in the phone and in the SIM card are downloaded.
   With some mobile phones, contacts in the SIM card may not be downloaded.
- Special characters and figures used in the contact name may not be displayed properly.

- Permission is required to download contacts from the mobile phone.
   When you attempt to download data, you may need to permit the download on the mobile phone. If the download fails, check the mobile phone screen for any notification or the mobile phone's permission setting.
- Depending on the mobile phone type or status, downloading may take longer.
- When you download your contacts, any old data will be deleted.
- You cannot edit or delete your contacts on the system.
- When you connect a new mobile phone, your contacts downloaded from the previous mobile phone will not be displayed, but they will remain in your system until you delete the previous phone from the device list.

### Answering calls

When a call comes in, a notification pop-up window of the incoming call appears on the system screen.



To answer the call, press the [1 RPT] button on the control panel.

 Alternatively, press the Call/Answer button on the steering wheel. To reject the call, press the [2 SHFL] button on the control panel.


 Alternatively, press the Call end button on the steering wheel.

#### NOTICE

- Depending on the mobile phone type, call rejection may not be supported.
- Once your mobile phone is connected to the system, the call sound may be output through the vehicle's speakers even after you exit the vehicle if the phone is within the connection range. To end the connection, disconnect the device from the system or deactivate Bluetooth on the device.

### Using options during a call

During a call, you will see the call screen shown below. Press a button to perform the function you want.



To switch the call to your mobile phone, press the [1 RPT] button on the control panel.

 Alternatively, press and hold the Call/ Answer button on the steering wheel. To end the call, press the [2 SHFL] button on the control panel.

- Alternatively, press the Call end button on the steering wheel.
- Press the [MENU/CLOCK] button on the control panel to access the following a menu option:
- Microphone Volume (Outgoing Volume): Adjust the microphone volume or turn off the microphone so the other party cannot hear you.

- If the caller information is saved in your contacts list, the caller's name and phone number will be displayed.
   If the caller information is not saved in your contacts list, only the caller's phone number will be displayed.
- You cannot switch to any other screen, such as the audio screen or the settings screen, during a Bluetooth call.
- Depending on the mobile phone type, call quality may vary. On some phones, your voice may be less audible to the other party.
- Depending on the mobile phone type, the phone number may not be displayed.
- Depending on the mobile phone type, the call switching function may not be supported.

### **PAN-EUROPEAN ECALL (IF EQUIPPED)**

The Pan-European eCall system is an automatic emergency call service made in event of a traffic accident or other accidents on the roads.

#### SOS

Driver or passenger manually can make an emergency call in the single duty dispatch service, by pressing SOS button to call the necessary emergency services.

 Stops sound and SOS is displayed on screen.

#### **SOS Test**

You can start the Pan-European eCall test mode by pressing the SOS Test button


 Stops sound and SOS TEST is displayed on screen.

- For more information, refer to the "Pan-European eCall System" in manual
- Depending on your region, the service may not be supported.
- Depending on your region or vehicle model, the name of the button may vary.

#### SYSTEM STATUS ICONS

Status icons appear at the top of the screen to display the current system status.

Familiarise yourself with the status icons that appear when you perform certain actions or functions and their meanings.



#### Bluetooth

Icon	Description
	Battery level of connected Bluetooth device
$\Re$	Mobile phone or audio device connected via Bluetooth
C	Bluetooth call in progress
	Microphone turned off during Bluetooth call
¢+	Downloading call history from a mobile phone connected via Bluetooth to the system
<b>↓</b> 目	Downloading contacts from a mobile phone connected via Bluetooth to the system
	Displayed when Bluetooth remote control is connected via smartphone applications

### Signal strength

Icon	Description
Yall	Signal strength of the mobile phone connected via Bluetooth

- The battery level displayed on the screen may differ from the battery level displayed on the connected device.
- The signal strength displayed on the screen may differ from the signal strength displayed on the connected mobile phone.
- Depending on vehicle models and specifications, some status icons may not be displayed.

### **INFOTAINMENT SYSTEM SPECIFICATIONS**

#### **USB**

#### Supported audio formats

- · Audio file specification
  - WAVeform audio format
  - MPEG1/2/2.5 Audio Layer3
  - Windows Media Audio Ver 7.X/8.X
- · Bit rates
  - MPEG1 (Layer3): 32/40/48/56/64/80/96/112/128/ 160/192/224/256/320 kbps
  - MPEG2 (Layer3): 8/16/24/32/40/48/56/64/80/96/ 112/128/144/160 kbps
  - MPEG2.5 (Layer3): 8/16/24/32/40/48/56/64/80/96/ 112/128/144/160 kbps
  - WMA (High Range): 48/64/80/96/128/160/192 kbps
- · Bits Per Sample
  - WAV (PCM(Stereo)): 24 bit
  - WAV (IMA ADPCM): 4 bit
  - WAV (MS ADPCM): 4 bit
- Sampling frequency
  - MPEG1: 44100/48000/32000 Hz
  - MPEG2: 22050/24000/16000 Hz
  - MPEG2.5: 11025/12000/8000 Hz
  - WMA: 32000/44100/48000 Hz
  - WAV: 44100/48000 Hz
- Maximum length of folder/file names (Based on Unicode): 40 English or Korean characters
- Supported characters for folder/file names (Unicode support): 2,604 Korean characters, 94 alphanumeric characters, 4,888 Chinese characters in common use, 986 special characters
- Maximum number of folders: 1,000
  Maximum number of files: 5.000

#### NOTICE

- Files that are not in a supported format may not be recognised or played, or information about them, such as the file name, may not be displayed properly.
- Only files with .mp3/.wma/.wav extensions can be recognised by the system. If the file is not in supported format, change the file format by using the latest encoding software.
- The device will not support files locked by DRM (Digital Rights Management).
- For MP3/WMA compression files and WAV file, differences in sound quality will occur depending on the bitrate. (Music files with a higher bitrate have a better sound quality.)
- Japanese or Simplified Chinese characters in folder or file names may not be displayed properly.

### Supported USB storage devices

- · Byte/Sector: 64 kbyte or less
- Format system: FAT12/16/32 (recommended), exFAT/NTFS

### NOTICE

- Operation is guaranteed only for a metal cover type USB storage device with a plug type connector.
  - USB storage devices with a plastic plug may not be recognised.
  - USB storage devices in memory card types, such as CF card or SD cards, may not be recognised.
- USB hard disk drives may not be recognised.
- When you use a large capacity USB storage device with multiple logical drives, only files stored on the first drive will be recognised.
- If an application program is loaded on a USB storage device, the corresponding media files may not play.
- Use USB 2.0 devices for better compatibility.

#### **Bluetooth**

- Bluetooth Power Class 2: -6 to 4 dBm
- · Aerial power: Max 3 mW
- Frequency range: 2400 to 2483.5 MHz
- Bluetooth patch RAM software version: 1

#### **TRADEMARKS**

Other trademarks and trade names are those of their respective owners.

 The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HYUNDAI is under licence.



### **DECLARATION OF CONFORMITY**

#### **CE RED for EU**

#### HYUDDAI EU Declaration of Conformity... MOBIS Product details (2) Product [3] Car Auido System Basic Model: ACB10HQIG Additional Models ACB11HQIG, ACB12HQIG, ACB13HQIG, ACB10HQGG, ACB10HQGN, ACB10HQGL, Model (4) ACB10HQGP, ACB11HQGG, ACB10HQMG, ACB00GQTP, ACB11GQTP, ACB00GQEG, ACB01GQEG, ACB90GQEG, ACB10GQEG, ACB11GQEG, ACBC0GQEG, ACB00GQEP, ACB90GQEP, ACB10GQEP, ACBC0GQEP, ACB11GQEP, ACBC1GQEP, ACB91GQEP, ACB02GQEP We hereby declare, that the product above is in compliance with the essential requirements of the Directive 2014/53/EU by application of 151 Applied Standards (6) Article |7| 3.2 EN 300 328 V2.1.1. Final Draft EN 303 345 V1.1.7 Radio (8) Article (7) 3.1b Draft EN 301 489-1 V2.2.0, Draft EN 301 489-17 V3.2.0 EN 55032;2015, EN 55035;2017 EMC (9) Article |7| 3.1a EN 60065:2014/A11:2017, EN 62311:2008 Safety (10), Health (11) Manufacturer (12) Representative in the EU [13] HYUNDAI MOBIS Co., Ltd. MOBIS Parts Europe N.V. Wilhelm-Fay-Strabe 51, 203, Teheran-ro, Gangnam-gu, Seoul, 06141, Korea Frankfurt Main, 65936, Germany Tel: +82-31-260-2707 Tel: +49-69-85096-5011 Notified Body [14] 29/03/2019 Signed By (15) TUV SUD BABT / TUV SUD Group This declaration of conformity is issued under the sole responsibility of the manufacturer, [16] Octagon House, Concorde Way, Fareham Hampshire, P015 5RL, United Kingdom Seunghoon Choe Notified Body Identification [17] Representative BABT-RED001341 i01 Hyundai MOBIS Co., Ltd. Reference [18] Additional information[19] HW: Al3.GEN.AUDIO4.0V.001 SW: AI3.GEN.001

# 6. Whilst driving

Before drivingBefore entering the vehicleBefore starting	6-4
Ignition switch Key ignition switch Engine Start/Stop button	6-6
Manual transmission	6-14
Automated Manual Transmission (AMT)	6-18 6-22 6-25 6-28
Braking system  Power brakes  Disc brakes wear indicator  Rear drum brakes  Parking brake  Anti-lock Brake System (ABS)  Electronic Stability Control (ESC)  Vehicle Stability Management (VSM)  Hill-Start Assist Control (HAC)  Emergency Stop Signal (ESS)  Brake Assist System (BAS)  Good braking practices	6-30 6-31 6-31 6-33 6-34 6-39 6-39

ISG (Idle Stop and Go) system 6-2 To activate ISG system 6-2 To deactivate ISG system 6-2 ISG system malfunction 6-2 The battery sensor deactivation 6-4	42 45 45
Special driving conditions	47 48 48 48 48 48
Winter driving	50
Vehicle weight6-5 Overloading6-5	
Trailer towing	57 61 62

## **MARNING**

## Carbon monoxide (CO) gas is toxic. Breathing CO can cause unconsciousness and death.

Engine exhaust contains carbon monoxide which cannot be seen or smelled.

#### Do not inhale engine exhaust.

If at any time you smell engine exhaust inside the vehicle, open the windows immediately. Exposure to CO can cause unconsciousness and death by asphyxiation.

#### Be sure the exhaust system does not leak.

The exhaust system should be checked whenever the vehicle is raised to change the oil or for any other purpose. If you hear a change in the sound of the exhaust or if you drive over something that strikes the underneath side of the vehicle, we recommend that the exhaust system be checked as soon as possible by a HYUNDAI authorised repairer.

#### Do not run the engine in an enclosed area.

Letting the engine idle in your garage, even with the garage door open, is a hazardous practice. Run the engine only long enough to start the engine and to move the vehicle out of the garage.

#### Avoid idling the engine for prolonged periods with people inside the vehicle.

If it is necessary to idle the engine for a prolonged period with people inside the vehicle, be sure to do so only in an open area with the air intake set at "Fresh" and fan control set to high so fresh air is drawn into the interior.

#### Keep the air intakes clear.

To assure proper operation of the ventilation system, keep the ventilation air intakes located in front of the windscreen clear of snow, ice, leaves, or other obstructions.

#### If you must drive with the tailgate open:

Close all windows.

Open instrument panel air vents.

Set the air intake control at "Fresh", the air flow control at "Floor" or "Face", and the fan control set to high.

#### **BEFORE DRIVING**

#### Before entering the vehicle

- Be sure all windows, outside mirror(s), and outside lights are clean and unobstructed.
- · Remove frost, snow, or ice.
- Visually check the tyres for uneven wear and damage.
- Check under the vehicle for any sign of leaks.
- Be sure there are no obstacles behind you if you intend to back up.

### **Before starting**

- Make sure the bonnet, the tailgate, and the doors are securely closed and locked.
- Adjust the position of the seat and steering wheel.
- Adjust the inside and outside rearview mirrors.
- · Verify all the lights work.
- Fasten your seat belt. Check that all passengers have fastened their seat belts.
- Check the gauges and indicators in the instrument panel and the messages on the instrument display when the ignition switch is in the ON position.
- Check that any items you are carrying are stored properly or fastened down securely.

## **⚠** WARNING

To reduce the risk of SERIOUS INJU-RY or DEATH, take the following precautions:

- ALWAYS wear your seat belt. All passengers must be properly belted whenever the vehicle is moving. For more details, refer to "Seat Belts" in chapter 3.
- Always drive defensively. Assume other drivers or pedestrians may be careless and make mistakes.
- Stay focused on the task of driving. Driver distraction can cause accidents.
- · Leave plenty of space between you and the vehicle in front of you.

## **MARNING**

NEVER drink or take drugs and drive.

Drinking or taking drugs and driving is dangerous and may result in an accident and SERIOUS INJURY or DEATH.

Drunk driving is the number one contributor to the highway death toll each year. Even a small amount of alcohol will affect your reflexes, perceptions and judgment. Just one drink can reduce your ability to respond to changing conditions and emergencies and your reaction time gets worse with each additional drink.

Driving whilst under the influence of drugs is as dangerous as or more dangerous than driving under the influence of alcohol.

You are much more likely to have a serious accident if you drink or take drugs and drive. If you are drinking or taking drugs, don't drive. Do not ride with a driver who has been drinking or taking drugs. Choose a designated driver or call a taxi.


#### **IGNITION SWITCH**



To reduce the risk of SERIOUS INJU-RY or DEATH, take the following precautions:

- NEVER allow children or any person who is unfamiliar with the vehicle to touch the ignition switch or related parts. Unexpected and sudden vehicle movement can occur.
- NEVER reach through the steering wheel for the ignition switch, or any other control, whilst the vehicle is in motion. The presence of your hand or arm in this area may cause a loss of vehicle control resulting in an accident.

# Key ignition switch (if equipped)



## **MARNING**

- NEVER turn the ignition switch to the LOCK or ACC position whilst the vehicle is in motion except in an emergency. This will result in the engine turning off and loss of power assist for the steering and brake systems. This may lead to loss of directional control and braking function, which could cause an accident.
- Before leaving the driver's seat, always make sure the shift lever is in 1st gear when the vehicle is parked on a uphill and in R (Reverse) on a downhill (for Manual transmission vehicle) or N (Neutral) position (for Automated Manual Transmission vehicle), apply the parking brake, and turn ignition switch to the LOCK position. Unexpected vehicle movement may occur if these precautions are not followed.

### NOTICE

Never use aftermarket keyhole covers. This may generate start-up failure due to communication failure.

## Key ignition switch positions

Switch Position	Action	Notice
LOCK	The ignition key can be removed in the LOCK position.	The steering wheel locks to protect the vehicle from theft. (if equipped)
ACC	Electrical accessories are usable.	The steering wheel unlocks. If difficulty is experienced turning the ignition switch to the ACC position, turn the key whilst turning the steering wheel right and left to release tension.
ON	This is the normal key position when the engine has started. All features and accessories are usable. The warning lights can be checked when you turn the ignition switch from ACC to ON.	Do not leave the ignition switch in the ON position when the engine is not running to prevent the battery from discharging.
START	To start the engine, turn the ignition switch to the START position. The switch returns to the ON position when you let go of the key.	The engine will crank until you release the key.

#### Starting the engine



### WARNING

- Always wear appropriate shoes when operating your vehicle. Unsuitable shoes, such as high heels, ski boots, sandals, flipflops, etc., may interfere with your ability to use the brake and accelerator pedals.
- Do not start the vehicle with the accelerator pedal depressed. The vehicle can move and lead to an accident.
- Wait until the engine rpm is normal. The vehicle may suddenly move if the brake pedal is released when the rpm is high.

Vehicle with Manual Transmission:

- 1. Make sure the parking brake is applied.
- 2. Make sure the shift lever is in N (Neutral).
- Depress the clutch and brake pedals.
- Turn the ignition switch to the START position. Hold the key (maximum of 10 seconds) until the engine starts and release it.

Vehicle with Automated Manual Transmission:

- 1. Make sure the parking brake is applied.
- Make sure the shift lever is in N (Neutral).
- 3. Depress the brake pedal firmly.
- 4. Turn the ignition switch to the START position. Hold the key (maximum of 10 seconds) until the engine starts and release it. The engine cannot be started unless the shift lever is N (Neutral) position.



### *i* Information

- Do not wait for the engine to warm up whilst the vehicle remains stationary. Start driving at moderate engine speeds. (Steep accelerating and decelerating should be avoided.)
- Always start the vehicle with your foot on the brake pedal. Do not depress the accelerator whilst starting the vehicle. Do not race the engine whilst warming it up.

#### NOTICE

To prevent damage to the vehicle:

- Do not hold the ignition key in the START position for more than 10 seconds. Wait 5 to 10 seconds before trying again.
- Do not turn the ignition switch to the START position with the engine running. It may damage the starter.
- If traffic and road conditions permit, you may put the shift lever in the N (Neutral) position whilst the vehicle is still moving and turn the ignition switch to the START position in an attempt to restart the engine.
- Do not push or tow your vehicle to start the engine.

# Engine Start/Stop button (if equipped)



Whenever the front door is opened, the Engine Start/Stop button will illuminate and will go off 30 seconds after the door is closed. (if equipped)



### **!** WARNING

To turn the engine off in an emergency:

Press and hold the Engine Start/ Stop button for more than two seconds OR rapidly press and release the Engine Start/Stop button three times (within three seconds).

If the vehicle is still moving, you can restart the engine with depressing the brake pedal (Automated Manual transmission) / brake pedal and clutch pedal (Manual transmission) by pressing the Engine Start/Stop button with the shift lever in the N (Neutral) position.

## **MARNING**

- NEVER press the Engine Start/ Stop button whilst the vehicle is in motion except in an emergency. This will result in the engine turning off and loss of power assist for the steering and brake systems. This may lead to loss of directional control and braking function, which could cause an accident.
- Before leaving the driver's seat, always set the parking brake, press the Engine Start/Stop button to the OFF position, and take the Smart Key with you. Unexpected vehicle movement may occur if these precautions are not followed.

## Engine Start/Stop button positions

<b>Button Position</b>	Action	Notice
OFF	<ul> <li>To turn off the engine, stop the vehicle and then press the Engine Start/Stop button.</li> <li>The steering wheel locks to protect the vehicle from theft. (if equipped)</li> </ul>	If the steering wheel is not locked properly when you open the driver's door, the warning chime will sound.
ACC	<ul> <li>Press the Engine Start/Stop button when the button is in the OFF position without depressing the clutch pedal.</li> <li>Electrical accessories are usable.</li> <li>The steering wheel unlocks.</li> </ul>	<ul> <li>If you leave the Engine Start/ Stop button in the ACC position for more than one hour, the battery power will turn off automatically to prevent the battery from discharging.</li> <li>If the steering wheel doesn't unlock properly, the Engine Start/Stop button will not work. Press the Engine Start/Stop button whilst turning the steering wheel right and left to release tension.</li> </ul>
ON	<ul> <li>Press the Engine Start/Stop button whilst it is in the ACC position without depressing the clutch pedal.</li> <li>The warning lights can be checked before the engine is started.</li> </ul>	Do not leave the Engine Start/ Stop button in the ON position when the engine is not running to prevent the battery from dis- charging.
START	To start the engine, depress the clutch and brake pedals and press the Engine Start/Stop button with the shift lever in neutral.	If you press the Engine Start/ Stop button without depressing the clutch pedal, the engine does not start and the Engine Start/Stop button changes as follows:  OFF → ACC → ON → OFF

#### Starting the engine



### ! WARNING

- Always wear appropriate shoes when operating your vehicle. Unsuitable shoes, such as high heels, ski boots, sandals, flipflops, etc., may interfere with your ability to use the brake and accelerator pedals.
- Do not start the vehicle with the accelerator pedal depressed.
  - The vehicle can move which can lead to an accident.
- Wait until the engine rpm is normal. The vehicle may suddenly move if the brake pedal is released when the rpm is high.

## *i* Information

- The engine will start by pressing the Engine Start/Stop button, only when the smart key is in the vehicle.
- Even if the smart key is in the vehicle, if it is far away from the driver, the engine may not start.
- When the Engine Start/Stop button is in the ACC or ON position, if any door is open, the system checks for the smart key. If the smart key is not in the vehicle, the "A" indicator will blink and the warning "Key not in vehicle" will come on, and if all doors are closed, the chime will also sound for about 5 seconds. Keep the smart key in the vehicle when using the ACC position or if the vehicle engine is ON.

Vehicle with Manual Transmission:

- 1. Always carry the smart key with you.
- 2. Make sure the parking brake is applied.
- Make sure the shift lever is in N (Neutral).
- Depress the clutch and brake pedals.
- 5. Press the Engine Start/Stop button.

Vehicle with Automated Manual Transmission:

- 1. Always carry the smart key with you.
- 2. Make sure the parking brake is applied.
- Make sure the shift lever is in N (Neutral).
- Depress the brake pedals.
- Press the Engine Start/Stop button.
   The engine cannot be started unless the shift lever is N (Neutral) position.

## *i* Information

- Do not wait for the engine to warm up whilst the vehicle remains stationary. Start driving at moderate engine speeds. (Steep accelerating and decelerating should be avoided.)
- Always start the vehicle with your foot on the brake pedal. Do not depress the accelerator whilst starting the vehicle. Do not race the engine whilst warming it up.

### NOTICE

To prevent damage to the vehicle:

- If traffic and road conditions permit, you may put the shift lever in the N (Neutral) position whilst the vehicle is still moving and press the Engine Start/Stop button in an attempt to restart the engine.
- Do not push or tow your vehicle to start the engine.

### NOTICE

To prevent damage to the vehicle:

Do not press the Engine Start/ Stop button for more than 10 seconds except when the stop light fuse is blown.

When the brake switch fuse is blown, you can't start the engine normally. Replace the fuse with a new one. If you are not able to replace the fuse, you can start the engine by pressing and holding the Engine Start/Stop button for 10 seconds with the Engine Start/ Stop button in the ACC position.

For your safety always depress the brake pedal before starting the engine.


#### Emergency starting



If the smart key battery is weak or the smart key does not work correctly, you can start the engine by pressing the Engine Start/Stop button with the smart key in the direction of the picture above.

#### **MANUAL TRANSMISSION (IF EQUIPPED)**





## **Manual transmission operation**

The manual transmission has 5 forward gears. The transmission is fully synchronized in all forward gears so shifting to either a higher or a lower gear is easily accomplished

## **MARNING**

Before leaving the driver's seat, always make sure the shift lever is in 1st gear when the vehicle is parked on a uphill and in R (Reverse) on a downhill, set the parking brake, and place the ignition switch in the LOCK/OFF position. Unexpected vehicle movement may occur if these precautions are not followed.

To shift to R (Reverse), make sure the vehicle has completely stopped, and then move the shift lever to neutral before moving into R (Reverse).

When you've come to a complete stop and it's hard to shift into 1st gear or R (Reverse):

- 1. Put the shift lever in neutral and release the clutch pedal.
- 2. Depress the clutch pedal, and then shift into first or R (Reverse) gear.

## *i* Information

During cold weather, shifting may be difficult until the transmission lubricant has warmed up.

#### Using the clutch (if equipped)

The clutch pedal should be depressed all the way to the floor before:

- Starting the engine
   The engine will not start without depressing the clutch pedal.
- Shifting

To start your vehicle, slowly release the clutch pedal and depress the accelerator.

When releasing the clutch pedal, release it slowly. The clutch pedal should always be released whilst driving.

### NOTICE

To prevent unnecessary wear or damage to the clutch:

- Do not rest your foot on the clutch pedal whilst driving.
- Do not hold the vehicle with the clutch on an incline, whilst waiting for the traffic light, etc.
- Always depress the clutch pedal down fully to prevent noise or damage.
- Do not start with the 2nd (second) gear engaged except when you start on a slippery road.
- Depress the clutch pedal all the way and be careful not to depress the pedal again before returning to the upright position after you release the pedal. If you depress the pedal before returning to the original position repeatedly, it may cause the clutch system failure.

### **Downshifting**

Downshift when you must slow down in heavy traffic or drive up a steep hill to prevent engine load.

Also, downshifting reduces the chance of stalling and can accelerate when you need to increase your speed again.

When the vehicle is going downhill, downshifting helps maintain safe speed by providing brake power from the engine and enables less wear on the brakes.

### NOTICE

To prevent damage to the engine, clutch and transmission:

- When downshifting from 5th gear to 4th gear, be careful not to inadvertently push the shift lever sideways engaging the 2nd gear. A drastic downshift may cause the engine speed to increase to the point the tachometer will enter the red-zone.
- Do not downshift more than two gear at a time or downshift the gear when the engine is running at high speed (5,000 RPM or higher). Such a downshifting may damage the engine, clutch and the transmission.

### **Good driving practices**

- Never take the vehicle out of gear and coast down a hill. This is extremely dangerous.
- Don't "ride" the brakes. This can cause the brakes and related parts to overheat and malfunction.
  - When you are driving down a long hill, slow down and shift to a lower gear. Engine braking will help slow down the vehicle.
- Slow down before shifting to a lower gear. This will help avoid over-revving the engine, which can cause damage.
- Slow down when you encounter cross winds. This gives you much better control of your vehicle.
- Be sure the vehicle is completely stopped before you shift into R (Reverse) to prevent damage to the transmission.
- Exercise extreme caution when driving on a slippery surface. Be especially careful when braking, accelerating or shifting gears. On a slippery surface, an abrupt change in vehicle speed can cause the drive wheels to lose traction and may cause loss of vehicle control resulting in an accident.

## **MARNING**


Do not use the engine brake (shifting from a higher gear to lower gear) rapidly on slippery roads. The vehicle may slip causing an accident.

## **MARNING**

To reduce the risk of SERIOUS INJU-RY or DEATH:

- ALWAYS wear your seatbelt. In a collision, an unbelted occupant is significantly more likely to be seriously injured or killed than a properly belted occupant.
- Avoid high speeds when cornering or turning.
- Do not make quick steering wheel movements, such as sharp lane changes or fast, sharp turns.
- The risk of rollover is greatly increased if you lose control of your vehicle at highway speeds.
- Loss of control often occurs if two or more wheels drop off the roadway and the driver over steers to reenter the roadway.
- In the event your vehicle leaves the roadway, do not steer sharply. Instead, slow down before pulling back into the travel lanes.
- HYUNDAI recommends you follow all posted speed limits.

### **AUTOMATED MANUAL TRANSMISSION (AMT) (IF EQUIPPED)**



Press the shift button, then move shift lever.

Move shift lever.

The Automated Manual Transmission (AMT) is a transmission equipped with a gear actuator and a clutch actuator in addition to the conventional manual transmission. To improve driving convenience, gear shift is automatically performed by the transmission control unit and clutch/gear actuator.

# **Automated Manual Transmission (AMT) operation**

The Automated Manual Transmission (AMT) has five forward speeds and one reverse speed.

The individual speeds are selected automatically in the D (Drive) position.

# Features of the Automated Manual Transmission (AMT)

- The Automated Manual Transmission (AMT) can be thought of as an automatically shifting manual transmission. It gives the driving feel of a manual transmission.
- When D (Drive) is selected, the transmission will automatically shift through the gears similar to a conventional automatic transmission. Unlike a traditional automatic transmission, the gear shifting can sometimes be felt and heard as the actuators engage the clutches and the gears are selected. When the gear is shifting, you may sometimes hear operating noise. This is normal and does not indicate a problem with your transmission.
- The Automated Manual Transmission (AMT) adopts a dry-type single clutch, which is different from the torque converter of the automatic transmission. It shows better acceleration performance and increased fuel efficiency whilst driving but initial launch might be slightly slower than the automatic transmission.

- As a result, gear shifts are sometimes more noticeable than a conventional automatic transmission and a light vibration during launching can be felt as the transmission speed is matched with the engine speed. This is a normal condition of the Automated Manual Transmission (AMT).
- The dry-type clutch transfers torque more directly and provides a direct drive feeling which may feel different from a conventional automatic transmission with a torque converter. This may be more noticeable when launching the vehicle from a stop or when travelling at low, stop-and-go vehicle speeds.
- When rapidly accelerating at a low vehicle speed, the engine rpm may increase highly depending on the vehicle's driving condition.
- For a smooth launch uphill, depress the accelerator pedal smoothly depending on the current conditions.
- If you release your foot from the accelerator pedal at low vehicle speed, you may feel engine braking, which is similar to manual transmission.

- When you turn the engine on and off, you may hear clicking sounds as the system goes through a self-test. This is a normal sound for the Automated Manual Transmission (AMT).
- During the first 1,000 miles (1,500 km), you may feel that the vehicle may not be smooth when accelerating at low speed. During this break-in period, the shift quality and performance of your new vehicle is continuously optimized.

## i Information


### **Creeping function**

The Creeping function helps the vehicle to start smoothly. If you take your foot off the brake pedal when the shift lever is in R (Reverse), D (Drive) or M (Manual) position, the vehicle will start slowly without depressing the accelerator pedal. To disable the function, depress the brake pedal or pull up the parking brake lever.

The creeping function will not operate when:

 The parking brake lever is engaged with the shift lever in R (Reverse), D (Drive) or M (Manual) position

# Automated Manual Transmission (AMT) instruction label



Read and follow the instruction label attached on the driver side's sunvisor before driving the vehicle.

Lever shifting condition

Levers	Lever shifting	Shifting condition	dition	When shi	fting con	When shifting condition is dissatisfied	atisfied
					Cluster		
From (Current position)	From To (Current position)	Vehicle speed	Brake	Shift indicator	Sound	Brake press indicator	Transmission
ı	z	N/A		1		-	ı
<b>r</b>	Q	Reversing below 4 mph (7 km/h)	Applied	R or N blinking	On	uO	z
z	Œ	Moving forward below 1 mph (2 km/h)	Applied	N blinking	On	uO	z
	Q	Reversing below 4 mph (7 km/h)	Applied	N blinking	On	uO	z
Q	Œ	Moving forward below 1 mph (2 km/h)	Applied	D or N blinking	On	uO	Z
	z	N/A		1		-	

## **MARNING**

To reduce the risk of serious injury or death:

- ALWAYS check the surrounding areas near your vehicle for people, especially children, before shifting a vehicle into D (Drive) or R (Reverse).
- Before leaving the driver's seat, always make sure the shift lever is in the N (Neutral) position, then set the parking brake, and place the ignition switch in the LOCK/OFF position. Unexpected and sudden vehicle movement can occur if these precautions are not followed.
- Do not use engine braking (shifting from a high gear to lower gear) rapidly on slippery roads. The vehicle may slip causing an accident.

The indicator in the instrument cluster displays the shift lever position when the ignition switch is in the ON position.

## **MARNING**

- After the vehicle has stopped, always make sure the shift lever is in N (Neutral), apply the parking brake, and turn the engine off.
- Do not use the N (Neutral) position in place of the parking brake.

### Automated Manual Transmission (AMT) warning indicator



#### **Press Brake**

The engine cannot be started unless the shift lever is N (Neutral) position and brake pedal is depressed.

#### Automated Manual Transmission (AMT) warning light



#### **Clutch Over Heated**

This warning light indicates that the clutch is overheated. It appears for a whilst when the ignition switch is turned ON. The indicator light illuminates when the Clutch's estimated temperature rises up to limited value.

## information

The AMT warning light may come on when clutch slip occurs excessively due to repeated stop-and-go driving on steep grades or the vehicle is held on an incline for a long time. In order to prevent warning light to turn ON, use the brake during low speed driving on a hill or when stopping the vehicle on an uphill slope.

- If the vehicle is held on a hill by using only the accelerator pedal or by creeping with brake pedal disengaged, the clutch may overheat which can result in damage. At this time, a warning light will appear on the cluster.
- If the warning light is ON, the foot brake must be applied.
- Ignoring the warnings can lead to damage to the clutch and transmission.

## Cluster display for transmission warning message AMT warning message



Driving up hills or on steep grades:

- To hold the vehicle on an incline use the foot brake or the parking brake.
- When in stop-and-go traffic on an incline, maintain a distance with the vehicle ahead before moving the vehicle forward. Then hold the vehicle on the incline with the foot brake.
- If the vehicle is held on a hill by applying the accelerator pedal or by creeping with brake pedal disengaged, the clutch and transmission may overheat which can result in damage. At this time, a warning message will appear on the cluster display.
- If the warning message appears on the cluster display, the foot brake must be applied.
- Ignoring the warnings can lead to damage to the transmission.



Transmission(clutch) High temperature (first & second warning)


- Under certain conditions, such as repeated stop-and-go launches on steep grades, sudden take off or acceleration, or other harsh driving conditions, the transmission clutch temperatures will increase excessively.
- When the clutch temperature is high, the safe protection mode engages and the gear position indicator on the cluster blinks with a chime. At this time, "Transmission temperature is high! Stop safely" warning message will appear on the cluster display and driving may not be smooth.

- After the first warning, clutch temperature will increase continuously. Then a warning will sound and the shift indicator will blink continuously (second warning).
- If this occurs, pull over to a safe location, stop the vehicle with the engine running, apply the brakes and allow the clutch to cool for a few minutes with engine on.
- If you ignore this warning, the driving condition may become worse. You may experience abrupt shifts, jerkiness. To return to the normal driving condition, Stop the vehicle and apply the foot brake. Then allow the transmission to cool for a few minutes with the engine on.



### **!** WARNING

On an uphill road, never hold the vehicle at a stop using only the accelerator pedal or the creeping mode. This may cause clutch overheating and excessive damage, resulting in the reduction of the clutch's life cycle.





OAC3069062TU

# Transmission(clutch) overheated (final warning)

- If the vehicle continues to be driven and the clutch temperature reaches the maximum temperature limit, the "Transmission hot! Park with engine On" warning will be displayed.
- The time of the transmission to cool down will be displayed.
- If this occurs, pull over to a safe location, stop the vehicle with the engine running, apply the brakes and shift the vehicle to N (Neutral), and allow the transmission to cool.

- When the message "Transmission cooled down. Resume driving" appears you can continue to drive your vehicle.
- When possible, drive the vehicle smoothly.
- If any of the warnings continue to blink, for your safety, we recommend you contact a HYUNDAI authorised repairer and have the system checked.

## *i* Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

### **Transmission ranges**

#### R (Reverse)

Use this position to drive the vehicle backward.

#### NOTICE

- Always come to a complete stop before shifting into R (Reverse) position.
- When moving to R (Reverse) position the gear is not shifted if the vehicle speed is over 3 km/h (2 mph).
- Depress the brake pedal fully. If not, the brake press indicator will illuminate and the gear is not shifted.

#### N (Neutral)

The wheels and transmission are not engaged.

Use N (Neutral) if you need to restart a stalled engine, or if it is necessary to stop with the engine ON.

Always depress the brake pedal when you are shifting from N (Neutral) to another gear.

## **MARNING**

Do not shift into gear unless your foot is firmly on the brake pedal. Shifting into gear when the engine is running at high speed can cause the vehicle to move very rapidly. You could lose control of the vehicle and hit people or objects.

#### D (Drive)

This is the normal forward driving position. The transmission will automatically shift to the appropriate gear position upon operation of the accelerator pedal and variation of vehicle speed.

For extra power when passing another vehicle or driving uphill, depress the accelerator further until you feel the transmission downshift to a lower gear.

#### When starting off on an uphill

- Engage the parking brake firmly to prevent the vehicle from rolling backwards.
- Move the shift lever to D (Drive) position whilst depressing the brake pedal. Make sure that the shift indicator in the cluster displays 1st gear.
- Take your foot of the brake pedal and depress the accelerator pedal gradually. Then, when the vehicle starts moving, release the parking brake and depress the accelerator pedal.

#### When starting off on a downhill

- Depress the brake pedal and move the shift lever to D (Drive) position.
   Make sure that the shift indicator in the cluster displays 1st gear.
- Take your foot off the brake pedal and slowly depress the accelerator pedal. When the vehicle speed increases, the clutch will be engaged.

- If the gear is not shifted after changing the shift lever from N (Neutral) to D (Drive)/M (Manual)/R (Reverse), try to shift the gear again. In this case, time delay and intermittent noise may occur which are normal.
- Always come to a complete stop and depress the brake pedal before shifting into D (Drive) position.
- When moving from R (Reverse) to D (Drive) position, the gear is not shifted if the vehicle speed is over 5 mph (8 km/h).
- Depress the brake pedal fully. If not, the brake press indicator will illuminate and the gear is not shifted.

#### Manual shift mode



Whether the vehicle is stationary or in motion, Manual shift mode is selected by pushing the shift lever from the D (Drive) position into the manual gate (M). To return to D (Drive) range operation, push the shift lever back into the main gate.

In Manual shift mode, moving the shift lever backwards and forwards will allow you to select the desired range of gears for the current driving conditions.

- + (Up) : Push the lever forward once to shift up one gear.
- (Down) : Pull the lever backwards once to shift down one gear.

### NOTICE

If you cannot move the shift lever into any position or if the gear is automatically moved to N (Neutral) position when the vehicle speed becomes below 6 mph (10 km/h), this may indicate malfunction of the system. In this case, we recommend the system be checked by a HYUN-DAI authorised repairer.

## *i* Information

- Only five forward gears can be selected. To reverse or park the vehicle, move the shift lever to the R (Reverse) or N (Neutral) position as required.
- Downshifts are made automatically when the vehicle slows down. When the vehicle stops, 1st gear is automatically selected.
- When the engine rpm approaches the red zone the transmission will upshift automatically.
- If the driver presses the lever to + (Up) or (Down) position, the transmission may not make the requested gear change if the next gear is outside of the allowable engine rpm range. The driver must execute upshifts in accordance with road conditions, taking care to keep the engine rpms below the red zone.
- When accelerating from a stop on a slippery road, push the shift lever forward into the + (Up) position. This allows the transmission to shift into the 2nd gear which is better for smooth driving on a slippery road. Push the shift lever to the (Down) side to shift back to the 1st gear.

#### **Parking**

To park your vehicle, always come to a complete stop and continue to depress the brake pedal.

- When parking on the flat road, move the shift lever from D (Drive)/R (Reverse) to N (Neutral) position. Then, engage the parking brake firmly before turning off the engine.
- When parking on a slope, it is recommended to place the shift lever in D (Drive) for uphill and R (Reverse) for downhill and to engage the parking brake before turning off the engine.

If the engine was turned off with the shift lever in D (Drive) or R (Reverse) position, it is necessary to depress the brake pedal and move the shift lever to N (Neutral) position to turn on the engine. Take the Key with you when exiting the vehicle.

## **MARNING**

When you stay in the vehicle with the engine running, be careful not to depress the accelerator pedal for a long period of time. The engine or exhaust system may overheat and start a fire.

The exhaust gas and the exhaust system are very hot. Keep away from the exhaust system components.

Do not stop or park over flammable materials, such as dry grass, paper or leaves. They may ignite and cause a fire.

#### **Good driving practices**

- Never move the shift lever from N (Neutral) to any other position with the accelerator pedal depressed.
- Be sure the vehicle is completely stopped before you attempt to shift into R (Reverse) or D (Drive).
- Do not move the shift lever to N (Neutral) when driving. Doing so may result in an accident because of a loss of engine braking and the transmission could be damaged.
- Do not drive with your foot resting on the brake pedal. Even light, but consistent pedal pressure can result in the brakes overheating, brake wear and possibly even brake failure.
- Depressing both accelerator and brake pedals at the same time can trigger logic for engine power reduction to assure vehicle deceleration.
   Vehicle acceleration will resume after the brake pedal is released.
- When driving in Manual shift mode, slow down before shifting to a lower gear. Otherwise, the lower gear may not be engaged if the engine rpms are outside of the allowable range.
- Always apply the parking brake when leaving the vehicle. Do not depend on placing the transmission in N (Neutral) to keep the vehicle from moving.

- Exercise extreme caution when driving on a slippery surface. Be especially careful when braking, accelerating or shifting gears. On a slippery surface, an abrupt change in vehicle speed can cause the drive wheels to lose traction and may cause loss of vehicle control resulting in an accident
- Optimum vehicle performance and economy is obtained by smoothly depressing and releasing the accelerator.

## **MARNING**

#### To reduce the risk of SERIOUS INJU-RY or DEATH:

- ALWAYS wear your seatbelt. In a collision, an unbelted occupant is significantly more likely to be seriously injured or killed than a properly belted occupant.
- Avoid high speeds when cornering or turning.
- Do not make quick steering wheel movements, such as sharp lane changes or fast, sharp turns.
- The risk of rollover is greatly increased if you lose control of your vehicle at highway speeds.
- Loss of control often occurs if two or more wheels drop off the roadway and the driver over steers to reenter the roadway.
- In the event your vehicle leaves the roadway, do not steer sharply. Instead, slow down before pulling back into the travel lanes.
- HYUNDAI recommends you follow all posted speed limits.

#### **BRAKING SYSTEM**

#### **Power brakes**

Your vehicle has power-assisted brakes that adjust automatically through normal usage.

If the engine is not running or is turned off whilst driving, the power assist for the brakes will not work. You can still stop your vehicle by applying greater force to the brake pedal than typical. The stopping distance, however, will be longer than with power brakes.

When the engine is not running, the reserve brake power is partially depleted each time the brake pedal is applied. Do not pump the brake pedal when the power assist has been interrupted.

Pump the brake pedal only when necessary to maintain steering control on slippery surfaces.

### *i* Information

- When the brake pedal is depressed under certain driving conditions or weather conditions, you may temporarily hear a noise. This is normal and does not indicate a problem with your brakes.
- Whilst driving on a road with deicing chemicals, brake noise or abnormal tyre wear may occur due to deicing chemicals. In a safe traffic condition, additionally apply the brakes to remove deicing chemicals on the brake discs and pads.

### **MARNING**

Take the following precautions:

- Do not drive with your foot resting on the brake pedal. This will create abnormal high brake temperatures, excessive brake lining and pad wear, and increased stopping distances.
- When descending down a long or steep hill, downshift to a lower gear in order to control your speed without using the brake pedal excessively. Applying the brakes continuously will cause the brakes to overheat and could result in a temporary loss of braking performance.
- · Wet brakes may impair the vehicle's ability to safely slow down; the vehicle may also pull to one side when the brakes are applied. Applying the brakes lightly will indicate whether they have been affected in this way. Always test vour brakes in this fashion after driving through deep water. To dry the brakes, lightly tap the brake pedal to heat up the brakes whilst maintaining a safe forward speed until brake performance returns to normal. Avoid driving at high speeds until the brakes function correctly.

#### Disc brakes wear indicator

When your brake pads are worn and new pads are required, you will hear a high pitched warning sound from your front or rear brakes. You may hear this sound come and go or it may occur whenever you depress the brake pedal.

#### NOTICE

To avoid costly brake repairs, do not continue to drive with worn brake pads.



Always replace brake pads as complete front or rear axle sets.

#### **Rear drum brakes**

Your rear drum brakes do not have wear indicators. Therefore, have the rear brake linings inspected if you hear a rear brake rubbing noise. Also have your rear brakes inspected each time you change or rotate your tyres and when you have the front brakes replaced.

#### **Parking brake**




Always set the parking brake before leaving the vehicle, to apply:

Firmly depress the brake pedal.

Pull up the parking brake lever as far as possible.



To reduce the risk of SERIOUS INJU-RY or DEATH, do not operate the parking brake whilst the vehicle is moving except in an emergency situation. It could damage the brake system and lead to an accident.



#### To release:

Firmly depress the brake pedal. Slightly pull up the parking brake lever. Whilst pressing the release button (1), lower the parking brake (2).

If the parking brake does not release or does not release all the way, we recommend that the system be checked by a HYUNDAI authorised repairer.



Whenever leaving the vehicle or parking, always come to a complete stop and continue to depress the brake pedal.

Move the shift lever into the 1st gear (for Manual transmission vehicle) or N (Neutral, for Automated Manual Transmission vehicle) position, then apply the parking brake, and place the ignition switch in the LOCK/OFF position.

#### Parking brake warning light



Check the Parking Brake Warning Light by placing the ignition switch to the ON position (do not start the engine).

This light will be illuminated when the parking brake is applied with the ignition switch in the START or ON position

Before driving, be sure the parking brake is released and the Brake Warning Light is OFF.

If the Parking Brake Warning Light remains on after the parking brake is released whilst the engine is running, there may be a malfunction in the brake system. Immediate attention is necessary.

If at all possible, cease driving the vehicle immediately. If that is not possible, use extreme caution whilst operating the vehicle and only continue to drive the vehicle until you can reach a safe location.

#### **Anti-lock Brake System (ABS)**

### **MARNING**

An Anti-Lock Braking System (ABS) or an Electronic Stability Control (ESC) system will not prevent accidents due to improper or dangerous driving manoeuvres. Even though vehicle control is improved during emergency braking, always maintain a safe distance between you and objects ahead of you. Vehicle speeds should always be reduced during extreme road conditions. The braking distance for vehicles equipped with ABS or ESC may be longer than for those without these systems in the following road conditions.

Drive your vehicle at reduced speeds during the following conditions:

- Rough, gravel or snow-covered roads.
- On roads where the road surface is pitted or has different surface height.
- Tyre chains are installed on your vehicle.

The safety features of an ABS or ESC equipped vehicle should not be tested by high speed driving or cornering. This could endanger the safety of yourself or others.

ABS is an electronic braking system that helps prevent a braking skid. ABS allows the driver to steer and brake at the same time.

#### Using ABS

To obtain the maximum benefit from your ABS in an emergency situation, do not attempt to modulate your brake pressure and do not try to pump your brakes. Depress your brake pedal as hard as possible.

When you apply your brakes under conditions which may lock the wheels, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal. This is normal and it means your ABS is active.

ABS does not reduce the time or distance it takes to stop the vehicle.

Always maintain a safe distance from the vehicle in front of you.

ABS will not prevent a skid that results from sudden changes in direction, such as trying to take a corner too fast or making a sudden lane change. Always drive at a safe speed for the road and weather conditions.

ABS cannot prevent a loss of stability. Always steer moderately when braking hard. Severe or sharp steering wheel movement can still cause your vehicle to veer into oncoming traffic or off the road.

On loose or uneven road surfaces, operation of the anti-lock brake system may result in a longer stopping distance than for vehicles equipped with a conventional brake system.

### **⚠** WARNING

#### NOTICE

When you drive on a road having poor traction, such as an icy road, and apply your brakes continuously, the ABS will be active continuously and the ABS warning light ((B)) may illuminate. Pull your vehicle over to a safe place and turn the engine off.

Restart the engine. If the ABS warning light is off, then your ABS system is normal.

Otherwise, you may have a problem with your ABS system. We recommend that you contact a HYUNDAI authorised repairer as soon as possible.

### Information

When you jump start your vehicle because of a drained battery, the ABS warning light (((3))) may turn on at the same time. This happens because of the low battery voltage. It does not mean your ABS is malfunctioning. Have the battery recharged before driving the vehicle.

# **Electronic Stability Control** (ESC)



The Electronic Stability Control (ESC) system helps to stabilize the vehicle during cornering manoeuvres.

ESC checks where you are steering and where the vehicle is actually going. ESC applies braking pressure to any one of the vehicle's brakes and intervenes in the engine management system to assist the driver with keeping the vehicle on the intended path. It is not a substitute for safe driving practices. Always adjust your speed and driving to the road conditions.

# **MARNING**

Never drive too fast for the road conditions or too quickly when cornering. The ESC system will not prevent accidents.

Excessive speed in turns, abrupt manoeuvres, and hydroplaning on wet surfaces can result in severe accidents.

#### ESC operation

#### ESC ON condition

When the ignition switch is in the ON position, the ESC and the ESC OFF indicator lights illuminate for about three seconds. After both lights go off, the ESC is enabled.

#### When operating



When the ESC is in operation, the ESC indicator light blinks:

- When you apply your brakes under conditions which may lock the wheels, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal. This is normal and it means your ESC is active.
- When the ESC activates, the engine may not respond to the accelerator as it does under routine conditions.
- If the Cruise Control was in use when the ESC activates, the Cruise Control automatically disengages. The Cruise Control can be reengaged when the road conditions allow. For more information, refer to the "Cruise Control System" in chapter 7. (if equipped).
- When moving out of the mud or driving on a slippery road, the engine rpm (revolutions per minute) may not increase even if you press the accelerator pedal deeply. This is to maintain the stability and traction of the vehicle and does not indicate a problem.

#### **ESC OFF condition**



To cancel ESC operation:

#### State 1



Press the ESC OFF button briefly. The ESC OFF indicator light and/or message "Traction control disabled" will illuminate and a warning chime sounds once. In this state, the traction control function of ESC (engine management) is disabled, but the brake control function of ESC (braking management) still operates.

#### • State 2



Press and hold the ESC OFF button continuously for more than 3 seconds. The ESC OFF indicator light and/or message "Traction control and ESC disabled" illuminates and a warning chime sounds twice. In this state, both the traction control function of ESC (engine management) and the brake control function of ESC (braking management) are disabled.


If the ignition switch is placed in the LOCK/OFF position when ESC is off, ESC remains off. Upon restarting the vehicle, the ESC will automatically turn on again.

### i

#### Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

#### Indicator lights



When the ignition switch is in the ON position, the ESC indicator light illuminates, then goes off if the ESC system is operating normally.

The ESC indicator light blinks whenever the ESC is operating.

If the ESC indicator light stays on, your vehicle may have a malfunction with the ESC system. When this warning light illuminates we recommend that the vehicle be checked by a HYUNDAI authorised repairer as soon as possible.

The ESC OFF indicator light comes on when the ESC is turned off with the button.



#### WARNING

When the ESC is blinking, this indicates the ESC is active:

Drive slowly and NEVER attempt to accelerate. NEVER turn the ESC off whilst the ESC indicator light is blinking or you may lose control of the vehicle resulting in an accident.

#### **NOTICE**

Driving with wheels and tyres with different sizes may cause the ESC system to malfunction. Before replacing tyres, make sure all four tyres and wheels are the same size. Never drive the vehicle with different sized wheels and tyres installed.

#### ESC OFF usage

When Driving

The ESC OFF mode should only be used briefly to help free the vehicle if stuck in snow or mud, by temporarily stopping operation of the ESC, to maintain wheel torque.

To turn ESC off whilst driving, press the ESC OFF button whilst driving on a flat road surface.

#### NOTICE

To prevent damage to the transmission:

- Do not allow wheel(s) of one axle to spin excessively whilst the ESC, ABS, and parking brake warning lights are displayed. The repairs would not be covered by the vehicle warranty. Reduce engine power and do not spin the wheel(s) excessively whilst these lights are displayed.
- When operating the vehicle on a dynamometer, make sure the ESC is turned off (ESC OFF light illuminated).

### *i* Information

Turning the ESC off does not affect ABS or standard brake system operation.

# **Vehicle Stability Management** (VSM)

The Vehicle Stability Management (VSM) is a function of the Electronic Stability Control (ESC) system. It helps ensure the vehicle stays stable when accelerating or braking suddenly on wet, slippery and rough roads where traction over the four tyres can suddenly become uneven.

### **MARNING**

Take the following precautions when using the Vehicle Stability Management (VSM):

- ALWAYS check the speed and the distance to the vehicle ahead. The VSM is not a substitute for safe driving practices.
- Never drive too fast for the road conditions. The VSM system will not prevent accidents. Excessive speed in bad weather, slippery and uneven roads can result in severe accidents.

#### VSM operation

When operating

When you apply your brakes under conditions which may activate the ESC, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal. This is normal and it means your VSM is active.

### Information

The VSM does not operate when:

- Driving on a banked road such as gradient or incline
- Driving in reverse.
- The ESC OFF indicator light is on.
- The MDPS (Motor Driven Power Steering) warning light (⊝!) is on or blinks.

### **MARNING**

If the ESC indicator light (\$\overline{\mathcal{S}}\$) or MDPS warning light (\$\overline{\mathcal{S}}\$!) stays on or blinks, your vehicle may have a malfunction with the VSM system. When the warning light illuminates, we recommend that the vehicle be checked by a HYUNDAI authorised repairer as soon as possible.

#### NOTICE

Driving with wheels and tyres with different sizes may cause the ESC system to malfunction. Before replacing tyres, make sure all four tyres and wheels are the same size. Never drive the vehicle with different sized tyres and wheels installed.

#### Hill-Start Assist Control (HAC)

Hill-Start Assist Control helps prevent the vehicle from rolling backwards when starting a vehicle from a stop on a hill. The system operates the brakes automatically for about 2 seconds (maximum of 5 seconds when the accelerator pedal is slightly depressed during HAC operation) and releases the brake after 2 seconds or when the accelerator pedal is depressed.

### **⚠** WARNING

Always be ready to depress the accelerator pedal when starting off an incline. Hill-Start Assist Control activates only for about 2 seconds (maximum of 5 seconds when the accelerator pedal is slightly depressed during HAC operation).

### i Information

- The HAC does not operate when the shift lever is in N (Neutral).
- The HAC activates even when the ESC (Electronic Stability Control) is off. However, it does not activate, when the ESC does not operate normally.

#### **Emergency Stop Signal (ESS)**

The Emergency Stop Signal system alerts the driver behind by blinking the stop light when the vehicle is braked rapidly and severely.

The system is activated when:

- The vehicle suddenly stops (vehicle speed is over 34 mph (55 km/h) and the vehicle deceleration at greater than 7 m/s²)
- · The ABS is activating

When the vehicle speed is under 25 mph (40 km/h) and the ABS deactivates or the sudden stop situation is over, the stop light blinking will stop. Instead, the hazard warning flasher will turn on automatically.

The hazard warning flasher will turn off when vehicle speed is over 6 mph (10 km/h) after the vehicle has stopped. Also, it will turn off when the vehicle is driven at low speed for some time. You can turn it off manually by pushing the hazard warning flasher switch.



The Emergency Stop Signal (ESS) system will not work if the hazard warning flasher is already on.

#### **Brake Assist System (BAS)**

The Brake Assistant System provides additional pressure when the brake pedal is momentarily and strongly depressed in a situation sudden braking is required while driving. The Brake Assistant System reduces the time for ABS (Anti-Lock Brake System) control to enter and consequently reduces the braking distance by providing additional pressure up to the point of ABS intervention.

#### **BAS** operation

- When the vehicle speed is more than 30 km/h (20 mph) and the ABS control is not entered.
- When the brake pedal is depressed strongly over a certain level.
- When the friction of the road surface is above a certain level.

#### BAS operation off

- The vehicle speed is below 10 km/h (6 mph).
- The brake pedal is depressed over a certain conditions.
- The friction of the road surface is below a certain level.

### **MARNING**

The system may not operate depending on driver's driving habit, driving speed, the degree to which the brake pedal is depressed and the road surface condition.

#### **Good braking practices**



#### WARNING

Whenever leaving the vehicle or parking, always come to a complete stop and continue to depress the brake pedal. Move the shift lever into the 1st gear (for manual transmission vehicle) or N (Neutral) position (for Automated Manual Transmission vehicle), then apply the parking brake, and place the ignition switch in the LOCK/OFF position.

Vehicles parked with the parking brake not applied or not fully engaged may roll inadvertently and may cause injury to the driver and others. ALWAYS apply the parking brake before exiting the vehicle.

Wet brakes can be dangerous! The brakes may get wet if the vehicle is driven through standing water or if it is washed.

Your vehicle will not stop as quickly if the brakes are wet. Wet brakes may cause the vehicle to pull to one side.

To dry the brakes, apply the brakes lightly until the braking action returns to normal. If the braking action does not return to normal, stop as soon as it is safe to do so and we recommend that you call a HYUNDAI authorised repairer for assistance.

DO NOT drive with your foot resting on the brake pedal. Even light, but constant pedal pressure can result in the brakes overheating, brake wear, and possibly even brake failure.

If a tyre goes flat whilst you are driving, apply the brakes gently and keep the vehicle pointed straight ahead whilst you slow down. When you are moving slowly enough for it to be safe to do so, pull off the road and stop in a safe location.

Keep your foot firmly on the brake pedal when the vehicle is stopped to prevent the vehicle from rolling forward.

#### ISG (IDLE STOP AND GO) SYSTEM (IF EQUIPPED)

The ISG system is to reduce the fuel consumption by automatically shutting down the engine, when the vehicle is at a standstill (for example, red stop light, stop sign, and traffic jam).

The engine is automatically started upon satisfying the starting conditions. The ISG system is always active, when the engine is running.

### information

When the engine is automatically started by the ISG system, some warning lights (for example, ABS, ESC, ESC OFF, MDPS, and parking brake warning light) may illuminate for a few seconds due to the low battery voltage. However, it does not indicate a malfunction with the ISG system.

#### To activate ISG system


#### Prerequisite for activation

The ISG system operates in the following situations.

- · The driver's seatbelt is fastened
- The driver's door and bonnet are closed
- The brake vacuum pressure is adequate
- The battery sensor is activated and the battery is sufficiently charged
- Outside temperature is not too low or too high
- The vehicle is driven over a constant speed and stops
- The climate control system satisfies the conditions
- The vehicle is sufficiently warmed up
- · The incline is gradual

 The steering wheel is turned less than 180 degrees and then the vehicle stops

### *i* Information



- The ISG system is not activated, when the prerequisites to activate the ISG system are unsatisfied. In this case, the ISG OFF button indicator illuminates, and the auto stop indicator ((A)) illuminates in yellow on the instrument cluster.
- When the above indicator remains illuminated on the instrument cluster, we recommend that you have the ISG system checked by a HYUNDAI authorised repair.

#### Auto stop

To stop the engine in idle stop mode Manual transmission vehicle

- 1. Decrease the vehicle speed to 3 mph (5 km/h).
- 2. Set the gear in N (Neutral).
- 3. Release the clutch pedal.

The auto stop indicator  $(\widehat{A})$  illuminates in green on the instrument cluster, when the engine stops.

### *i* Information

The driving speed must reach at least 5 km/h (3 mph) after an idle stop to stop the engine in idle stop mode again.

# Automated Manual Transmission vehicle

- Decrease the vehicle speed to 0 km/h.
- 2. Depress the brake pedal with the shift lever in D (Drive) or N (Neutral).

The auto stop indicator  $(\widehat{A})$  illuminates in green on the instrument cluster, when the engine stops.

### *i* Information

The driving speed must reach at least 3 mph (5 km/h) after an idle stop to stop the engine in idle stop mode again.

In auto stop mode, when the driver opens the bonnet, the ISG system will be deactivated.

When the system is deactivated:



The ISG OFF button indicator illuminates.



The message, "Auto Stop is Off. Press clutch pedal and start engine manually", appears on the cluster display with a beep sound.

At this time, restart the vehicle manually by:

#### Manual transmission vehicle

Depressing the clutch and brake pedal with the gear in neutral.

### **Automated Manual Transmission vehicle**

Depressing the brake pedal with the shift lever in N (Neutral).

#### Auto start

To restart the engine in the auto stop mode

#### Manual transmission vehicle

- When the brake pedal is depressed
- 1) Depress the clutch pedal
- 2) Release the brake pedal
- When the brake pedal is not depressed
- 1) Depress the clutch pedal

The auto stop indicator ((A)) goes OFF on the instrument cluster, when the engine is restarted.

### Automated Manual Transmission vehicle

- Release the brake pedal.
- When Auto Hold is activated, if you release the brake pedal, the engine will be in the auto stop state. However, if you depress the accelerator pedal, the engine will start again.

The auto stop indicator ((A)) goes OFF on the instrument cluster, when the engine is restarted.

The engine is automatically restarted in the following situations.

- The brake vacuum pressure is low
- The engine has stopped for about 5 minutes
- The air conditioning is ON with the fan speed set to the highest position
- · The front defroster is ON
- The battery is weak
- The cooling and heating performance of the climate control system is unsatisfactory

The auto stop indicator ((A)) blinks in green for 5 seconds on the instrument cluster and a message "Auto Start" will appear on the cluster display.

The auto start is temporarily deactivated in the following situations.



### Automated Manual Transmission vehicle

When the shift lever is shifted from N (Neutral) to R (Reverse), D (Drive) or Manual shift mode without the brake pedal depressed. A message "Press brake pedal before driving on" will appear on the cluster display. To activate auto start, depress the brake pedal.

#### To deactivate ISG system

- Press the ISG OFF button to deactivate the ISG system. Then, the ISG OFF button indicator illuminates, and the message "Auto Stop System Off" appears on the cluster display.
- Press the ISG OFF button again to reactivate the ISG system. Then, the ISG OFF button indicator turns OFF.

#### ISG system malfunction

The ISG system may not operate: When there is a malfunction with the ISG sensors or the ISG system.

The followings occur, when there is a malfunction with the ISG system:

- The auto stop indicator (A) will blink in yellow on the instrument cluster.
- The light on the ISG OFF button will illuminate.

### *i* Information

- When you cannot turn OFF the ISG OFF button indicator by pressing the ISG OFF button, or when the malfunction with the ISG system persists, we recommend that you contact a HYUNDAI authorised repairer.
- You can turn off the ISG OFF button indicator by driving over 50 mph (80 km/h) for up to 2 hours with the fan speed below the 2nd position. If the ISG OFF button indicator remains ON, we recommend that you contact a HYUNDAI authorised repairer.

### **MARNING**

When the engine is in auto stop mode, the engine may restart. Before leaving the vehicle or checking the engine compartment, stop the engine by placing the ignition switch to the LOCK/OFF position or removing the ignition key.

# The battery sensor deactivation



[A]: Battery sensor

The battery sensor is deactivated, when the battery is disconnected from the negative pole for maintenance purpose.

In this case, the ISG system is limitedly operated due to the battery sensor deactivation. Thus, the driver needs to take the following procedures to reactivate the battery sensor after disconnecting the battery.

# Prerequisites to reactivate the battery sensor

Keep the engine in the OFF status for 4 hours, and attempt to restart the engine 3 to 4 times for the battery-sensor reactivation.

Pay extreme caution not to connect any accessories (for example, navigation and black box) to the vehicle with the engine in the OFF status. If not, the battery sensor may not be reactivated.

### *i* Information

The ISG system may not operate in the following situations.

- There is a malfunction with the ISG system.
- The battery is weak.
- The brake vacuum pressure is low.

In those cases, we recommend that you have the ISG system checked by a HYUNDAI authorised repairer.

#### NOTICE

- Use only the genuine HYUNDAI ISG battery or the equivalent speficied for your vehicle for replacement. If not, the ISG system may not normally operate.
- Do not recharge the ISG battery with a general battery charger. If not, it may damage or explode the ISG battery.
- Do not remove the battery cap. If not, the battery electrolyte, which is harmful to the human body, may leak out.

#### **SPECIAL DRIVING CONDITIONS**

#### **Hazardous driving conditions**

When hazardous driving elements are encountered such as water, snow, ice, mud and sand, take the following precautions:

- Drive cautiously and maintain a longer braking distance.
- · Avoid abrupt braking or steering.
- When your vehicle is stuck in snow, mud, or sand, use second gear. Accelerate slowly to avoid unnecessary wheel spin.
- Put sand, rock salt, tyre chains or other non-slip materials under the wheels to provide additional traction whilst the vehicle becomes stuck in ice, snow, or mud.

### **MARNING**

Downshifting with an Automated manual transmission, whilst driving on slippery surfaces can cause an accident. The sudden change in tyre speed could cause the tyres to skid. Be careful when downshifting on slippery surfaces.

#### **Rocking the vehicle**

If it is necessary to rock the vehicle to free it from snow, sand, or mud, first turn the steering wheel right and left to clear the area around your front wheels. Then, shift back and forth between 1st and R (Reverse, for manual transmission vehicle) or R (Reverse) and a forward gear (for Automated manual transmission vehicle).

Try to avoid spinning the wheels, and do not race the engine.

To prevent transmission wear, wait until the wheels stop spinning before shifting gears. Release the accelerator pedal whilst shifting, and press lightly on the accelerator pedal whilst the transmission is in gear. Slowly spinning the wheels in forward and reverse directions causes a rocking motion that may free the vehicle.

### **MARNING**

If the vehicle is stuck and excessive wheel spin occurs, the temperature in the tyres can increase very quickly. If the tyres become damaged, a tyre blow out or tyre explosion can occur. This condition is dangerous you and others may be injured. Do not attempt this procedure if people or objects are anywhere near the vehicle.

If you attempt to free the vehicle, the vehicle can overheat quickly, possibly causing an engine compartment fire or other damage. Try to avoid spinning the wheels as much as possible to prevent overheating of either the tyres or the engine. DO NOT allow the vehicle to spin the wheels above 35 mph (56 km/h).

### information

The ESC system must be turned OFF before rocking the vehicle.

#### NOTICE

If you are still stuck after rocking the vehicle a few times, have the vehicle pulled out by a tow vehicle to avoid engine overheating, possible damage to the transmission, and tyre damage. See "Towing" in chapter 8.

#### **Smooth cornering**

Avoid braking or gear changing in corners, especially when roads are wet. Ideally, corners should always be taken under gentle acceleration.

#### **Driving at night**

Night driving presents more hazards than driving in the daylight. Here are some important tips to remember:

- Slow down and keep more distance between you and other vehicles, as it may be more difficult to see at night, especially in areas where there may not be any street lights.
- Adjust your mirrors to reduce the glare from other drivers' headlights.
- Keep your headlights clean and properly aimed. Dirty or improperly aimed headlights will make it much more difficult to see at night.
- Avoid staring directly at the headlights of oncoming vehicles. You could be temporarily blinded, and it will take several seconds for your eyes to readjust to the darkness.

#### **Driving in the rain**

Rain and wet roads can make driving dangerous. Here are a few things to consider when driving in the rain or on slick pavement:

- Slow down and allow extra following distance. A heavy rainfall makes it harder to see and increases the distance needed to stop your vehicle.
- Turn OFF your Cruise Control (if equipped).
- Replace your windscreen wiper blades when they show signs of streaking or missing areas on the windscreen.

- Be sure your tyres have enough tread. If your tyres do not have enough tread, making a quick stop on wet pavement can cause a skid and possibly lead to an accident. See "Tyre replacement" in chapter 9.
- Turn on your headlights to make it easier for others to see you.
- Driving too fast through large puddles can affect your brakes. If you must go through puddles, try to drive through them slowly.
- If you believe your brakes may be wet, apply them lightly whilst driving until normal braking operation returns.

#### Hydroplaning

If the road is wet enough and you are going fast enough, your vehicle may have little or no contact with the road surface and actually ride on the water. The best advice is SLOW DOWN when the road is wet.

The risk of hydroplaning increases as the depth of tyre tread decreases, refer to "Tyre replacement" in chapter 9.

#### **Driving in flooded areas**

Avoid driving through flooded areas unless you are sure the water is no higher than the bottom of the wheel hub. Drive through any water slowly. Allow adequate stopping distance because brake performance may be reduced.

After driving through water, dry the brakes by gently applying them several times whilst the vehicle is moving slowly.

#### **Highway driving**

#### **Tyres**

Adjust the tyre inflation, as specified. Under-inflation may overheat or damage the tyres.

Do not install worn-out or damaged tyres, which may reduce traction or fail the braking operation.

### *i* Information

Never over-inflate your tyres above the maximum inflation pressure, as specified on your tyres.

# Fuel, engine coolant and engine oil

Driving at higher speeds on the highway consumes more fuel and is less efficient than driving at a slower, more moderate speed. Maintain a moderate speed in order to conserve fuel when driving on the highway.

Be sure to check both the engine coolant level and the engine oil before driving.

#### Drive belt

A loose or damaged drive belt may overheat the engine.

#### Reducing the risk of a rollover

Your multi-purpose passenger vehicle is defined as a Sports Utility Vehicle (SUV).

SUV's have higher ground clearance and a narrower track to make them capable of performing in a wide variety of off-road applications. The specific design characteristics give them a higher centre of gravity than ordinary vehicles making them more likely to roll over if you make abrupt turns. Utility vehicles have a significantly higher rollover rate than other types of vehicles.

Due to this risk, driver and passengers are strongly recommended to buckle their seat belts. In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt. There are steps that a driver can make to reduce the risk of a rollover.

If at all possible, avoid sharp turns or abrupt manoeuvres, do not load your vehicle with heavy cargo on the roof, and never modify your vehicle in any way.

### **WARNING**

Utility vehicles have a significantly higher rollover rate than other types of vehicles. To prevent rollovers or loss of control:

- Take corners at slower speeds than you would with a passenger vehicle.
- Avoid sharp turns and abrupt manoeuvres.
- Do not modify your vehicle in any way that you would raise the centre of gravity.
- · Keep tyres properly inflated.
- Do not carry heavy cargo on the roof.

### **MARNING**

In a rollover crash, an unbelted person is significantly more likely to die than a person wearing a seat belt. Make sure all passengers are wearing their seat belts.

#### WINTER DRIVING

The severe weather conditions of winter quickly wear out tyres and cause other problems. To minimise winter driving problems, you should take the following suggestions:

#### **Snow or icy conditions**

You need to keep sufficient distance between your vehicle and the vehicle in front of you.

Apply the brakes gently. Speeding, rapid acceleration, sudden brake applications, and sharp turns are potentially very hazardous practices. During deceleration, use engine braking to the fullest extent. Sudden brake applications on snowy or icy roads may cause the vehicle to skid.

To drive your vehicle in deep snow, it may be necessary to use snow tyres or to install tyre chains on your tyres.

Always carry emergency equipment. Some of the items you may want to carry include tyre chains, tow straps or chains, a flashlight, emergency flares, sand, a shovel, jumper cables, a window scraper, gloves, ground cloth, coveralls, a blanket, etc.

#### Snow tyres



#### ! WARNING

Snow tyres should be equivalent in size and type to the vehicle's standard tyres. Otherwise, the safety and handling of your vehicle may be adversely affected.

If you mount snow tyres on your vehicle, make sure to use radial tyres of the same size and load range as the original tyres. Mount snow tyres on all four wheels to balance your vehicle's handling in all weather conditions. The traction provided by snow tyres on dry roads may not be as high as your vehicle's original equipment tyres. Check with the tyre dealer for maximum speed recommendations.



#### Information

Do not install studded tyres without first checking local and municipal regulations for possible restrictions against their use.

#### Tyre chains



Since the sidewalls of radial tyres are thinner than other types of tyres, they may be damaged by mounting some types of tyre chains on them. Therefore, the use of snow tyres is recommended instead of tyre chains. Do not mount tyre chains on vehicles equipped with aluminum wheels; if possible use a wire type chain. If tyre chains must be used, use genuine HYUNDAI parts or the equivalent speficied for your vehicle and install the tyre chain after reviewing the instructions provided with the tyre chains. Damage to your vehicle caused by improper tyre chain use is not covered by your vehicle manufacturer's warrantv.

#### NOTICE

If your vehicle has 185/55R15 or 195/45R16 size tyres do not use tyre chain; they can damage your vehicle (wheel, suspension and body).

### **MARNING**

The use of tyre chains may adversely affect vehicle handling:

- Drive less than 20 mph (30 km/h) or the chain manufacturer's recommended speed limit, whichever is lower.
- Drive carefully and avoid bumps, holes, sharp turns, and other road hazards, which may cause the vehicle to bounce.
- Avoid sharp turns or locked wheel braking.

### i Information

- Install tyre chains on the front tyres.
   It should be noted that installing tyre chains on the tyres will provide a greater driving force, but will not prevent side skids.
- Do not install studded tyres without first checking local and municipal regulations for possible restrictions against their use.

#### **Chain Installation**

When installing tyre chains, follow the manufacturer's instructions and mount them as tightly possible. Drive slowly (less than 20 mph (30 km/h)) with chains installed. If you hear the chains contacting the body or chassis, stop and tighten them. If they still make contact, slow down until the noise stops. Remove the tyre chains as soon as you begin driving on cleared roads.

When mounting snow chains, park the vehicle on level ground away from traffic. Turn on the vehicle

Hazard Warning Flasher and place a triangular emergency warning device behind the vehicle (if available). Always place the vehicle in P (Park), apply the parking brake and turn off the engine before installing snow chains.

#### NOTICE

When using tyre chains:

- Wrong size chains or improperly installed chains can damage your vehicle's brake lines, suspension, body and wheels.
- Use SAE "S" class or wire chains.
- If you hear noise caused by chains contacting the body, retighten the chain to prevent contact with the vehicle body.
- To prevent body damage, retighten the chains after driving 0.3~0.6 miles (0.5~1.0 km).
- Do not use tyre chains on vehicles equipped with aluminum wheels. If unavoidable, use a wire type chain.
- Use wire chains less than 0.47 in (12 mm) wide to prevent damage to the chain's connection.

#### **Winter Precautions**

### Use high quality ethylene glycol coolant

Your vehicle is delivered with high quality ethylene glycol coolant in the cooling system. It is the only type of coolant that should be used because it helps prevent corrosion in the cooling system, lubricates the water pump and prevents freezing.

Be sure to replace or replenish your coolant in accordance with the maintenance schedule in chapter 9. Before winter, have your coolant tested to assure that its freezing point is sufficient for the temperatures anticipated during the winter.

#### Check battery and cables

Winter temperatures affect battery performance. Inspect the battery and cables, as specified in the chapter 9. The battery charging level can be checked by a HYUNDAI authorised repairer or in a service station.

# Change to "winter weight" oil if necessary

In some regions during winter, it is recommended to use the "winter weight" oil with lower viscosity. For further information, refer to the chapter 2. When you are not sure about a type of winter weight oil, we recommend that you consult a HYUNDAI authorised repairer.

# Check spark plugs and ignition system

Inspect the spark plugs, as specified in the chapter 9. If necessary, replace them. Also check all ignition wirings and components for any cracks, wearout, and damage.

#### To prevent locks from freezing

To prevent the locks from being frozen, spray approved de-icing fluid or glycer-in into key holes. When a lock opening is already covered with ice, spray approved de-icing fluid over the ice to remove it. When an internal part of a lock freezes, try to thaw it with a heated key. Carefully use the heated key to avoid an injury.

#### Use approved window washer antifreeze solution in system

To prevent the window washer from being frozen, add authorized window washer anti-freeze solution, as specified on the window washer container. Window washer anti-freeze solution is available from a HYUNDAI authorised repairer, and most vehicle accessory outlets. Do not use engine coolant or other types of anti-freeze solution to prevent any damage to the vehicle paint.

#### Do not let your parking brake freeze

Under some conditions your parking brake can freeze in the engaged position.

This is most likely to happen when there is an accumulation of snow or ice around or near the rear brakes or if the brakes are wet. When there is the risk that your parking brake may freeze, temporarily apply it with the shift lever in N (for Automated Manual Transmission) or in first or reverse gear (for manual transmission). Also, block the rear wheels in advance, so the vehicle may not roll. Then, release the parking brake.

### Do not let ice and snow accumulate underneath

Under some conditions, snow and ice can build up under the fenders and interfere with the steering. When driving in such conditions during the severe winter, you should check underneath the vehicle on a regular basis, to ensure that the front wheels and the steering components is unblocked.

#### Carry emergency equipment

In accordance with weather conditions, you should carry appropriate emergency equipment, whilst driving. Some of the items you may want to carry include tyre chains, tow straps or chains, flashlight, emergency flares, sand, shovel, jumper cables, window scraper, gloves, ground cloth, coveralls, blanket, etc.

# Do not place objects or materials in the engine compartment

Putting objects or materials in the engine compartment may cause an engine failure or combustion, because they may block the engine cooling. Such damage will not be covered by the manufacturer's warranty.

# Drive your vehicle when water vapour condenses and accumulates inside the exhaust pipes

When the vehicle is stopped for a long time in winter whilst the engine is running, water vapour may condense and accumulate inside the exhaust pipes. Water in the exhaust pipes may cause noise, etc., but it is drained driving at medium to high speed.

#### VEHICLE WEIGHT

Two labels on your driver's door sill show how much weight your vehicle was designed to carry: the Tyre and Loading Information Label and the Certification Label.

Before loading your vehicle, familiarize yourself with the following terms for determining your vehicle's weight ratings, from the vehicle's specifications and the Certification Label:

#### **Base Kerb Weight**

This is the weight of the vehicle including a full tank of fuel and all standard equipment. It does not include passengers, cargo, or optional equipment.

#### Vehicle Kerb Weight

This is the weight of your new vehicle when you picked it up from your dealer plus any aftermarket equipment.

#### **Cargo Weight**

This figure includes all weight added to the Base Kerb Weight, including cargo and optional equipment.

#### **GAW (Gross Axle Weight)**

This is the total weight placed on each axle (front and rear) - including vehicle kerb weight and all payload.

#### **GAWR (Gross Axle Weight Rating)**

This is the maximum allowable weight that can be carried by a single axle (front or rear). These numbers are shown on the Certification Label. The total load on each axle must never exceed its GAWR.

#### **GVW (Gross Vehicle Weight)**

This is the Base Kerb Weight plus actual Cargo Weight plus passengers.

# GVWR (Gross Vehicle Weight Rating)

This is the maximum allowable weight of the fully loaded vehicle (including all options, equipment, passengers and cargo). The GVWR is shown on the Certification Label located on the driver's door sill.

#### **Overloading**



#### WARNING

The Gross Axle Weight Rating (GAWR) and the Gross Vehicle Weight Rating (GVWR) for your vehicle are on the Certification Label attached to the driver's (or front passenger's) door. Exceeding these ratings can cause an accident or vehicle damage. You can calculate the weight of your load by weighing the items (and people) before putting them in the vehicle. Be careful not to overload your vehicle.

#### TRAILER TOWING (IF EQUIPPED)

If you are considering to tow with your vehicle, you should first your country's legal requirements. As laws vary the requirements for towing trailers, cars, or other types of vehicles or apparatus may differ. We recom-mend that you ask a HYUNDAI authorised repairer for further details before towing.

Remember that trailering is different than just driving your vehicle by itself. Trailering means changes in han-dling, durability, and fuel economy. Successful, safe trailering requires correct equipment, and it has to be used properly. Damage to your vehi-cle caused by improper trailer towing is not covered by your vehicle manu-facturer's warranty.

This section contains many time-tested, important trailering tips and safety rules. Many of these are important for your safety and that of your passengers. Please read this section carefully before you pull a trailer.

### **⚠** WARNING

Take the following precautions:

- If you don't use the correct equipment and/or drive improp-erly, you can lose control of the vehicle when you are pulling a trailer. For example, if the trailer is too heavy, the braking per-formance may be reduced. You and your passengers could be seriously or fatally injured. Pull a trailer only if you have fol-lowed all the steps in this sec-tion.
- Before towing, make sure the total trailer weight, GCW (Gross Combination Weight), GVW (Gross Vehicle Weight), GAW (Gross Axle Weight) and trailer tongue load are all within the limits.
- When you tow a trailer, make sure to turn off the ISG system.

### *i* Information

- Do not install any equipment on the vehicle that blocks the license plate and cannot be easily removed or repositioned.
- When a trailer is not used, detach it from the vehicle so that the license plate is visible.

### *i* Information


- The technically permissible maximum load on the rear axle(s) may be exceeded by not more than 15 % and the technically permissible maximum laden mass of the vehicle may be exceeded by not more than 10 % or 220.4 lbs (100 kg), whiche ver value is lower. In this case, do not exceed 62.1 mph (100 km/h) for vehicle of category M1 or 49.7 mph (80 km/h) for vehicle of category N1.
- When a vehicle of category M1 is towing a trailer, the additional load imposed at the trailer coupling device may cause the tire maximum load ratings to be exceeded, but not by more than 15 %. In this case, do not exceed 62.1 mph (100 km/h) and increase the tire inflation pressure by at least 0.2 bar.
- \* M1: passenger vehicle (9-seater or under)
- \* N1 : commercial vehicle (3.5ton or under)

#### If you decide to pull a trailer?

Here are some important points if you decide to pull a trailer:


- Consider using a sway control. You can ask a trailer hitch dealer about sway control.
- Do not do any towing with your vehicle during its first 1,200 miles (2,000 km) in order to allow the engine to properly break in. Failure to heed this caution may result in serious engine or transmission damage.
- When towing a trailer, we recommend that you consult a HYUNDAI authorized repairer for further information on additional require-ments such as a towing kit, etc.
- Always drive your vehicle at a moderate speed (less than 60 mph (100 km/h)) or posted towing speed limit.
- On a long uphill grade, do not exceed 45 mph (70 km/h) or the posted towing speed limit, whichever is lower.
- Carefully observe the weight and load limits provided in the following pages.

#### Trailer weight



What is the maximum safe weight of a trailer? It should never weigh more than the maximum trailer weight with trailer brakes. But even that can be too heavy. It depends on how you plan to use your trailer. For example, speed, altitude, road grades, outside temperature and how often your vehicle is used to pull a trailer are all important. The ideal trailer weight can also depend on any special equipment that you have on your vehicle.

#### Tongue load



The tongue load is an important weight to measure because it affects the total Gross Vehicle Weight (GVW) of your vehicle. The trailer tongue should weigh a maximum of 10 % of the total loaded trailer weight, within the limits of the maximum trail-er tongue load permissible.

After you've loaded your trailer, weigh the trailer and then the tongue, separately, to see if the weights are proper. If they aren't, you may be able to correct them simply by moving some items around in the trailer

### **MARNING**

Take the following precautions:

- Never load a trailer with more weight in the rear than in the front. The front should be loaded with approximately 60 % of the total trailer load; the rear should be loaded with approximately 40 % of the total trailer load.
- Never exceed the maximum weight limits of the trailer or trailer towing equipment. Improper loading can result in damage to your vehicle and/or personal injury. Check weights and loading at a commercial scale or highway patrol office equipped with scales.

### *i* Information

With increasing altitude the engine performance decreases. From 1,000 m above sea level and for every 1,000 m thereafter 10 % of vehicle/trailer weight (trailer weighter + gross vehicle weight) must be deducted.

#### Reference weight and distance when towing a trailer

The following table indicates the maximum trailer weight for your vehicle.

Do not exceed the maximum allowable trailer weight.

The maximum trailer weight includes the weight of the trailer, any cargo, and equipment or items attached to the trailer. The towing load in excess of these limits can seriously affect vehicle steering and performance, and may damage the engine and drivetrain.

Item		Smartstream G1.0		Smartstream G1.0 T-GDi	Smartstream G1.2		
		AMT	MT	MT	AMT	MT	
Maximum trailer weight lbs. (kg)	With brake system	661 (300)					
	Without brake sys- tem	661 (300)					
Maximum permissible static vertical load on the coupling device		165 (75)					
lbs. (kg)							
Recommended distance from rear wheel center to coupling point		25.19 (640)					
inch (mm)							

Any additional weight, cargo, or accessories in your vehicle will reduce the maximum trailer weight and corresponding tongue load limits.

#### **Trailer towing equipment**

#### **Hitches**

Make sure that all equipment is properly installed and maintained, and that it meets federal, state, and local regulations. Hyundai recommends that you have all trailer hitch equipment installed at a HYUNDAI authorised repairer with factory-recommended accessory parts that are specifically designed for your vehicle.

Here are some rules to follow about hitches:

- The bumpers on your vehicle are not intended for hitches. Do not attach rental hitches or other bumper-type hitches to them. Use only a framemounted hitch that does not attach to the bumper.
- Any part of the rear license plate or lighting devices of the vehicle must not be obscured by the mechanical coupling device. If the rear number plate and/or lighting devices can be obscured partially by any part of the mechanical coupling device, mechanical coupling devices that cannot be easily removed or repositioned without use of any tools, except an easily operated (an effort not exceeding 15 lbf.ft (20 Nm) release key that is supplied by the manufacturer of the coupling device, are not permitted for use.

Note that the mechanical coupling device that is fitted and not used must always be removed or repositioned if the rear number plate and/or rear lighting devices are obscured by any part of the mechanical coupling device.

 A HYUNDAI trailer hitches are available from a HYUNDAI authorised repairer.

#### Safety chains

You should always attach chains between your vehicle and your trailer. Instructions about safety chains may be provided by the hitch manufactur-er or trailer manufacturer. Follow the manufacturer's recommendation for attaching safety chains. Always leave just enough slack so you can turn with your trailer. And, never allow safety chains to drag on the ground.

#### Trailer brakes

If your trailer is equipped with a braking system, make sure it conforms to your country's regulations and that it is properly installed and operating correctly.

If your trailer weighs more than the maximum trailer weight without trailer brakes loaded, then it needs its own brakes and they must be ade-quate. Be sure to read and follow the instructions for the trailer brakes so you'll be able to install, adjust and maintain them properly. Be sure not to modify your vehicle's brake sys-tem.



#### **WARNING**

Do not use a trailer with its own brakes unless you are absolutely certain that you have properly set up the brake system. This is not a task for amateurs. Use an experienced, competent trailer shop for this work.

#### **Driving with a trailer**

Towing a trailer requires a certain amount of experience. Before setting out for the open road, you must get to know your trailer. Acquaint yourself with the feel of handling and braking with the added weight of the trailer. And always keep in mind that the vehicle you are driving is now longer and not nearly as responsive as your vehicle is by itself.

Before you start, check the trailer hitch and platform, safety chains, electrical connector(s), lights, tires and brakes.

During your trip, occasionally check to be sure that the load is secure, and that the lights and trailer brakes are still working.

#### Distance

Stay at least twice as far behind the vehicle ahead as you would when driving your vehicle without a trailer. This can help you avoid situations that require heavy braking and sud-den turns.

#### Passing

You will need more passing distance up ahead when you're towing a trail-er. And, because of the increased vehicle length, you'll need to go much farther beyond the passed vehicle before you can return to your lane.

#### Backing up

Hold the bottom of the steering wheel with one hand. Then, to move the trailer to the left, move your hand to the left. To move the trailer to the right, move your hand to the right. Always back up slowly and, if possi-ble, have someone guide you.

#### Making turns

When you're turning with a trailer, make wider turns than normal. Do this so your trailer won't strike soft shoulders, curbs, road signs, trees, or other objects. Avoid jerky or sudden maneuvers. Signal well in advance.

#### Turn signals

When you tow a trailer, your vehicle has to have a different turn signal flasher and extra wiring. The green arrows on your instrument panel will flash whenever you signal a turn or lane change. Properly connected, the trailer lights will also flash to alert other drivers you're about to turn, change lanes, or stop.

When towing a trailer, the green arrows on your instrument panel will flash for turns even if the bulbs on the trailer are burned out. Thus, you may think drivers behind you are seeing your signals when, in fact, they are not. It's important to check occasionally to be sure the trailer bulbs are still working. You must also check the lights every time you disconnect and then reconnect the wires.



#### WARNING

Do not connect a trailer lighting system directly to your vehicle's lighting system. Use an approved trailer wiring harness. Failure to do so could result in damage to the vehicle electrical system and/or personal injury. We recommend that you consult a HYUNDAI authorised repairer for assistance.

#### Driving on hills

Reduce speed and shift to a lower gear before you start down a long or steep downgrade. If you don't shift down, you might have to use your brakes so much that they would get overheated and may not operate effi-ciently.

On a long uphill grade, shift down and reduce your speed to around 45 mph (70 km/h) to reduce the possibility of engine and transmission overheating.

If your trailer weighs more than the maximum trailer weight without trail-er brakes and you have an automated manual transmission, you should drive in D (Drive) when towing a trailer.

Operating your vehicle in D (Drive) when towing a trailer will minimize heat build-up and extend the life of your transmission.

#### NOTICE

To prevent engine and/or trans-mission overheating:

• When towing a trailer on steep grades (in excess of 6 %) pay close attention to the engine coolant temperature gauge to ensure the engine does not overheat. If the needle of the coolant temperature gauge moves towards "130", pull over and stop as soon as it is safe to do so, and allow the engine to idle until it cools down. You may proceed once the engine has cooled sufficiently.

- If you tow a trailer with the maximum gross vehicle weight and maximum trailer weight, it can cause the engine or transmission to overheat. When driving in such conditions, allow the engine to idle until it cools down. You may proceed once the engine or transmission has cooled sufficiently.
- When towing a trailer, your vehicle speed may be much slower than the general flow of traffic, especially when climbing an uphill grade. Use the right hand lane when towing a trailer on an uphill grade. Choose your vehicle speed according to the maximum posted speed limit for vehicles with trailers, the steepness of the grade, and your trailer weight.
- Vehicles equipped with an automated manual transmission when towing a trailer on steep grades, need to be aware that the clutch in the transmission could over-heat. When the clutch is over-heated, the safe protection mode engages. If the safe protection mode engages, the gear position indicator on the cluster blinks with a chime sound.

#### Parking on hills

Generally, if you have a trailer attached to your vehicle, you should not park your vehicle on a hill.

However, if you ever have to park your trailer on a hill, here's how to do it:

- 1. Pull the vehicle into the parking space.
  - Turn the steering wheel in the direction of the curb (right if head-ed down hill, left if headed up hill).
- 2. Shift the vehicle to neutral (N)
- Set the parking brake and shut off the vehicle.
- Place wheel chocks under the trailer wheels on the down hill side of the wheels.
- Start the vehicle, hold the brakes, shift to neutral, release the park-ing brake and slowly release the brakes until the trailer chocks absorb the load.
- Reapply the brakes and parking brakes.
- 7. Move the shift lever to 1st gear (for manual transmission vehicle) or N (Neutral, for automated manual transmission vehicle) when the vehicle is parked on a uphill grade and in R (Reverse) on a downhill.
- Shut off the vehicle and release the vehicle brakes but leave the parking brake set.

### **MARNING**

To prevent serious or fatal injury:

- Do not get out of the vehicle without the parking brake firmly set. If you have left the engine running, the vehicle can move suddenly. You and others could be seriously or fatally injured.
- Do not apply the accelerator pedal to hold the vehicle on an uphill.

# Ready to leave after parking on a hill

- With the shift lever in neutral (for manual transmission vehicle) or N (Neutral, for automated manual transmission vehicle), apply your brakes and hold the brake pedal down whilst you:
  - · Start your engine;
  - · Shift into gear; and
  - Release the parking brake.
- 2. Slowly remove your foot from the brake pedal.
- 3. Drive slowly until the trailer is clear of the chocks.
- 4. Stop and have someone pick up and store the chocks.

# Maintenance when towing a trailer

Your vehicle will need service more often when you regularly pull a trail-er. Important items to pay particular attention to include engine oil, transmission fluid, axle lubricant and cooling system fluid. Brake condition is another important item to frequently check. If you're trailering, it's a good idea to review these items before you start your trip. Don't forget to also maintain your trailer and hitch. Follow the maintenance schedule that accompanied your trailer and check it periodically. Preferably, conduct the check at the start of each day's driving. Most importantly, all hitch nuts and bolts should be tight.

#### NOTICE

#### To prevent vehicle damage:


- Due to higher load during trailer usage, overheating might occur on hot days or during uphill driv-ing. If the coolant gauge indi-cates over-heating, switch off the air conditioner and stop the vehicle in a safe area to cool down the engine.
- Do not switch off the engine whilst the coolant gauge indi-cates overheating. (Keep the engine idle to cool down the engine)
- If your vehicle is not equipped with an air conditioner, you should install a condenser fan to improve engine performance when towing a trailer.

# 7. Driver assistance system

Due to the infotainment software version, the description of each function of the driver assistance system may differ from the owner's manual.

Forward Collision-Avoidance Assist (FCA)	7-2
Forward Collision-Avoidance Assist settings	
Forward Collision-Avoidance Assist operation	
Forward Collision-Avoidance Assist malfunction and limitations.	7-8
Lane Keeping Assist (LKA)	7-15
Lane Keeping Assist settings	7-15
Lane Keeping Assist Operation	7-17
Lane Keeping Assist malfunction and limitations	7-19
Manual Speed Limit Assist (MSLA)	7-22
Manual Speed Limit Assist operation	
Intelligent Speed Limit Assist(ISLA)	7-25
Intelligent Speed Limit Assist settings	
Intelligent Speed Limit Assist operation	7-27
Intelligent Speed Limit Assist malfunction and limitations	7-29
Driver Attention Warning (DAW)	7-32
Driver Attention Warning settings	
Driver Attention Warning operation	7-33
Driver Attention Warning malfunction and limitations	7-34
Cruise Control (CC)	7-38
Cruise Control operation	7-38
Lane Following Assist (LFA)	7-42
Lane Following Assist Settings	
Turning Lane Following Assist On/Off	
Lane Following Assist malfunction and limitations	
Rear View Monitor (RVM)	7-47
Rear View Monitor settings	
Rear View Monitor Operation	
Rear View Monitor malfunction and limitations	7-49
Reverse Parking Distance Warning (PDW)	7-50
Reverse Parking Distance Warning settings	7-50
Reverse Parking Distance Warning operation	
Reverse Parking Distance Warning malfunction and limitations .	7-51

# FORWARD COLLISION-AVOIDANCE ASSIST (FCA) (IF EQUIPPED)



Forward Collision-Avoidance Assist is designed to help detect and monitor the vehicle ahead or help detect a pedestrian or a cyclist in the roadway and warn the driver that a collision is imminent with a warning message and an audible warning, and if necessary, apply emergency braking.

#### Detecting sensor



[1]: Front view camera

Refer to the picture above for the detailed location of the detecting sensor.

### **!** CAUTION

Take the following precautions to maintain optimal performance of the detecting sensor:

- NEVER disassemble the detecting sensor or sensor assembly, or cause any damage to it.
- If the detecting sensor have been replaced or repaired, we recommend that you have your vehicle inspected by a HYUNDAI authorised repairer.
- NEVER install any accessories or stickers on the front winds-creen, or tint the front winds-creen.
- Exercise extreme caution to keep the front view camera dry.
- NEVER place any reflective objects (for example, white paper, mirror) over the dashboard.
- Do not place any objects near the front windshield or install any accessories on the front windshield. It can affect the performance of the defogging and defrosting function of the climate control system, which may prevent the Driver Assistance systems from operating
- Do not apply license plate frame or objects, such as a bumper sticker, film or a bumper guard, near the front radar cover.

# Forward Collision-Avoidance Assist settings

#### Forward Safety



With the engine on, select or deselect User settings > Driver assistance > Diving safety from the settings menu in the instrument cluster or Settings > Vehicle > Driver assistance > Driving safety settings menu in the infotainment system to set whether or not to use each function.

If 'Forward Safety' is selected, Forward Collision-Avoidance Assist will warn you with a warning message and an audible warning depending on the collision risk levels. Braking assist will be applied depending on the collision risk levels.

The driver can monitor Forward Collision-Avoidance Assist ON/OFF status from the Settings menu. If the warning light remains ON when Forward Collision-Avoidance Assist is ON, we recommend to have the vehicle inspected by a HYUNDAI authorised repairer.



When the engine is restarted, Forward Collision-Avoidance Assist will always turn on. However, if Forward Safety is deselected, the driver should always be aware of the surroundings and drive safely.

#### Forward Safety warning timing



- With the engine on, select User settings > Driver assistance > Driving safety > Forward Safety Warning Timing from the settings menu in the instrument cluster or Settings > Vehicle > Driver assistance > Driving safety > Forward Safety Warning Timing settings menu in the infotainment system to change the initial warningactivation time for Forward Collision-Avoidance Assist. The warning timecan be set to either Normal or Later.
- Use Normal in normal driving conditions. If the Warning Timingseems sensitive, change it to Later.
- If Later is selected, Forward Collision-Avoidance Assist, warns the driver more slowly.

#### Warning methods



The Warning Methods can be set when the vehicle is in ON position.

- Warning volume: Select User settings > Driver assistance > Warning volume on the instrument cluster or Settings > Vehicle > Driver assistance > Warning methods > Warning volume on the infotainment system, and adjust the warning volume.
- Driving safety priority: Select Settings > Vehicle > Driver assistance
   > Warning methods > Driving safety priority on the infotainment system, the audio volume is reduced whilst a warning sounds.

## **CAUTION**

- The setting of the Warning Timing and Warning Volume applies to all functions of Forward Collision-Avoidance Assist.
- Even though 'Normal' is selected for Warning Timing, if the front vehicle suddenly stops, the warning may seem late.
- Select 'Late' for Warning Timing when traffic is light and when driving speed is slow.

# *i* Information

If the engine is restarted, Warning Timing and Warning Volume will maintain the last setting.

# Forward Collision-Avoidance Assist operation

#### Warning and control

The basic function for Forward Collision-Avoidance Assist is to warn and help control the vehicle depending on the collision risk level: 'Collision Warning', 'Emergency Braking' and 'Stopping vehicle and ending brake control'.



OAC3073055TU

#### **Collision warning**

- To warn the driver of a collision, Forward Safety warning light (♣) blinks, the 'Collision Warning' warning message will appear on the cluster and an audible warning will sound.
- If a vehicle is detected in front, the function will operate when your vehicle speed is between about 3-112 mph (5-180 km/h).
- If a pedestrian or a cyclist is detected in front, the function will operate when your vehicle speed is between about 3-49 mph (5-80 km/h).



OAC3073045TU

#### **Emergency braking**

- To warn the driver that emergency braking will occur, Forward Safety warning light (ﷺ) blinks, the 'Emergency Braking' warning message will appear on the cluster and an audible warning will sound.
- If a vehicle is detected in front, the function will operate when your vehicle speed is between about 6-37 mph (10-60 km/h).
- The function operation range may decrease due to the front traffic condition or the surroundings of the vehicle
- If a pedestrian or a cyclist is detected in front, the function will operate when your vehicle speed is between about 6-37 mph (10-60 km/h).
- In emergency braking situation, braking is assisted with strong braking power by the function to help prevent collision with the vehicle, pedestrian or cyclist ahead.



# Stopping vehicle and ending brake control

- When the vehicle is stopped due to emergency braking, the 'Drive carefully' warning message will appear on the cluster.
- For your safety, the driver should depress the brake pedal immediately and check the surroundings.
- Brake control will end after the vehicle is stopped by emergency braking for about 2 seconds.

## *i* Information

The warning sound during collision warning and emergency braking can be switched off by pressing the hazard warning flasher button

## **MARNING**

Take the following precautions when using Forward Collision-Avoidance Assist:

- For your safety, change the Settings after parking the vehicle at a safe location.
- Forward Collision-Avoidance Assist does not operate in all situations or cannot avoid every collisions.

- The driver should hold the responsibility to control the vehicle. Do not solely depend on Forward Collision-Avoidance Assist. Rather, maintain a safe braking distance, and, if necessary, depress the brake pedal to reduce driving speed or to stop the vehicle.
- Never deliberately operate Forward Collision-Avoidance Assist on people, animal, objects, etc. It may cause serious injury or death.
- Forward Collision-Avoidance Assist may not operate if the driver depresses the brake pedal to avoid collision.
- Depending on the road and driving conditions, Forward Collision-Avoidance Assist may warn the driver late or may not warn the driver
- During Forward Collision-Avoidance Assist operation the vehicle may stop suddenly injuring passengers and shifting loose objects. Always have the seat belt on and keep loose objects secured.
- If any other system's warning message is displayed or audible warning is generated, Forward Collision-Avoidance Assist warning message may not be displayed and audible warning may not be generated.
- You may not hear the warning sound of Forward Collision-Avoidance Assist if the surrounding is noisy.
- Forward Collision-Avoidance Assist may turn off or may not operate properly or may operate unnecessarily depending on the road conditions and the surroundings.

### **⚠** WARNING

- Even if there is a problem with Forward Collision-Avoidance Assist, the vehicle's basic braking performance will operate properly.
- During emergency braking, braking control by Forward Collision-Avoidance Assist will automatically cancel when the driver excessively depresses the accelerator pedal or sharply steers the vehicle.

# **CAUTION**


- Depending on the condition of the vehicle or pedestrian in front and the surroundings, the speed or the sensor's detection range to operate Forward Collision-Avoidance Assist may reduce, which may limit or disable the function. Forward Collision-Avoidance Assist may only warn the driver, or it may not operate.
- Forward Collision-Avoidance Assist will operate under certain conditions by judging the risk level based on the condition of the oncoming vehicle, driving direction, speed and surroundings.
- Forward Collision-Avoidance Assist may be limited or disabled if the vehicle speed is too fast or the speed difference with the other vehicle or cyclist is large.

### *i* Information

- In a situation where collision is imminent, braking may be assisted by Forward Collision-Avoidance Assist when braking is insufficient by the driver.
- The images and colors in the cluster may differ depending on the cluster type or theme selected from the instrument cluster.

#### Forward Collision-Avoidance Assist malfunction and limitations


#### Forward Collision-Avoidance Assist malfunction



OTM070094N

When Forward Collision-Avoidance Assist is not working properly, the 'Check Forward Safety system' warning message will appear, and the A and se warning lights will illuminate on the cluster. We recommend that the vehicle be inspected by a HYUNDAI authorised repairer.

#### Forward Collision-Avoidance Assist disabled



When the front windscreen where the front view camera is located or the sensor is covered with foreign material, such as snow or rain, it can reduce the detecting performance and temporarily limit or disable Forward Collision-Avoidance Assist.

If this occurs the 'Forward Safety system' disabled. Camera obscured' warning message, and the A and se warning lights will illuminate on the cluster.

Forward Collision-Avoidance Assist will operate properly when such snow, rain or foreign material is removed.

If Forward Collision-Avoidance Assist does not operate properly after obstruction (snow, rain, or foreign material) is removed, we recommend that the vehicle be inspected by a HYUNDAI authorised repairer.

## **!** WARNING

- Even though the warning message or warning light does not appear on the cluster, Forward Collision-Avoidance Assist may not properly operate.
- · Forward Collision-Avoidance Assist may not properly operate in an area (for example, open terrain), where any objects are not detected after turning ON the engine.
- · If the vehicle is turned off and restarted while the camera is blocked or malfunctioning, the condition is maintained. Therefore, Forward Collision-Avoidance Assist may not operate properly.

#### Limitations of Forward Collision-Avoidance Assist

Forward Collision-Avoidance Assist may not operate properly, or it may operate unexpectedly under the following circumstances:

- The detecting sensor or the surroundings are contaminated or damaged
- The temperature around the front view camera is high or low
- The camera lens is contaminated due to tinted, filmed or coated windscreen, damaged glass, or stuck of foreign material (sticker, bug, etc.) on the glass
- Moisture is not removed or frozen on the windscreen
- Washer fluid is continuously sprayed, or the wiper is on
- Driving in heavy rain or snow, or thick fog
- The field of view of the front view camera is obstructed by sun glare
- Street light or light from an oncoming vehicle is reflected on the wet road surface, such as a puddle on the road
- An object is placed on the dashboard
- Your vehicle is being towed
- · The surrounding is very bright
- The surrounding is very dark, such as in a tunnel, etc.
- The brightness changes suddenly, for example when entering or exiting a tunnel
- The headlights outside is low, and the headlights are not on or are not bright

- Driving through steam, smoke or shadow
- Only part of the vehicle or pedestrian is detected
- The vehicle in front is a bus, heavy truck, truck with an unusually shaped cargo, trailer, etc.
- The vehicle in front has no tail lights, tail lights are located unusually, etc.
- The brightness outside is low, and the tail lights are not on or are not bright
- The rear of the front vehicle is small or the vehicle does not look normal, such as when the vehicle is tilted, overturned, or the side of the vehicle is visible, etc.
- The front vehicle's ground clearance is low or high
- A vehicle or pedestrian suddenly cuts in front
- The vehicle in front is detected late
- The vehicle in front is suddenly blocked by an obstacle
- The vehicle in front suddenly changes lane or suddenly reduces speed
- The vehicle in front is bent out of shape
- The vehicle in front is covered with snow

- You are departing or returning to the lane
- · Unstable driving
- You are on a roundabout and the vehicle in front is not detected
- You are continuously driving in a circle
- The vehicle in front has an unusual shape
- The vehicle in front is driving uphill or downhill
- The pedestrian is not fully detected, for example, if the pedestrian is leaning over or is not fully walking upright
- The pedestrian is wearing clothing or equipment that makes it difficult to detect as a pedestrian



The illustration above shows the image the front view camera will detect as a vehicle, a pedestrian or a cyclist.


- The pedestrian in front is moving very quickly
- The pedestrian in front is short or is posing a low posture
- The pedestrian in front has impaired mobility
- The pedestrian in front is moving intersected with the driving direction

- There is a group of pedestrians or a large crowd in front
- The pedestrian is wearing clothing that easily blends into the background, making it difficult to detect
- The pedestrian is difficult to distinguish from the similarly shaped structure in the surroundings
- You are driving by a pedestrian, cyclist, traffic sign, structure, etc. near the intersection
- Driving in a parking lot
- Driving through a tollgate, construction area, unpaved road, partial paved road, uneven road, speed bumps, etc.
- Driving on an incline road, curved road, etc.
- Driving through a roadside with trees or streetlights
- The adverse road conditions cause excessive vehicle vibrations whilst driving
- Your vehicle height is low or high due to heavy loads, abnormal tyre pressure, etc.
- Driving through a narrow road where trees or grass are overgrown
- There is interference by electromagnetic waves, such as driving in an area with strong radio waves or electrical noise




· Driving on a curved road





Forward Collision-Avoidance Assist may not detect other vehicle, a pedestrian or a cyclist in front of you on curved roads adversely affecting the performance of the sensors. This may result in no warning or braking assist when necessary.

When driving on a curve, you must maintain a safe braking distance, and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.



Forward Collision-Avoidance Assist may detect a vehicle, a pedestrian or a cyclist in the next lane or outside the lane when driving on a curved road.

If this occurs, Forward Collision-Avoidance Assist may unnecessarily warn the driver and control the brake. Always check the traffic conditions around the vehicle.

#### · Driving on an inclined road






Forward Collision-Avoidance Assist may not detect other vehicle, a pedestrian or a cyclist in front of you whilst driving uphill or downhill adversely affecting the performance of the sensors.

This may result in unnecessary warning or braking assist, or no warning or braking assist when necessary.

Also, vehicle speed may rapidly decrease when a vehicle, a pedestrian or a cyclist ahead is suddenly detected.

Always have your eyes on the road whilst driving uphill or downhill and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.


#### · Changing lanes



[A]: Your vehicle,

[B]: Lane changing vehicle

When a vehicle moves into your lane from an adjacent lane, it cannot be detected by the sensor until it is in the sensor's detection range. Forward Collision-Avoidance Assist may not immediately detect the vehicle when the vehicle changes lanes abruptly. In this case, you must maintain a safe braking distance, and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.



[A]: Your vehicle,

[B]: Lane changing vehicle,

[C]: Same lane vehicle

When a vehicle in front of you merges out of the lane, Forward Collision-Avoidance Assist may not immediately detect the vehicle that is now in front of you.

In this case, you must maintain a safe braking distance, and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain a safe distance.

#### · Detecting vehicle



If the vehicle in front of you has cargo that extends rearward from the cab, or when the vehicle in front of you has higher ground clearance, additional special attention is required. Forward Collision-Avoidance Assist may not be able to detect the cargo extending from the vehicle. In these instances, you must maintain a safe braking distance from the rearmost object, and if necessary, steer your vehicle and depress the brake pedal to reduce your driving speed in order to maintain distance.

# **MARNING**

- When you are towing a trailer or another vehicle, turn off Forward Collision-Avoidance Assist for safety reasons.
- Forward Collision-Avoidance Assist may operate if objects that are similar in shape or characteristics to vehicle, a pedestrian or a cyclist are detected.
- Forward Collision-Avoidance Assist does not operate on bicycles, motorcycles, or smaller wheeled objects, such as luggage bags, shopping carts, or strollers.
- Forward Collision-Avoidance Assist may not operate properly if interfered by strong electromagnetic waves.
- Forward Collision-Avoidance Assist may not operate for 15 seconds after the vehicle is started, or the front view camera is initialized.

#### LANE KEEPING ASSIST (LKA) (IF EQUIPPED)

Whilst driving over a certain speed, Lane Keeping Assist detects lane markings (or road edges) and may warn you if your vehicle leaves the lane without using the turn signal and may assist with steering to prevent your vehicle departing from its travel lane.

#### Detecting sensor



[1]: Front view camera

The front view camera is used as a detecting sensor to detect lane markings (or road edges).

Refer to the illustration above for the detailed location of the detecting sensor.



### **CAUTION**

For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

# Lane Keeping Assist settings Lane Safety



OAC3073057TU

With the engine on, select User settings > Driver assistance > Driving safety > Lane safety from the settings menu in the instrument cluster or Settings > Vehicle > Driver assistance > **Driving safety > Lane safety** from the Settings menu in the infotainment system to set whether to use each function. If Lane safety is selected, Lane Keeping Assist will automatically assist the driver's steering when lane departure is detected to help prevent the vehicle from moving out of its lane. If Lane safety is deselected, Lane Keeping Assist will turn off and the yellow indicator light will turn on the instrument cluster.



#### Information

When the vehicle is restarted, Lane Keeping Assist will always turn on

# **MARNING**

- Lane Keeping Assist does not control the steering wheel when the vehicle is driven in the middle of the lane.
- The driver should always be aware of the surroundings. If Lane Safety is deselected, Lane Keeping Assist cannot assist you.

#### Warning Methods



The Warning Methods can be set when the vehicle is in ON position.

- Warning volume: Select User settings > Driver assistance > Warning volume on the instrument cluster or Settings > Vehicle > Driver assistance > Warning methods > Warning volume on the infotainment system, and adjust the warning volume.
- Driving safety priority: Select Settings > Vehicle > Driver assistance
   > Warning methods > Driving safety priority on the infotainment system, the audio volume is reduced whilst a warning sounds.

# *i* Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- Warning Method will maintain its last setting even if the vehicle is restarted.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

# Lane Keeping Assist Operation Turning Lane Keeping Assist



Whenever the vehicle is turned off and on, Lane Keeping Assist will always turn on and the gray (A) indicator light will appear on the cluster.

When Lane Keeping Assist is on, press and hold the Lane Driving Assist (/⊕\) button to turn off the function.

When Lane Keeping Assist is off, the ( ) indicator turns yellow.


### *i* Information

- When Lane Keeping Assist is getting ready to operate, (/=\) indicator turns
- When Lane Keeping Assist is ready to operate, (A) indicator turns green on the instrument cluster.

#### Warning and control

Lane Keeping Assist will warn and control the vehicle with Lane Departure Warning and Lane Keeping Assist.

#### **Lane Departure Warning**



- To warn the driver that the vehicle is departing from the projected lane in front, the green indicator light will blink on the cluster, the lane line will blink on the cluster depending on which direction the vehicle is veering, and an audible warning will sound.
- Lane Departure Warning will operate when your vehicle speed is between about 40-120 mph (60-200 km/h).

#### **Lane Keeping Assist**

- To warn the driver that the vehicle is departing from the projected lane in front, the green indicator light will blink on the instrument cluster, and the steering wheel will make adjustments to keep the vehicle inside the lane.
- Lane Keeping Assist will operate when your vehicle speed is between about 40-120 mph (60-200 km/h).

#### Hands-off warning



OAC3073061TU

If the driver takes their hands off the steering wheel for several seconds, the 'Keep hands on the steering wheel' warning message will appear on the instrument cluster, and an audible warning will sound in stages.

#### WARNING

- · The steering wheel may not be assisted if the steering wheel is held very tight or the steering wheel is steered over a certain dearee.
- · Lane Keeping Assist does not operate at all times. It is the responsibility of the driver to safely steer the vehicle and to maintain the vehicle in its lane.
- The hands-off warning message may appear late depending on road conditions. Always have your hands on the steering wheel whilst driving.
- · If the steering wheel is held very lightly, the hands-off warning message may appear because Lane Keeping Assist may not recognize that the driver has their hands on the steering wheel.
- · If you attach objects to the steering wheel, the hands-off warning may not work properly.

## *i* Information

- Even though the steering is assisted by Lane Keeping Assist, the drivermay control the steering wheel.
- The steering wheel may feel heavier or lighter when the steering wheel is assisted by Lane Keeping Assist than when it is not.
- When lane markings (or road edges) are detected, the lane lines on the instrument cluster will change from grev to white.





OAC3073062TU

- The images and colors in the instrument cluster may differ depending on the instrument cluster type or theme selected from the instrumentcluster.
- · For more information on instrument cluster settings, refer to the "Cluster Display Control" section in chapter 4.

# Lane Keeping Assist malfunction and limitations

# Lane Keeping Assist malfunction



OKS072055L

When Lane Keeping Assist is not working properly, the 'Check Lane Safety system' warning message will appear, the master (A) warning light, and the yellow (A) indicator light will illuminate on the cluster. If this occurs, we recommend that the vehicle be inspected by a HYUNDAI authorised repairer.

#### Lane Keeping Assist disabled



OAC3073102TU

When the front windscreen where the front view camera is located, or sensor is covered with foreign material, such as snow or rain, it can reduce the detecting performance and temporarily limit or disable Lane Keeping Assist.

If this occurs, the 'Lane Keeping Assist system disabled. Camera obscured' warning message and master (1) light or Lane Safety warning light (1) will appear on the instrument cluster.

Lane Keeping Assist will operate properly when snow, rain or foreign material is removed.

If Lane Keeping Assist does not operate properly after it is removed, we recommend that the vehicle be inspected by a HYUNDAI authorised repairer.



- Even though the warning message or warning light does not appear on the instrument cluster, Lane Keeping Assist may not properly operate.
- If the vehicle is turned off and restarted whilst the camera is blocked or malfunctioned, the condition is maintained. Therefore, Lane Keeping Assist may not operate properly.

# Limitations of Lane Keeping Assist

Lane Keeping Assist may not operate properly or may operate unexpectedly under the following circumstances:

- The lane is contaminated or difficult to detect because:
  - The lane markings (or road edge) are covered with rain, snow, dirt, oil, etc.
  - The colour of the lane marking (or road edge) is not distinguishable from the road
  - There are markings (or road edges) on the road near the lane or the markings (or road edges) on the road look similar to the lane markings (or road edge)
  - The lane marking (or road edge) is indistinct or damaged
  - The shadow is on the lane marking (or road edge) by a median strip, trees, guardrail, noise barriers, etc.
- The lane number increases or decreases, or the lane markings (or road edges) are crossing
- There are more than two lane markings (or road edges) on the road
- The lane markings (or road edges) are complicated or a structure substitutes for the lines, such as a construction area
- There are road markings, such as zigzag lanes, crosswalk markings and road signs
- The lane suddenly disappears, such as at the intersection
- The lane (or road width) is very wide or narrow

- There is a road edge without a lane
- There is a boundary structure in the roadway, such as a tollbooth, sidewalk, kerb, etc.
- The distance to the front vehicle is extremely short or the vehicle in front is covering the lane marking (or road edge)

# *i* Information

For more information on the limitations of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in chapter 7.

# **⚠** WARNING

Take the following precautions when using Lane Keeping Assist:

- The driver has the responsibility to safely drive and control the vehicle. Do not solely rely on Lane Keeping Assist and drive dangerously.
- The operation of Lane Keeping Assist can be cancelled or not work properly depending on road conditions and surroundings. Always be cautious whilst driving.
- Refer to the "Limitations of Lane Keeping Assist" if the lane is not detected properly.
- When you are towing a trailer or another vehicle, we recommend that Lane Keeping Assist is turned off due to safety reasons.
- If the vehicle is driven at high speed, the steering wheel will not be controlled. The driver must always follow the speed limit when using Lane Keeping Assist.
- If any other function's warning message is displayed or audible warning is generated, Lane Keeping Assist warning message may not be displayed and audible warning may not be generated.
- You may not hear the warning sound of Lane Keeping Assist if the surrounding is noisy.
- If you attach objects to the steering wheel, steering may not be assisted properly.
- Lane Keeping Assist may not operate for 15 seconds after the vehicle is started, or the front view camera is initialized.

- Lane Keeping Assist will not operate when:
  - The turn signal or hazard warning flasher is turned on
  - The vehicle is not driven in the centre of the lane when Lane Keeping Assist is turned on or right after changing a lane
  - ESC (Electronic Stability Control) or VSM (Vehicle Stability Management) is activated
  - The vehicle is driven on a sharp curve
  - Vehicle speed is below 35 mph (55 km/h) or above 130 mph (210 km/h)
  - The vehicle makes sudden lane changes
  - The vehicle brakes suddenly
- Driving stability may decrease when the vehicle is overloaded or the weight distribution is uneven.
   This may degrade the Lane Keeping Assist performance.

#### MANUAL SPEED LIMIT ASSIST (MSLA) (IF EQUIPPED)



OAC3073097R

- (1) Manual Speed Limit Assist enabled indicator
- (2) Set speed

You can set the speed limit when you do not want to drive over a specific speed.

If you drive over the preset speed limit, Manual Speed Limit Assist operates (set speed limit will blink and chime will sound) until the vehicle speed returns within the speed limit.

# **Manual Speed Limit Assist operation**

Setting speed limit



1. Press and hold Driving Assist ((Co)) button at the desired speed. The Speed Limit ((S) LIMIT) indicator will illuminate on the instrument cluster.





Push the + switch up or - switch down, and release it at the desired speed.

Push the + switch up or - switch down and hold it. The speed will increase or decrease to the nearest multiple of ten (multiple of five in mph) at first, and then increase or decrease by 5 mph (10 km/h).



3. The set speed limit will be displayed on the instrument cluster.

If you would like to drive over the preset speed limit, depress the accelerator pedal beyond the pressure point to activate the kickdown function.

The set speed limit will blink and chime will sound until you return the vehicle speed within the speed limit.

## *i* Information

The available maximum speed may differ depending on the vehicle. The set speed cannot exceed the maximum speed.

# Temporarily pausing Manual Speed Limit Assist



Press the **IID** switch to temporarily pause the set speed limit. The set speed limit will turn off but the Speed Limit (**S**I\_IMIT) indicator will stay on.

# Resuming Manual Speed Limit Assist



To resume Manual Speed Limit Assist after the function was paused, operate the +, -, II 5 switch.

If you push the + switch up or - switch down, vehicle speed will be set to the current speed on the instrument cluster.

If you press the **IID** switch, vehicle speed will resume to the preset speed.

# Turning off Manual Speed Limit Assist



Press the Driving Assist ( $\bigcirc$ n) button to turn Manual Speed Limit Assist off. The Speed Limit ( $\bigcirc$ 1 indicator will go off.

# **MARNING**

Take the following precautions when using Manual Speed Limit Assist:

- Always set the vehicle speed under the speed limit in your state.
- Keep Manual Speed Limit Assist off when the function is not in use, to avoid inadvertently setting a speed. Check that the Speed Limit ((S)(LIMIT)) indicator is off.
- Manual Speed Limit Assist does not substitute for proper and safe driving. It is the responsibility of the driver to always drive safely and be aware of unexpected and sudden situations. Pay attention to the road conditions at all times.

#### **INTELLIGENT SPEED LIMIT ASSIST (ISLA) (IF EQUIPPED)**

Intelligent Speed Limit Assist uses information from the detected road sign and navigation system to inform the driver of the speed limit of the current road. Also, Intelligent Speed Limit Assist helps the driver to maintain within the speed limit of the road.

### **CAUTION**

- Intelligent Speed Limit Assist may not operate properly if the function is used in other countries.
- If a navigation is applied to your vehicle, the navigation needs to be regularly updated for Intelligent Speed Limit Assist to operate properly.
- The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

#### Detecting sensor



[1]: Front view camera

Refer to the picture above for the detailed location of the detecting sensor.



For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

# **Intelligent Speed Limit Assist settings**

#### Speed Limit



OAC3073064TU

With the engine on, select or deselect User settings > Driver assistance > Speed limit from the settings menu in the instrument cluster or Settings > Vehicle > Driver assistance > Speed limit from the Settings menu in the infotainment system to set whether to use each function.

- Select country: when the navigation system is not available, you can manually select the country to set the speed limit.
- If Speed limit assist is selected, Intelligent Speed Limit Assist will inform the driver of speed limit and additional road signs. In addition, Intelligent Speed Limit Assist will inform the driver to change set speed of Manual Speed Limit Assist to help the driver stay within the speed limit.
- If Speed limit warning is selected, Intelligent Speed Limit Assist will inform the driver of speed limit. In addition, Intelligent Speed Limit Assist will warn the driver when the vehicle is driven faster than the speed limit.

- Speed Limit information: Provides information on speed limits and additional sign without audible warning.
- If **Off** is selected, Intelligent Speed Limit Assist will turn off. The (—) warning light is displayed.

# **MARNING**

For your safety, only change the settings after parking the vehicle at a safe location.

#### Warning methods



The Warning methods can be set when the vehicle is in ON position.

Warning volume: Select User settings > Driver assistance > Warning volume on the instrument cluster or Settings > Vehicle > Driver assistance > Warning methods > Warning volume on the infotainment system, and adjust the warning volume.

## *i* Information

- If you change the warning volume, the warning volume of other driver assistance system may change.
- If the vehicle is restarted, warning volume will maintain the last setting.
- There may be no setting menu depending on the vehicle specification.

## *i* Information

- Press and hold the Mute (\*\*) button on the steering wheel to change the speed limit settings from "Speed limit assist" (or "Speed limit warning") to "Speed limit information", or from "Speed limit information" (or "Off") to "Speed limit information".
- This function may not be available depending on the infotainment software version.

### **MARNING**

For your safety, only change the settings after parking the vehicle at a safe location.

# Intelligent Speed Limit Assist operation

#### Warning and control

Intelligent Speed Limit Assist will warn and control the vehicle by "Displaying speed limit", "Warning overspeed" and "Changing set speed".



OAC3073066TU

Displaying speed limit
Speed limit information is displayed on
the instrument cluster.

# *i* Information

- If speed limit information of the road cannot be recognized, '---' sign will be displayed. Please refer to "Limitations of Intelligent Speed Limit Assist" if the road signs are difficult to recognize.
- Intelligent Speed Limit Assist provides additional road sign information in addition to speed limit. The additional road sign information provided may vary according to your country.
- Supplementary sign displayed under the speed limit or overtaking restriction sign means the conditions under which the signs must be followed. If the supplementary sign is not recognized, it will be displayed as blank.
- The images and colors in the instrument cluster may differ depending on the cluster type or theme selected from the instrument cluster.



#### Warning overspeed

When driving at a speed higher than the displayed speed limit, the red speed limit indicator will blink and warning sounds.



#### Changing set speed

If the speed limit of the road changes during the operation of Manual Speed Limit Assist, an arrow in the direction of up or down is displayed to inform the driver that the set speed needs to be changed. At this time, the driver can change the set speed according to the speed limit by using the + or - switch on the steering wheel.



# **Set Speed Auto Change (Navigation equipped)**

Manual Speed Limit Assist assists the vehicle to adjust its set speed according to the speed limit. When the set speed is set as same as the speed limit, the vehicle automatically adjusts its set speed if the speed limit changes. The function operates on the road which has a speed limit of 45 mph (70 km/h) or higher. When the function is active, the set speed on the instrument cluster appears in green.

# **MARNING**


- Even after changing the set speed according to the speed limit of the road, the vehicle can still be driven over the speed limit. If necessary, depress the brake pedal to reduce your driving speed.
- If the speed limit of the road is under 20 mph (30 km/h), the Changing set speed function will not work.
- Intelligent Speed Limit Assist operates using the speed units in the instrument cluster set by the driver. If the speed unit is not set to the speed unit used in your country, Intelligent Speed Limit Assist may not operate properly.

# *i* Information

• For more information on Manual Speed Limit Assist operation, refer to the "Manual Speed Limit Assist (MSLA)" section in this chapter.


# Intelligent Speed Limit Assist malfunction and limitations

# Intelligent Speed Limit Assist malfunction



When Intelligent Speed Limit Assist is not working properly, the 'Check Speed Limit system' warning message will appear on the cluster for several seconds, and the master ((A)) warning light and ((C)) warning light will illuminate on the instrument cluster. If this occurs, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

# Intelligent Speed Limit Assist disabled



OTM070226L

When the front windscreen where the front view camera is located is covered with foreign material, such as snow or rain, it can reduce the detecting performance and temporarily limit or disable Intelligent Speed Limit Assist. If this occurs, the 'Speed Limit system disabled. Camera obscured' warning message and (---) warning light will appear on the instrument cluster.

Intelligent Speed Limit Assist will operate properly when snow, rain or foreign material is removed.

If Intelligent Speed Limit Assist does not operate properly after it is removed, we recommend that you have the vehicle inspected by a HYUNDAI authorised repairer.

# **MARNING**

- Even though the warning message or warning light does not appear on the cluster, Intelligent Speed Limit Assist may not properly operate.
- If the vehicle is turned off and restarted whilst the camera is blocked or malfunctioned, the condition is maintained. Therefore, Intelligent Speed Limit Assist may not operate properly.

#### Limitations of Intelligent Speed Limit Assist

Intelligent Speed Limit Assist may not operate properly, or it may operate unexpectedly under the following circumstances:

- The road sign is contaminated or indistinguishable
- The road sign is difficult to see due to bad weather, such as rain, snow, fog, etc.
- The road sign is not clear or damaged
- The road sign is partially obscured by surrounding objects or shadow
- The road signs do not conform to the standard
- The text or picture on the road sign is different from the standard
- The road sign is installed between the main line and the exit road or between diverging roads
- There is no conditional road signs on the road sign located on the exit road
- · A sign is attached to another vehicle

- The distance between the vehicle and the road signs is too far
- The vehicle encounters illuminant road signs
- Intelligent Speed Limit Assist incorrectly recognizes numbers or pictures in the street signs or other signs as the speed limit
- A road sign near the road you are driving is detected
- The other traffic sign or signboards are alongside the road sign
- Multiple signs are installed close together
- The minimum speed limit sign is misrecognized
- The minimum speed limit sign is on the road
- The brightness changes suddenly, for example when entering or exiting a tunnel or passing under a bridge
- Headlights are not used or the brightness of the headlights are weak at night or in the tunnel
- Road signs are difficult to recognize due to the reflection of sunlight, street lights, or oncoming vehicles
- The navigation information or GPS information contain errors.
- The driver does not follow the guide of the navigation.
- The driver is driving on a new road that is not in the navigation system yet.
- The field of view of the front view camera is obstructed by sun glare
- Driving on a road that is sharply curved or continuously curved
- Driving through speed bumps, or driving up and down or left to right on steep inclines

- · The vehicle is shaking heavily
- Driving on a newly opened road
- The navigation software is being updated whilst driving
- The navigation is restarted whilst driving
- Driving on a road under construction.

# **MARNING**

- Intelligent Speed Limit Assist is a supplemental function that helps the driver to comply with the speed limit on the road, and may not display the correct speed limit or control the driving speed properly.
- Always set the vehicle speed to the speed limit in your area.
- Intelligent Speed Limit Assist may not operate for 15 seconds after the engine is started, or the front camera is initialized.

# *i* Information

For more information on the limitations of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

### **DRIVER ATTENTION WARNING (DAW) (IF EQUIPPED)**

#### **Inattentive Driving Warning**

Driver Attention Warning monitors your driving pattern whilst driving. When the driver's attention level is below a certain level. Driver Attention Warning recommends a break to help with safe drivina.

#### Leading Vehicle Departure Alert function

Leading Vehicle Departure Alert function will inform the driver when a detected vehicle in front departs.

#### Detecting sensor



[1]: Front view camera

The front view camera is used as a detecting sensor to help detect driving patterns and front vehicle departure whilst vehicle is being driven.

Refer to the illustration above for the detailed location of the detecting sensor.


### **CAUTION**

Always keep the front view camera in good condition to maintain optimal performance of Driver Attention Warning.

For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

#### **Driver Attention Warning set**tings

#### Leading Vehicle Departure Alert



OAC3073051TU

With the engine on, select or deselect User settings > Driver assistance > DAW (Driver Attention Warning) from the Settings menu in the instrument cluster or **Settings** > **Vehicle** > **Driver** assistance > DAW (Driver Attention Warning) from the Settings menu in the infotainment system to set whether to use the function.

 If Leading vehicle departure alert is selected, the function will inform the driver when a detected vehicle in front departs from a stop.

#### **Driver Attention Warning** operation

#### Inattentive Driving Warning

The basic function of Driver Attention Warning is to warn the driver 'Consider taking a break'.

#### Consider taking a break



- The 'Consider taking a break' message and Driver Attention Warning light (">) will appear on the cluster and an audible warning will sound to suggest that the driver take a break, when the driver's attention level is below a certain level.
- · Driver Attention Warning will not suggest a break when the total driving time is shorter than 4 minutes or 4 minutes has not passed after the last break was suggested.
- A break is suggested when your vehicle speed is between about 0-120 mph (0-200 km/h).



For your safety, only change the Settings after parking the vehicle at a safe location.

### ! CAUTION

Driver Attention Warning may suggest a break depending on the driver's driving pattern or habits, even if the driver doesn't feel fatiqued.

Driver Attention Warning is a supplemental function and may not be able to determine whether the driver is inattentive

A driver who feels fatigued should take a break at a safe location, even though there is no break suggestion by Driver Attention Warning.



#### Information

For more information on instrument cluster settings, refer to the "Cluster Display" section in chapter 4.

# Leading Vehicle Departure Alert function



OAC3073071TU

When a detected vehicle in front departs from a stop, Leading Vehicle Departure Alert will inform the driver by displaying the 'Leading vehicle is driving on' message on the instrument cluster and an audible warning will sound.

### **WARNING**

- If any other function's warning message is displayed or audible warning is generated, Leading Vehicle Departure Alert's warning message may not be displayed and audible warning may not be generated.
- The driver has the responsibility to safely drive and control the vehicle.

### **CAUTION**

- Leading Vehicle Departure Alert is a supplemental function and may not alert the driver whenever the front vehicle departs from a stop.
- Always check the front of the vehicle and road conditions before departure.

# *i* Information

The images and colors in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings.

#### **Driver Attention Warning malfunction and limitations**

#### Driver Attention Warning malfunction



When Driver Attention Warning is not working properly, the 'Check Inattentive Driving Warning system' warning message will appear on the instrument cluster for several seconds, and the master warning light and Driver Attention Warning light ( ) will illuminate on the instrument cluster. If this occurs, we recommend that the vehicle be inspected by a HYUNDAI authorised repairer.

# Driver Attention Warning disabled



OAC3073103TU

When the front windscreen where the front view camera is located is covered with foreign material, such as snow or rain, it can reduce the detecting performance and temporarily limit or disable Driver Attention Warning. If this occurs, the 'Inattentive Driving Warning disabled. Camera obscured' warning message, master (小) warning light and Driver Attention Warning light (宀) will appear on the instrument cluster. Driver Attention Warning will operate properly when snow, rain or foreign material is removed. If Driver Attention Warning does not operate properly after it is removed, we recommend to have the vehicle inspected by a HYUNDAI authorised repairer.

### **!** WARNING

- Driver Attention Warning may not properly operate in an area (for example, open terrain) where any objects are not detected right after turning ON the vehicle.
- If the vehicle is turned off and restarted while the camera is blocked or malfunctioned, the condition is maintained. Therefore, Driver Attention Warning may not operate properly.


# Limitations of Driver Attention Warning

Driver Attention Warning may not work properly in the following situations:


- The vehicle is driven violently
- The vehicle intentionally crosses over lanes frequently
- The vehicle is controlled by Driver Assistance function, such as Lane Keeping Assist

# Leading Vehicle Departure Alert function

· When the vehicle cuts in




OAC3073088TU



[A]: Your vehicle, [B]: Front vehicle

If a vehicle cuts in front of your vehicle, Leading Departure Alert may not operate properly.


When the vehicle ahead sharply steers



[A]: Your vehicle, [B]: Front vehicle

If the vehicle in front makes a sharp turn, such as to turn left or right or make a U-turn, etc., Leading Vehicle Departure Alert may not operate properly.

When the vehicle ahead abruptly departures




If the vehicle in front abruptly departures, Leading Vehicle Departure Alert may not operate properly.

 When a pedestrian or bicycle is between you and the vehicle ahead




If there is a pedestrian(s) or bicycle(s) in between you and the vehicle in front, Leading Vehicle Departure Alert may not operate properly.

· When in a parking lot



If a vehicle parked in front drives away from you, Leading Vehicle Departure Alert may alert you that the parked vehicle is driving away.

When driving at a tollgate or intersection, etc.



If you pass a tollbooth or intersection with lots of vehicles or you drive where lanes are merged or divided frequently, Leading Vehicle Departure Alert may not operate properly.


### **MARNING**

Driver Attention Warning may not operate for 15 seconds after the vehicle is started or function are initialized.

## *i* Information

For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

### **CRUISE CONTROL (CC) (IF EQUIPPED)**



- (1) Cruise indicator
- (2) Set speed

Cruise Control will allow you to drive at speeds above 20 mph (30 km/h) without depressing the accelerator pedal.

### **Cruise Control operation**

### Setting set speed

 Accelerate to the desired speed, which must be more than 20 mph (30 km/h).



- 2. Press the Driving Assist (Co) button at the desired speed. The set speed and Cruise (COCRUSE) indicator will illuminate on the instrument cluster.
- 3. Release the accelerator pedal.

  Vehicle speed will maintain the set speed even when the accelerator pedal is not depressed.

## *i* Information

The vehicle may slightly slow down or speed up whilst driving uphill or downhill.

#### Increasing set speed



- Push the + switch up and release it immediately. The set speed will increase by 1 mph (1 km/h) each time the switch is operated in this manner.
- Push the + switch up and hold it whilst monitoring the set speed on the instrument cluster. The set speed will increase to the nearest multiple of ten (multiple of five in mph) at first, and then increase by 5 mph (10 km/h) each time the switch is operated in this manner

Release the switch when the desired speed is shown and the vehicle will accelerate to that speed.

### Information

The available maximum speed may differ depending on the vehicle. The set speed cannot exceed the maximum speed.

### Decreasing set speed



OAC3073048TU

- · Push the switch down and release it immediately. The set speed will decrease by 1 mph (1 km/h) each time the switch is operated in this manner
- · Push the switch down and hold it whilst monitoring the set speed on the instrument cluster. The set speed will decrease to the nearest multiple of ten (multiple of five in mph) at first. and then decrease by 5 mph (10 km/h) each time the switch is operated in this manner. Release the switch at the speed you want to maintain.

### Accelerating temporarily

If you want to speed up temporarily when Cruise Control is on, depress the accelerator pedal.

To return to the set speed, take your foot off the accelerator pedal.

If you push the + switch up or - switch down at increased speed, the set speed will be set to the current increased speed.

## Temporarily pausing Cruise Control



Cruise Control will be paused when:


- · Depressing the brake pedal.
- Pressing the IID button.
- Shifting the gear to N (Neutral).
- Decreasing vehicle speed to less than about 20 mph (30 km/h).
- ESC (Electronic Stability Control) is operating.
- Downshifting to 2nd gear when in Manual Shift mode.

The set speed will turn off but the Cruise (\*\*)CRUISE) indicator will stay on.

### NOTICE

If Cruise Control pauses during a situation that is not mentioned, we recommend that the vehicle be inspected by a HYUNDAI authorised repairer.

### Resuming Cruise Control



Operate the +, - switch or **II** button.

If you push the + switch up or - switch

down, vehicle speed will be set to the current speed on the instrument cluster.

If you press the II  $\supset$  button, vehicle The vehicle will resume to the preset speed. The vehicle speed must be above 20 mph (30 km/h) for Cruise Control to resume.



Check the driving condition before using the property button. Driving speed may sharply increase or decrease when you press the property button.

### Turning off Cruise Control



Press the Driving Assist (Co) button to turn Cruise Control off. The Cruise ( CRUISE) indicator will go off.

Always press the Driving Assist button to turn Cruise Control off when not in use.



If your vehicle is equipped with Manual Speed Limit Assist, press and hold the Driving Assist ( ) button to turn off Cruise Control. However, Manual Speed Limit Assist will turn on.

## **!** WARNING

Take the following precautions when using Cruise Control:

- Always set the vehicle speed under the speed limit in your state.
- Keep Cruise Control off when the function is not in use, to avoid inadvertently setting a speed. Check that the Cruise (GCRUISE) indicator is off.
- · Cruise Control does not substitute for proper and safe driving. It is the responsibility of the driver to always drive safely and should always be aware of unexpected and sudden situations from occurrina.
- Always drive cautiously to prevent unexpected and sudden situations from occurring. Pay attention to the road conditions at all times.
- Do not use Cruise Control when it may be unsafe to keep the vehicle at a constant speed:
  - When driving in heavy traffic, or when traffic conditions make it difficult to drive at a constant speed
  - When driving on rainy, icy, or snow-covered roads
  - When driving on hilly or windy roads
  - When driving in windy areas
  - When driving with limited view (possibly due to bad weather. such as fog, snow, rain and sandstorm)
- · Do not use Cruise Control when towing a trailer.

### LANE FOLLOWING ASSIST (LFA) (IF EQUIPPED)

Lane Following Assist detects lane markings and/or a vehicle ahead on the road, and centre vour vehicle in the lane

### Detecting sensor



[1]: Front view camera

The front view camera is used as a detecting sensor to help detect lane markings and vehicles in front.

Refer to the illustration above for the detailed location of the detecting sensor.



### ! CAUTION

For more information on the precautions of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

### **Lane Following Assist Settings** Warning Methods



The Warning Methods can be set when the vehicle is in ON position.

- · Warning volume: Select User settings > Driver assistance > Warning volume on the instrument cluster or Settings > Vehicle > Driver assistance > Warning methods > Warning volume on the infotainment system, and adjust the warning volume.
- · Driving safety priority: Select Settings > Vehicle > Driver assistance > Warning methods > Driving safety priority on the infotainment system, the audio volume is reduced whilst a warning sounds.

### Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- · Warning Method will maintain its last setting even if the vehicle is restarted.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

### **Turning Lane Following Assist** On/Off



With the engine on, short press the Lane Driving Assist button located on the steering wheel to turn on Lane Following Assist.

The grey or green (A) indicator light will illuminate on the instrument cluster. Press the button again to turn off the function.

### Lane Following Assist



OAC3073072TU

If the vehicle ahead and/or both lane markings are detected and your vehicle speed is below 120 mph (200 km/h), the green  $\bigcirc$  indicator light illuminates on the instrument cluster, and Lane Following Assist will help centre the vehicle in the lane by assisting the steering wheel.

## ! CAUTION

When the steering wheel is not assisted, the white (a) indicator light blinks and changes to grey.

### Hands-off warning




OAC3073061TU

If the driver takes their hands off the steering wheel for several seconds, the 'Keep hands on the steering wheel' warning message will appear and an audible warning will sound in stages.

First stage : Warning message

Second stage: Warning message (red steering wheel) and

audible warning



B0356EA01


If the driver still does not have their hands on the steering wheel after the hands-off warning, the 'LFA (Lane Following Assist) cancelled' warning message will appear and Lane Following Assist will be automatically cancelled.

## **MARNING**

- The steering wheel may not be assisted if the steering wheel is held very tight or the steering wheel is steered over a certain degree.
- Lane Following Assist does not operate at all times. It is the responsibility of the driver to safely steer the vehicle and to maintain the vehicle in its lane.
- The hands-off warning message may appear late depending on road conditions. Always have your hands on the steering wheel whilst driving.
- If the steering wheel is held very lightly the hands-off warning message may appear because the function may not recognize that the driver has their hands on the steering wheel.
- If you attach objects to the steering wheel, the hands-off warning may not work properly.

## *i* Information

- For more information on instrument cluster settings, refer to the "Cluster Display Control" section in chapter 4.
- When both lane markings are detected, the lane lines on the instrument cluster will change from grey to white.



- The images and colors in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings menu.
- If lane markings are not detected, steering wheel control by Lane Following Assist can be limited depending on whether a vehicle is in front or the driving conditions of the vehicle.
- Even though the steering is assisted by Lane Following Assist, the driver may control the steering wheel.
- The steering wheel may feel heavier or lighter when the steering wheel is assisted by Lane Following Assist than when it is not.

### Lane Following Assist malfunction and limitations

## Lane Following Assist malfunction



When Lane Following Assist is not working properly, the 'Check LFA (Lane Following Assist) system' warning message will appear on the instrument cluster, for several seconds, and the master warning light will illuminate on the instrument cluster. If this occurs, we recommend that the vehicle be inspected by a HYUNDAI authorised repairer.

## Limitations of Lane Following Assist

For more information on Lane Following Assist's limitations, refer to the "Lane Keeping Assist (LKA)" section in this chapter.

## *i* Information

For more information on Lane Following Assist precautions, refer to the "Lane Keeping Assist (LKA)" section in this chapter.

## **MARNING**

- For more information on Lane Following Assist warnings, refer to the warnings of "Lane Keeping Assist malfunction and limitations" section in this chapter.
- Driving stability may decrease when the vehicle is overloaded or the weight distribution is uneven.
   This may degrade the Lane Following Assist performance.

### **REAR VIEW MONITOR (RVM) (IF EQUIPPED)**

Rear View Monitor displays the area behind your vehicle to help with safe parking or driving.

### *i* Information

If equipped with a display audio or if an additional infotainment system (genuine Hyundai part) has been installed, Rear View Monitor functions may differ from those indicated in the Owner's Manual.

In such a case, familiarize yourself the settings and operations of the Rear View Monitor as outlined in the web manual, which can be accessed via the QR code in the Infotainment System Ouick Guide.

#### Detecting sensor



[1]: Wide-rear view camera

Refer to the illustration above for the detailed location of the detecting sensor.

## Rear View Monitor settings Warning Methods



OAC3073076TU


The Warning Methods can be set when the vehicle is in ON position.

Parking safety priority: Select Settings > Vehicle > Driver assistance
 Warning methods > Parking safety priority on the infotainment system, the audio volume is reduced whilst Rear View Monitor is operating.

### *i* Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- Warning Method will maintain its last setting even if the vehicle is restarted.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

#### Camera settings



You can change Rear View Monitor Content selection by touching the setup icon (③) on the screen whilst Rear View Monitor is operating, or selecting Settings > Vehicle > Driver assistance > Parking safety > Camera settings from the Settings menu whilst the engine is on.

#### **Extended Rear View Monitor**

Keeps displaying the rear view when shifting from R (Reverse) to N (Neutral) or D (Drive). When exceeding a certain speed, the rear view stops displaying.

### **Rear View Parking Lines**

If **Rear view parking lines** is selected, the rear view parking guide lines and rear top view guide lines will be displayed at the left side of the infotaintment system screen.

### *i* Information

- The horizontal guideline of the Rear View Parking Guidance shows the distance of 0.5 m (20 in.), 1 m (40 in.) and 2.3 m (91 in.) from the vehicle.
- The horizontal guideline of the Rear Top View Parking Guidance shows the tailgate opening distance, 1.5 m (60 in.) from the vehicle.

### **Rear View Monitor Operation**

#### Rear view



### **Operating conditions**

- Shift the gear to R (Reverse), the rear view will appear on the screen.
- Touch the , the rear view will appear on the screen.

#### Off conditions

- The rear view cannot be turned off when the gear is in R (Reverse).
- Engage the parking brake while in neutral or shift to another gear, the rear view will turn off.

## *i* Information

When the gear is in R (Reverse), the rear view does not turn off.

### Rear top view

Select the rear top view mode from the view buttons (1).

The top view appears on the screen and you can check the distance to the vehicle or object in the back of your vehicle.

## Rear View Monitor malfunction and limitations

#### Rear View Monitor malfunction

When Rear View Monitor is not working properly, or the screen flickers, or the camera image does not display properly, we recommend that the vehicle be inspected by a HYUNDAI authorised repairer.

#### Limitations of Rear View Monitor

When the vehicle is stopped for a long time in winter or when the vehicle is parked in an indoor parking lot, the exhaust fumes may temporarily blur the image.

## **MARNING**

- The rear view camera does not cover the complete area behind the vehicle. The driver should always check the rear area directly through the inside and outside rearview mirror before parking or backing up.
- The distance to the object shown on the screen may differ from the actual distance. This is because the image shown on the Rear View Monitor is displayed by calibrating the image from the wide-rear view camera. When the vehicle is tilted by cargo weight or position, rear parking guidelines may differ from the actual distance. Make sure to directly check the vehicle's surroundings for safety.
- Always keep the rear view camera lens clean. If the lens is covered with foreign material, it may adversely affect camera performance and Rear View Monitor may not operate properly. However, do not use chemical solvents such as strong detergents containing high alkaline or volatile organic solvents (petrol, acetone, etc.). This may damage the camera lens.

## REVERSE PARKING DISTANCE WARNING (PDW) (IF EQUIPPED)

Parking Distance Warning will help warn the driver if an obstacle is detected within a certain distance when the vehicle is moving in reverse at low speeds.


### Detecting sensor



[1]: Rear ultrasonic sensors

Refer to the illustration above for the detailed location of the detecting sensors.

### Reverse Parking Distance Warning settings Warning Methods



OAC3073077TU

The Warning Methods can be set when the vehicle is in ON position.

Warning volume: Select User settings > Driver assistance > Warning volume on the instrument cluster or Settings > Vehicle > Driver assistance > Warning methods > Warning volume on the infotainment system, and adjust the warning volume.

### *i* Information

- If you change the Warning Methods, Warning Methods of other Driver Assistance systems may change.
- Warning Method will maintain its last setting even if the vehicle is restarted.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

## Reverse Parking Distance Warning operation

## Reverse Parking Distance Warning

Reverse Parking Distance Warning will operate under the following conditions.

• The gear is shifted to R (Reverse).

Distance from object	Warning indicator	Warning sound
24-40 in. (60-100 cm)		Buzzer beeps inter- mittently
12-24 in. (30-60 cm)		Beeps more frequently
Within 12 in. (30 cm)		Beeps con- tinuously

- The corresponding indicator will illuminate whenever each ultrasonic sensor detects a person, animal or object in its sensing range. Also an audible warning will sound.
- When more than two objects are detected at the same time, the closest one will be warned with an audible warning.
- The shape of the indicator in the illustration may differ from the actual vehicle.

# Reverse Parking Distance Warning malfunction and limitations

## Reverse Parking Distance Warning malfunction

After starting the engine, a beep will sound when the gear is shifted to R (Reverse) to indicate Reverse Parking Distance Warning is operating properly. However, if one or more of the following occurs, first check whether the ultrasonic sensor is damaged or blocked with foreign material. If it still does not work properly, we recommend that the vehicle be inspected by a HYUNDAI authorised repairer.

- The audible warning does not sound.
- The buzzer sounds intermittently.
- The 'Check Parking Distance Warning system' warning message appears on the instrument cluster.



B0377EU01

## Parking Distance Warning disabled



B0377EU03

If this occurs the 'Parking Distance Warning system limited. Ultrasonic sensor blocked' warning message appears on the instrument cluster.

Parking Distance Warning will operate properly when snow, rain or foreign material is removed. If Parking Distance Warning does not operate properly after obstruction (snow, rain, or foreign material) is removed (including trailer, carrier, etc., from the rear bumper), we recommend that the vehicle be inspected by a HYUNDAI authorised repairer.

## *i* Information



When the Parking Distance Warning is operating, if the function is not working normally or the ultrasonic sensor is blocked, the master warning light (△) appears in the direction of the corresponding sensor. You can check the warning in the Utility view on the cluster.

## Limitations of Reverse Parking Distance Warning

- Reverse Parking Distance Warning may not operate properly when:
  - Moisture is frozen to the sensor
  - Sensor is covered with foreign substance, such as snow or water (Reverse Parking Distance Warning will operate properly when such foreign substance is removed.)
  - The weather is extremely hot or cold
  - The sensor or sensor assembly is disassembled
  - The surface of the sensor is pressed hard or hit with a hard object
  - The surface of the sensor is scratched with a sharp object
  - The sensors or its surrounding area is directly sprayed with high pressure washer

- Reverse Parking Distance Warning may malfunction when:
  - Heavy rain or water spray is present
  - Water flows on the surface of the sensor
  - Affected by another vehicle's sensors
  - The sensor is covered with snow
  - Driving on uneven road, gravel roads or bushes
  - Objects that generates ultrasonic waves are near the sensor
  - License plate is installed in a different spot from the original location
  - The vehicle bumper height or ultrasonic sensor installation has been modified
  - Attaching equipments or accessories around the ultrasonic sensors
- The following objects may not be detected:
  - Sharp or slim objects, such as ropes, chains or small poles.
  - Narrow objects, such as corners of a square column
  - Objects, which tend to absorb sensor frequency, such as clothes, spongy material or snow.
  - Objects smaller than 100 cm (40 in.) in length and narrower than 14 cm (6 in.) in diameter.
  - Pedestrians, animals or objects that are very close to the ultrasonic sensors.

## **MARNING**

- Parking Distance Warning is a supplemental function. The operation of Parking Distance Warning can be affected by several factors (including environmental conditions). It is the responsibility of the driver to always check the front and rear views before and whilst parking.
- Your new vehicle warranty does not cover any accidents or damage to the vehicle due to the malfunction of Parking Distance Warning.
- Pay close attention when driving near objects, pedestrians, and especially children. Some objects may not be detected by the ultrasonic sensors, due to the objects distance, size or material, all of which can limit the effectiveness of the sensor.
- Parking Distance Warning does not warn you in the order of detection. It varies depending on the speed of the vehicle or the shape of a person, animal, or object.
- If the Parking Distance Warning does not operate properly, we recommend that the vehicle be inspected by a HYUNDAI authorised repairer.

# 8. Emergency situations

Hazard warning flasher	8-3
In case of an emergency whilst driving	8-3
If the engine stalls at a crossroad or crossing	
If you have a flat tyre whilst driving	
If the engine will not start	
If the engine doesn't turn over or turns over slowly	
If the engine turns over normally but doesn't start	
Jump starting	8-6
If the engine overheats	8-9
Tyre Pressure Monitoring System (TPMS)	8-10
Resetting TPMS	
Low tyre pressure light	
TPMS malfunction indicator	8-14
If you have a flat tyre (with spare tyre)	
Jack and tools	
Changing tyres	
Jack label	
EC Declaration of conformity for Jack	
UK Declaration of conformity for Jack	
If you have a flat tyre (with Tyre Mobility Kit)	
Introduction	
Notes on the safe use of the Tyre Mobility Kit	
Components of the Tyre Mobility Kit	
Using the Tyre Mobility Kit	
Checking the tyre inflation pressure	
Checking the tyre initiation pressure	0 30

lowing	8-32
Towing service	
Removable towing hook	
Emergency towing	
Emergency commodity	
Fire extinguisher	
First aid kit	
Triangle reflector	8-36
Tyre pressure gauge	
Pan-European eCall System	8-37
Information on data processing	
Pan-European eCall System	

### **HAZARD WARNING FLASHER**



The hazard warning flasher serves as a warning to other drivers to exercise extreme caution when approaching, overtaking, or passing your vehicle.

It should be used whenever emergency repairs are being made or when the vehicle is stopped near the edge of a roadway.

To turn the hazard warning flasher on or off, press the hazard warning flasher button with the ignition switch in any position. The button is located in the centre fascia panel. All turn signal lights will flash simultaneously.

- The hazard warning flasher operates whether your vehicle is running or not.
- The turn signals do not work when the hazard flasher is on.

## IN CASE OF AN EMERGENCY WHILST DRIVING

## If the engine stalls whilst driving

- Reduce your speed gradually, keeping a straight line. Move cautiously off the road to a safe place.
- Turn on your hazard warning flasher.
- Try to start the engine again. If your vehicle will not start, we recommend that you contact a HYUNDAI authorised repairer.

## If the engine stalls at a crossroad or crossing

If the engine stalls at a crossroads or crossing, if safe to do so, move the shift lever to the N (Neutral) position and then push the vehicle to a safe location.

## If you have a flat tyre whilst driving

If a tyre goes flat whilst you are driving:

- Take your foot off the accelerator pedal and let the vehicle slow down whilst driving straight ahead. Do not apply the brakes immediately or attempt to pull off the road as this may cause loss of vehicle control resulting in an accident. When the vehicle has slowed to such a speed that it is safe to do so, brake carefully and pull off the road. Drive off the road as far as possible and park on firm, level ground. If you are on a divided highway, do not park in the median area between the two traffic lanes.
- When the vehicle is stopped, press the hazard warning flasher button, move the shift lever into N (Neutral, for Automated manual transmission) or neutral (for Manual transmission vehicle), apply the parking brake, and place the ignition switch in the LOCK/ OFF position.
- Have all passengers get out of the vehicle. Be sure they all get out on the side of the vehicle that is away from traffic.
- When you have a flat tyre, follow the instructions provided later in this chapter.

#### IF THE ENGINE WILL NOT START

## If the engine doesn't turn over or turns over slowly

- Be sure the for Automated manual transmission or N (Neutral) if it is a vehicle. The engine starts only when the shift lever is in N (Neutral).
- Check the battery connections to be sure they are clean and tight.
- Turn on the interior light. If the light dims or goes out when you operate the starter, the battery is drained.

Do not push or pull the vehicle to start it. This could cause damage to your vehicle. See instructions for "Jump Starting" provided in this chapter.



### **CAUTION**

Push or pull starting the vehicle may cause the catalytic converter to overload which can lead to damage to the emission control system.

## If the engine turns over normally but doesn't start

 Check the fuel level and add fuel if necessary.

If the engine still does not start, we recommend that you call a HYUNDAI authorised repairer for assistance.

#### **JUMP STARTING**

Jump starting can be dangerous if done incorrectly. Follow the jump starting procedure in this section to avoid serious injury or damage to your vehicle. If in doubt about how to properly jump start your vehicle, we strongly recommend that you have a service technician or towing service do it for you.



### WARNING

To prevent SERIOUS INJURY or DEATH to you or bystanders, always follow these precautions when working near or handling the battery:



Always read and follow instructions carefully when handling a battery.



Wear eye protection designed to protect the eyes from acid splashes.



Keep all flames, sparks, or smoking materials away from the battery.



Hydrogen is always present in battery cells, is highly combustible, and may explode if ignited.



Keep batteries out of reach of children.



Batteries contain sulfuric acid which is highly corrosive. Do not allow acid to contact your eyes, skin or clothing. If acid gets into your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If acid gets on your skin, thoroughly wash the area. If you feel pain or a burning sensation, get medical attention immediately.

- When lifting a plastic-cased battery, excessive pressure on the case may cause battery acid to leak. Lift with a battery carrier or with your hands on opposite corners.
- Do not attempt to jump start your vehicle if your battery is frozen.
- NEVER attempt to recharge the battery when the vehicle's battery cables are connected to the battery.
- The electrical ignition system works with high voltage. NEVER touch these components with the engine running or when the ignition switch is in the ON position.
- Do not allow the (+) and (-) jumper cables to touch. It may cause sparks.
- The battery may rupture or explode when you jump start with a low or frozen battery.

### NOTICE

To prevent damage to your vehicle:

- Only use a 12 V power supply (battery or jumper system) to jump start your vehicle.
- Do not attempt to jump start your vehicle by push-starting.

### *i* Information



An inappropriately disposed battery can be harmful to the environment and human health. Dispose of the battery according to your local law(s) or regulations.

### Jump starting procedure

- Position the vehicles close enough that the jumper cables will reach, but do not allow the vehicles to touch.
- Avoid fans or any moving parts in the engine compartment at all times, even when the vehicles are turned off.
- Turn off all electrical devices such as radios, lights, air conditioning, etc. Put the vehicles in N (Neutral, for Automated manual transmission vehicle) or neutral (for Manual transmission vehicle), and set the parking brakes. Turn both vehicles OFF.

## **CAUTION**

Before jump starting, make sure to correctly identify the positive (+) and negative (-) terminals to avoid reverse polarity connections.



- Connect the jumper cables in the exact sequence shown in the illustration. First connect one jumper cable to the red, positive (+) jumper terminal of your vehicle (1).
- Connect the other end of the jumper cable to the red, positive (+) battery/ jumper terminal of the assisting vehicle (2).
- Connect the second jumper cable to the black, negative (-) battery/jumper terminal of the assisting vehicle (3).
- Connect the other end of the second jumper cable to the black, negative
   chassis ground of your vehicle
   (4).

Do not allow the jumper cables to contact anything except the correct battery or jumper terminals or the correct ground. Do not lean over the battery when making connections.

## ⚠ WARNING

Do not connect the jumper cable to the negative (-) jumper terminal of the discharged battery. A spark could cause the battery to explode and lead to a personal injury or vehicle damage.

8. Operate your vehicle for at least 30 minutes of driving or at least 60 minutes of engine running at idle before shutting off the engine. Without sufficient time to charge the battery the vehicle will reoccur another no start. You can also visit your nearest dealer to request the battery be charged and tested.

If your vehicle will not start after a few attempts, it probably requires service. In this event please seek qualified assistance. If the cause of your battery discharging is not apparent, we recommend that you have your vehicle checked by a HYUNDAI authorised repairer.

Disconnect the jumper cables in the exact reverse order you connected them:

- 1. Disconnect the jumper cable from the black, negative (-) chassis ground of your vehicle (4).
- Disconnect the other end of the jumper cable from the black, negative (-) battery/chassis ground of the assisting vehicle (3).
- Disconnect the second jumper cable from the red, positive (+) battery/ jumper terminal of the assisting vehicle (2).
- Disconnect the other end of the jumper cable from the red, positive (+) jumper terminal of your vehicle (1).

## **MARNING**

Whilst jump starting your vehicle, avoid the positive (+) and negative (-) cables to come in contact. A spark could cause personal injury.

#### IF THE ENGINE OVERHEATS

If your temperature gauge indicates overheating, you experience a loss of power, or hear loud pinging or knocking, the engine may be overheating. If this happens, you should:

- 1. Pull off the road and stop as soon as it is safe to do so.
- Place the shift lever in N (Neutral, for Automated manual transmission vehicle) or neutral (for Manual transmission vehicle) and set the parking brake. If the air conditioning is ON, turn it OFF.
- 3. If engine coolant is running out under the vehicle or steam is coming out from the bonnet, stop the engine. Do not open the bonnet until the coolant has stopped running or the steaming has stopped. If there is no visible loss of engine coolant and no steam, leave the engine running and check to be sure the engine cooling fan is operating. If the fan is not running, turn the engine off.

### **MARNING**



Whilst the engine is running, keep hands, clothing and tools away from the moving parts such as the cooling fan and drive belt to prevent serious injury.

- Check for coolant leaking from the radiator, hoses or under the vehicle. (If the air conditioning had been in use, it is normal for cold water to be draining from it when you stop.)
- If engine coolant is leaking out, stop the engine immediately and we recommend that you call a HYUNDAI authorised repairer for assistance.

## **MARNING**



NEVER remove the radiator cap or the drain plug whilst the engine and radiator are hot. Hot coolant and steam may blow

out under pressure, causing serious injury.

Turn the engine off and wait until the engine cools down. Use extreme care when removing the radiator cap. Wrap a thick towel around it, and turn it counterclockwise slowly to the first stop. Step back whilst the pressure is released from the cooling system. When you are sure all the pressure has been released, press down on the cap, using a thick towel, and continue turning counterclockwise to remove it.

- 6. If you cannot find the cause of the overheating, wait until the engine temperature has returned to normal. Then, if coolant has been lost, carefully add coolant to the reservoir to bring the fluid level in the reservoir up to the halfway mark.
- Proceed with caution, keeping alert for further signs of overheating. If overheating happens again, we recommend that you call a HYUNDAI authorised repairer for assistance.

### NOTICE

- Serious loss of coolant indicates a leak in the cooling system and we recommend the system be checked by a HYUNDAI authorised repairer.
- When the engine overheats from low engine coolant, suddenly adding engine coolant may cause cracks in the engine. To prevent damage, add engine coolant slowly in small quantities.

### TYRE PRESSURE MONITORING SYSTEM (TPMS, IF EQUIPPED)







- (1) Low Tyre Pressure Telltale/TPMS Malfunction Indicator
- (2) TPMS reset
- (3) Low Tyre Pressure warning message

The Tyre Pressure Monitoring System (TPMS) determines whether the tyre pressure is low through sensors in the wheel, which detects changes in tyre radius and vibration whilst driving. For this system to work properly, you need to reset and save the current tyre pressure. After resetting the TPMS, when one or more of your tyres are under-inflated compared to the saved tyre pressure, a warning light appears on the instrument cluster. A warning light also appears if there is a problem with the TPMS system.

For more information on warning lights and TPMS reset, refer to the following section in this chapter.

#### **Resetting TPMS**

To reset TPMS:

- 1. Adjust all tyre pressure to the recommended tyre inflation pressures.
- 2. Press the



- Select **Tyre pressure** on the cluster by using the △, ∨ (UP, DOWN) switch.
- 4. Press and hold the OK button on the steering wheel, and select **Set**.





5. Check whether the "Standard tyre pressures saved" message appears on the cluster and the (!) warning light blinks for about 4 seconds.

### Information

- If the "Standard tyre pressures saved" message on the instrument cluster does not appear or the warning light does not blink, try again from Step 2.
- For more information on the recommended inflation pressure for your vehicle, refer to the "Tyres and wheels" section in chapter 2.

For normal operation of the TPMS, be sure to reset in the following situations:

- · After repairing or replacing a tyre or wheel
- · After rotating the position of a tyre or wheel.
- After adjusting the tyre inflation pres-
- · When the Low Tyre Pressure warnina light is on.
- · After replacing the suspension or ABS/ESC.

### **↑** CAUTION

- · Be sure to reset after the inflation pressure of all four tyres are set to the recommended inflation pressure. If you reset without adjusting the inflation pressure, the warning sound may not activate or may activate improperly.
- · If the inflation pressure of the four tyres are adjusted, be sure to perform reset. Otherwise, the system may malfunction and the warning sound may not activate or may activate improperly.
- Adjust the inflation pressure when the tyres are cold. A cold tyre means the vehicle has not been driven for 3 hours or has been driven for less than 1 mile (1.6 km).

### Low tyre pressure light



When the Low Tyre Pressure warning light ((!)) illuminates and a warning message appears on the instrument cluster for 10 seconds, one or more of your tyres is significantly under-inflated. If the warning light illuminates, reduce your speed, and also avoid hard cornering and sudden braking. We recommend that your vehicle be inspected by

Check the condition and inflation pressure of all four tyres, then reset the TPMS (For more information, refer to the "Resetting TPMS" section in this chapter.) or take required counteractions such as repairing or replacing the tyres.

a HYUNDAI authorised repairer.

When a HYUNDAI authorised repairer is not nearby, stop at a safe place and check the condition and inflation pressure of all four tyres, then reset the TPMS.

If you cannot unable to adjust the inflation pressure, use the Tyre Mobility Kit (TMK) to repair or replace the under-inflated tyre with a spare tyre (if equipped). We recommend that your vehicle be inspected by a HYUNDAI authorised repairer.

You may not be able to identify a tyre with low pressure by simply looking at it. Always use a good quality tyre pressure gauge to measure. Note that a tyre that is hot (from being driven) has a higher pressure measurement than a tyre that is cold.

A cold tyre means the vehicle has been sitting for 3 hours and driven for less than 1 mile (1.6 km) in that 3 hour period. Allow the tyre to cool before measuring the inflation pressure. Always be sure the tyre is cold before inflating to the recommended pressure.

### Information

- The warning light may remain on even after replaced with a spare tyre.
   Replace your vehicle with original sized tyres.
- Note that the TPMS is not a substitute for proper tyre maintenance. It is the driver's responsibility to maintain the appropriate recommended inflation pressure, and the tyres must be inspected periodically to maintain the recommended inflation pressure.
- The Low Tyre Pressure warning light may illuminate when the TPMS is not reset when necessary.
- In winter or cold weather, the Low Tyre Pressure warning light may illuminate if the tyre pressure was adjusted to the recommended tyre inflation pressure in warm weather. It does not mean your TPMS is malfunctioning because the decreased temperature leads to a proportional lowering of tyre pressure. Check the tyre inflation pressure and adjust the tyres to the recommended tyre inflation pressure.

- TPMS performance may reduce in the following situations when:
  - Reset is done incorrectly.
  - Original sized tyres are not installed.
  - Driving on rough roads such as snowy, slippery roads, or unpaved roads.
  - Repeating hard cornering, sudden acceleration, or sudden braking.
  - Driving too slow or too fast.
  - The vehicle is overloaded.
  - Spare tyre or snow chains are installed.

### **CAUTION**

- Continued driving on low pressure tyres can cause the tyres to overheat and fail. Under-inflation may cause the vehicle to be unstable and reduce tyre life and fuel economy, increase braking distance, and other tyre failures that result in loss of vehicle control. We recommend that your vehicle be inspected by a HYUNDAI authorised repairer and maintain the recommended inflation pressure.
- The TPMS cannot alert you to severe and sudden tyre damage caused by external factors. If you notice any vehicle instability, immediately take your foot off the accelerator pedal, apply the brakes gradually with light force, and slowly move to a safe position off the road.

### **TPMS** malfunction indicator



The TPMS malfunction indicator ((!)) illuminates for about 70 seconds when there is a problem with the Tyre Pressure Monitoring System.

If the indicator remains illuminated even after the TPMS is reset, we recommend that your vehicle be inspected by a HYUNDAI authorised repairer as soon as possible.

If there is a malfunction with the TPMS, the under-inflated tyre cannot be detected.

### NOTICE

Condition	⟩ indicator status</th
Low pressure	Illuminate
System malfunction	Blinks for about 70 seconds and illuminate
Reset	Blinks for about 4 seconds and goes off

### IF YOU HAVE A FLAT TYRE (WITH SPARE TYRE, IF EQUIPPED)

## **MARNING**

Changing a tyre can be dangerous. Follow the instructions in this section when changing a tyre to reduce the risk of serious injury or death.

## **CAUTION**

Be careful as you use the jack handle to stay clear of the flat end. The flat end has sharp edges that could cause cuts.

#### Jack and tools



- (1) Jack
- (2) Jack handle
- (3) Wheel lug nut wrench
- (4) Towing hook

The jack, jack handle, wheel lug nut wrench, and towing hook are stored in the luggage compartment under the luggage box cover.



The jack is provided for emergency tyre changing only.

Turn the winged hold down bolt counterclockwise to remove the spare tyre.

Store the spare tyre in the same compartment by turning the winged hold down bolt clockwise.

To prevent the spare tyre and tools from "rattling", store them in their proper location.



If it is hard to loosen the tyre hold-down wing bolt by hand, you can loosen it easily using the jack handle.

- 1. Put the jack handle (1) inside of the tyre hold-down wing bolt.
- Turn the tyre hold-down wing bolt counterclockwise with the jack handle.

### **Changing tyres**



### ↑ WARNING

A vehicle can slip or roll off of a jack causing serious injury or death to you or those nearby. Take the following safety precautions:

- · Do not get under a vehicle that is supported by a jack.
- · NEVER attempt to change a tyre in the lane of traffic. ALWAYS move the vehicle completely off the road on level, firm ground away from traffic before trying to change a tyre. If you cannot find a level, firm place off the road, call a towing service for assistance.
- · Be sure to use the jack provided with the vehicle.
- · ALWAYS place the jack on the designated jacking positions on the vehicle and NEVER on the bumpers or any other part of the vehicle for jacking support.
- · Do not start or run the engine whilst the vehicle is on the lack.
- · Do not allow anyone to remain in the vehicle whilst it is on the lack.
- Keep children away from the road and the vehicle.

Follow these steps to change your vehicle's tyre:

- 1. Park on a level, firm surface.
- 2. Move the shift lever into N (Neutral. for Automated manual transmission vehicle) or neutral (for Manual transmission vehicle), apply the parking brake, and place the ignition switch in the LOCK/OFF position.
- 3. Press the hazard warning flasher button.
- 4. Remove the wheel lug nut wrench, jack, jack handle, and spare tyre from the vehicle.



[A]: Block

5. Block both the front and rear of the tyre diagonally opposite of the tyre you are changing.



6. Loosen the wheel lug nuts counterclockwise one turn each in the order shown above, but do not remove any lug nuts until the tyre has been raised off of the ground.



7. Place the jack at the designated jacking position under the frame closest to the tyre you are changing. The jacking positions are plates welded to the frame with two notches. Never jack any other position or part of the vehicle. Doing so may damage the side seal molding or other parts of the vehicle.



 Insert the jack handle into the jack and turn it clockwise, raising the vehicle until the tyre clears the ground. Make sure the vehicle is stable on the jack.

- Loosen the lug nuts with the wheel lug nut wrench and remove them with your fingers. Remove the wheel from the studs and lay it flat on the ground out of the way. Remove any dirt or debris from the studs, mounting surfaces, and wheel.
- 10. Install the spare tyre onto the studs of the hub.
- Tighten the lug nuts with your fingers onto the studs with the smaller end of the lug nuts closest to the wheel.
- Lower the vehicle to the ground by turning the jack handle counterclockwise.



13. Use the wheel lug nut wrench to tighten the lug nuts in the order shown. Double-check each lug nut until they are tight. After changing tyres, we recommend that a HYUN-DAI authorised repairer tighten the lug nuts to their proper torque as soon as possible. The wheel lug nut should be tightened to 11-13 kgf.m (79-94 lbf.ft).

If you have a tyre gauge, check the tyre pressure (see "Tyres and Wheels" in chapter 2 for tyre pressure instructions.). If the pressure is lower or higher than recommended, drive slowly to the nearest service station and adjust it to the recommended pressure. Always reinstall the valve cap after checking or adjusting tyre pressure. If the cap is not replaced, air may leak from the tyre. If you lose a valve cap, buy another and install it as soon as possible. After changing tyres, secure the flat tyre and return the jack and tools to their proper storage locations.

NOTICE

- Check the tyre pressure as soon as possible after installing a spare tyre. Adjust it to the recommended pressure.
- · Check and tighten the wheel lug nuts after driving 30 mi. (50 km) if tyres are replaced. Re-check the tyre wheel lug nuts after driving over 600 mi. (1,000 km).



Your vehicle has metric threads on the studs and lug nuts. Make certain during tyre changing that the same nuts that were removed are reinstalled. If you have to replace your lug nuts make sure they have metric threads to avoid damaging the studs and ensure the wheel is properly secured to the hub. We recommend that you consult a HYUNDAI authorised repairer for assistance.

If any of the equipment such as the iack, lug nuts, studs, or other equipment is damaged or in poor condition, do not attempt to change the tyre and call for assistance.

### Use of compact spare tyres (if equipped)

Compact spare tyres are designed for emergency use only. Drive carefully on the compact spare tyre and always follow the safety precautions.



### WARNING

To prevent compact spare tyre failure and loss of control possibly resulting in an accident:

- Use the compact spare tyre only in an emergency.
- NEVER operate your vehicle over 50 mph (80 km/h).
- · Do not exceed the vehicle's maximum load rating or the load carrying capacity shown on the sidewall of the compact spare tyre.
- Do not use the compact spare tyre continuously. Repair or replace the original tyre as soon as possible to avoid failure of the compact spare tyre.

When driving with the compact spare tyre mounted to your vehicle:

- Check the tyre pressure after installing the compact spare tyre. The compact spare tyre should be inflated to 60 psi (420 kPa).
- Do not take this vehicle through an automatic car wash whilst the compact spare tyre is installed.
- Do not use the compact spare tyre on any other vehicle because this tyre has been designed especially for your vehicle.
- The compact spare tyre's tread life is shorter than a regular tyre. Inspect your compact spare tyre regularly and replace worn compact spare tyres with the same size and design, mounted on the same wheel.
- Do not use more than one compact spare tyre at a time.
- Do not tow a trailer whilst the compact spare tyre is installed.

### NOTICE

When the original tyre and wheel are repaired and reinstalled on the vehicle, the lug nut torque must be set correctly. The correct lug nut tightening torque is 11-13 kgf.m (79-94 lbf.ft).

### **CAUTION**


To prevent damaging the compact spare tyre and your vehicle:

- Drive slowly enough for the road conditions to avoid all hazards, such as a potholes or debris.
- Avoid driving over obstacles. The compact spare tyre diameter is smaller than the diameter of a conventional tyre and reduces the ground clearance about 25 mm (1 in.).
- Do not use tyre chains on the compact spare tyre. Because of the smaller size, a tyre chain will not fit properly.
- Do not use the compact spare tyre on any other wheels, nor should standard tyres, snow tyres, wheel covers or trim rings be used with the compact spare wheel.
- Do not suddenly accelerate or decelerate (0 

  25 mph) (0 

  40 km/h) in any driving mode. It may cause leakage of transfer oil.

### Jack label



The actual Jack label in the vehicle may differ from the illustration.


For more detailed specifications, refer to the label attached to the jack.

- 1. Model Name
- 2. Maximum allowable load
- 3. When using the jack, set your parking brake.
- 4. When using the jack, stop the engine.
- 5. Do not get under a vehicle that is supported by a jack.
- 6. The designated locations under the frame

- 7. When supporting the vehicle, the base plate of jack must be vertical under the lifting point.
- Shift into R (Reverse) gear on vehicles with Manual transmission or move the shift lever to the N (Neutral) position on vehicles with Automated manual transmission.
- 9. The jack should be used on firm level ground.
- Representative company and address

### **EC Declaration of conformity for Jack**

### Type A



JACKDOC14S

### Type B

#### EG-Konformitätserklärung EC Declaration of Conformity

Hiermit erklären wir, We herewith declare.

Chengde Runhan Auto Accessory Co., Ltd.

East of High-Technological Development Zone, Chengde Hebel PEOPLE'S REPUBLIC OF CHINA

daß die nachfolgend bezeichnete Maschine aufgrund ihrer Konzipierung und Bauart sowie in der von uns in Verkehr gebrachten Ausführung den einschlägigen grundlegenden Sicherheits- und Gesundheitsanforderungen der EG-Richtlinien entspricht.

That the following machine complies with the appropriate basic safety and health requirements of the EC Directive based on its design and type, as brought into circulation by us.

Bei einer nicht mit uns abgestimmten Änderung der Maschine verliert diese Erklärung ihre

In case of alteration of the machine, not agreed upon by us, this declaration will lose its validity

Bezeichnung der Maschine: Mechanical jack(Scissor jack)

Machine Description:

Maschinentyp: Machine Type.

Handelsmarke: Trade name

Maschinen-Nr.: 09110-C8000

Einschlägige EG-Richtlinien: EG-Maschinenrichtlinie 2006/42/EG Applicable EC Directives: EC Machinery Directive: 2006/42/EC

Angewandte harmonisierte Normen:

Applicable Harmonized Standards:

EN 1494:2000/A1:2008

Herstellerunterschrift/Datum:

Angaben zum Unterzeichner:

Title of Signatory: genera/ manager

This Declaration of Conformity has been prepared by TÜV Product Service. A specimen of this product meets the requirements of conformity test carried out by TÜV Product Service according with the applicable standards under the mentioned directives.


Diese Konformitätserklärung wurde vom TÜV Product Service vorbereitet. Ein Muster dieses Produktes hat die Anforderungen der Konformitätsprüfung erfüllt. Diese Prüfung wurde beim TÜV Product Service aufgrund der zutreffenden Vorschriften der genannten Richtlinien durchgeführt.

TÜV Product Service Prüfbericht Nr./ TÜV Product Service report reference no.: 70.436.12.078.02-00 Date/Datum 2 MAY 2017

Revision 0

OAC3N070039TU

### **UK Declaration of conformity for Jack**



OAC3073039TU

### IF YOU HAVE A FLAT TYRE (WITH TYRE MOBILITY KIT, IF EQUIPPED)



For safe operation, carefully read and follow the instructions in this manual before use.

- (1) Compressor
- (2) Sealant bottle

The Tyre Mobility Kit is a temporary fix to the tyre and we recommend that the system be inspected by a HYUNDAI authorised repairer.

### **↑** CAUTION

When two or more tyres are flat, do not use the tyre mobility kit because the sealant provided with the Tyre Mobility Kit must be used for only one flat tyre.

### **⚠** WARNING

Do not use the Tyre Mobility Kit to repair punctures in the tyre walls. This can result in an accident due to tvre failure.

### **⚠** WARNING

The tyre inflation pressure must be at least 32 psi (220 kPa). If it is not, do not continue driving.

Call for road side service or towing.

### Introduction

With the Tyre Mobility Kit you stay mobile even after experiencing a tyre puncture.

The system of compressor and sealing compound effectively and comfortably seals most punctures in a passenger car tyre caused by nails or similar objects and reinflates the tyre.

After you ensured that the tyre is properly sealed you can drive cautiously on the tyre (distance up to 120 miles (200 km)) at a max. speed of 50 mph (80 km/h) in order to reach a service station or tyre dealer to have the tyre replaced. It is possible that some tyres, especially with larger punctures or damage to the sidewall, cannot be sealed completely.

Air pressure loss in the tyre may adversely affect tyre performance.

For this reason, you should avoid abrupt steering or other driving manoeuvres, especially if the vehicle is heavily loaded or if a trailer is in use.

The Tyre Mobility Kit is not designed or intended as a permanent tyre repair method and is to be used for one tyre only. This instruction shows you step by step how to temporarily seal the puncture simply and reliably.

Read the section "Notes on the safe use of the Tyre Mobility Kit".



### WARNING

Do not use the TMK if a tyre is severely damaged by driving run flat or with insufficient air pressure.


Only punctured areas located within the tread region of the tyre can be sealed using the TMK.

### Notes on the safe use of the Tyre Mobility Kit

- Park your car at the side of the road so that you can work with the Tyre Mobility Kit away from moving traffic.
- To be sure your vehicle will not move, even when you're on fairly level ground, always set your parking brake.
- Only use the Tyre Mobility Kit for sealing/inflation passenger car tyres.
   Only punctured areas located within the tread region of the tyre can be sealed using the tyre mobility kit.
- Do not use on motorcycles, bicycles or any other type of tyres.
- When the tyre and wheel are damaged, do not use Tyre Mobility Kit for your safety.
- Use of the Tyre Mobility Kit may not be effective for tyre damage larger than about 0.24 in. (6 mm).
  - If the tyre cannot be made roadworthy with the Tyre Mobility Kit, we recommend that you contact a HYUND-Al authorised repairer.
- Do not use the Tyre Mobility Kit if a tyre is severely damaged by driving run flat or with insufficient air pressure.
- Do not remove any foreign objects such as nails or screws that have penetrated the tyre.

- Provided the car is outdoors, leave the engine running. Otherwise operating the compressor may eventually drain the car battery.
- Never leave the Tyre Mobility Kit unattended whilst it is being used.
- Do not leave the compressor running for more than 10 min. at a time or it may overheat.
- Do not use the Tyre Mobility Kit if the ambient temperature is below -30°C (-22°F).
- In case of skin contact with the sealant, wash the area thoroughly with plenty of water. If the irritation persists, seek medical attention.
- In case of eye contact with the sealant, flush your eyes for at least 15 minutes. If the irritation persists, seek medical attention.
- In case of swallowing the sealant, rinse the mouth and drink plenty of water. However, never give anything to an unconscious person and seek medical attention immediately.
- Long time exposure to the sealant may cause damage to bodily tissue such as kidney, etc.

### **Components of the Tyre Mobility Kit**



- 1. Speed-restriction label
- 2. Sealant bottle and label with speed restriction
- 3. Filling hose from sealant bottle to wheel
- 4. Connectors and cable for the power outlet direct connection
- 5. Holder for the sealant bottle
- 6. Compressor
- 7. ON/OFF switch
- 8. Pressure gauge for displaying the tyre inflation pressure
- 9. Button for reducing the tyre inflation pressure
- 10. Hose to connect compressor and sealant bottle or compressor and wheel

Connectors, cable and connection hose are stored in the compressor housing. Strictly follow the specified sequence, otherwise the sealant may escape under high pressure.

### **⚠** WARNING

### **Expired sealant**

Do not use the Tyre sealant after the sealant has expired (for example, pasted the expiration date on the sealant container). This can increase the risk of tyre failure.



### **⚠** WARNING

#### Sealant

- · Keep out of reach of children.
- · Avoid contact with eyes.
- · Do not swallow.

### **Using the Tyre Mobility Kit**



### CAUTION



Detach the speed restriction label (1) from the sealant bottle (2), and place it in a highly visible place inside the vehicle such as on the steering wheel to remind the driver not to drive too fast.

1. Shake the sealant bottle (2).



2. Screw connection hose (10) onto the connector of the sealant bottle



3. Insert the sealant bottle into the housing (5) of the compressor so that the bottle is upright.



4. Unscrew the valve cap from the valve of the defective wheel and screw the filling hose (3) of the sealant bottle onto the valve.

## **CAUTION**

Securely install the sealant filling hose to the valve. If not, sealant may flow backward, possibly clogging the filling hose.



5. Plug the compressor power cord (4) into the vehicle power outlet.

### NOTICE

Only use the front passenger side power outlet when connecting the power cord.

6. With the ignition switch in the ON position, switch on the compressor and let it run for about 5~7 minutes to fill the sealant up to proper pressure. (refer to Tyre and Wheels, chapter 2). The inflation pressure of the tyre after filling is unimportant and will be checked/corrected later. Be careful not to overinflate the tyre and stay away from the tyre when filling it.

### **CAUTION**

### Tyre pressure

Do not attempt to drive your vehicle if the tyre pressure is below 200 kPa (29 psi). This could result in an accident due to sudden tyre failure.

- 7. Switch off the compressor.
- Detach the hoses from the sealant bottle connector and from the tyre valve.

Return the Tyre Mobility Kit to its storage location in the vehicle.


### A

### WARNING

#### Carbon monoxide

Do not leave your vehicle running in a poorly ventilated area for extended periods of time. Carbon monoxide poisoning and suffocation can occur.

### Distributing the sealant



 Immediately drive about 4-6 miles (7-10 km or, about 10min) to evenly distribute the sealant in the tyre.

Do not exceed a speed of 50 mph (80 km/h). If possible, do not fall below a speed of 12 mph (20 km/h).

Whilst driving, if you experience any unusual vibration, ride disturbance or noise, reduce your speed and drive with caution until you can safely pull off of the side of the road.

Call for road side service or towing.

# Checking the tyre inflation pressure



- After driving about 4-6 miles (7-10 km or about 10 min.), stop at a safety location.
- 2. Connect the filling hose (3) of the compressor directly to the tyre valve.
- 3. Plug the compressor power cord into the vehicle power outlet.
- Adjust the tyre inflation pressure to the recomended tyre inflation.
   With the ignition swithched on, proceed as follows.
  - To increase the inflation pressure: Switch on the compressor.
     To check the current inflation pressure setting, briefly switch off the compressor.
  - To reduce the inflation pressure: Press the button (9) on the compressor.

### NOTICE

Do not let the compressor run for more than 10 minutes, otherwise the device will overheat and may be damaged.



### Information

The pressure gauge may show higher than actual reading when the compressor is running. To get an accurate tyre reading, the compressor needs to be turned off.



### CAUTION

If the inflation pressure is not maintained, drive the vehicle a second time, refer to Distributing the sealant. Then repeat steps 1 to 4.

Use of the Tire Mobility Kit may be ineffectual for tyre damage larger than about 0.24 in. (6 mm).

We recommend that you contact a HYUNDAI authorised repairer if the tyre cannot be made roadworthy with the Tyre Mobility Kit.



### WARNING

The tyre inflation pressure should meet the standard "TYRES AND WHEELS" in Chapter 2 or "Tyre Inflation Pressure Standard Label" on the B pillar of the driver's seat. If it is not, do not continue driving. Call for road side service or towing.



### **CAUTION**

Tyre pressure sensor (if equipped with TPMS)

The sealant on the tyre pressure sensor and wheel should be removed when you replace the tyre with a new one and inspect the tyre pressure sensors. We recommend that you get this done at a HYUNDAI authorised repairer.




### Information

When reinstalling the repaired or replaced tyre and wheel on the vehicle. tighten the wheel lug nut to 11-13 kgf·m (79-94 lbf·ft).

### **TOWING**

### **Towing service**



[A]: Dolly

If emergency towing is necessary, we recommend having it done by a HYUN-DAI authorised repairer or a commercial tow-truck service.

Proper lifting and towing procedures are necessary to prevent damage to the vehicle. The use of wheel dollies or flatbed is recommended.

It is acceptable to tow the vehicle with the rear wheels on the ground (without dollies) and the front wheels off the ground.

If any of the loaded wheels or suspension components are damaged or the vehicle is being towed with the front wheels on the ground, use a towing dolly under the front wheels.

When being towed by a commercial tow truck and wheel dollies are not used, the front of the vehicle should always be lifted, not the rear.

### **CAUTION**

 Do not tow the vehicle with 4 wheels on the ground (such as dinghy towing behind a motorhome or other motor vehicle) as this can seriously damage the Automated Manual Transmiss-ion.



Do not tow the vehicle with the front wheels on the ground as this may cause damage to the vehicle.



Do not tow with sling-type equipment. Use wheel lift or flatbed equipment.



When towing your vehicle in an emergency without wheel dollies:

- 1. Place the ignition switch in the ACC position.
- 2. Place the shift lever in N (Neutral).
- 3. Release the parking brake.



### **CAUTION**

Failure to place the shift lever in N (Neutral) may cause internal damage to the transmission.

### Removable towing hook



1. Open the tailgate, and remove the towing hook from the tool case.



- 2. Remove the hole cover by pressing the lower part of the cover on the bumper.
- Install the towing hook by turning it clockwise into the hole until it is fully secured
- 4. Remove the towing hook and install the cover after use.

### **Emergency towing**





If towing is necessary, we recommend you have it done by a HYUNDAI authorised repairer or a commercial tow truck service.

If towing service is not available in an emergency, your vehicle may be temporarily towed using a cable or chain secured to the emergency towing hook at the front (or rear) of the vehicle.

Use extreme caution when towing the vehicle with a cable or chain. A driver must be in the vehicle to steer it and operate the brakes.


Towing in this manner may be done only on hard-surfaced roads for a short distance and at low speeds. Also, the wheels, axles, power train, steering and brakes must all be in good condition.

### **CAUTION**

The driver must be in the vehicle for steering and braking operations when the vehicle is being towed. Passengers other than the driver must not be in the vehicle.

Always follow these emergency towing precautions:

- Place the ignition switch in the ACC position so the steering wheel is not locked
- · Place the shift lever in N (Neutral).
- · Release the parking brake.
- Depress the brake pedal with more force than normal since you will have reduced braking performance.
- More steering effort will be required because the power steering system will be disabled.
- Use a vehicle heavier than your own to tow your vehicle.
- The drivers of both vehicles should communicate with each other frequently.
- Before emergency towing, check that the hook is not broken or damaged.
- Fasten the towing cable or chain securely to the hook.
- Do not jerk the hook. Apply steady and even force.



- Use a towing cable or chain less than 16 ft. (5 m) long. Attach a white or red cloth (about 12 in. (30 cm) wide) in the middle of the cable or chain for easy visibility.
- Drive carefully so the towing cable or chain remains tight during towing.
- Before towing, check the Automated manual transmission for fluid leaks under your vehicle. If the Automated manual transmission fluid is leaking, flatbed equipment or a towing dolly must be used

### NOTICE

Accelerate or decelerate the vehicle in a slow and gradual manner whilst maintaining tension on the tow rope or chain to start or drive the vehicle, otherwise tow hooks and the vehicle may be damaged.

### NOTICE

To avoid damage to your vehicle and vehicle components when towing:

- Always pull straight ahead when using the towing hooks. Do not pull from the side or at a vertical angle.
- Do not use the towing hooks to pull a vehicle out of mud, sand or other conditions from which the vehicle cannot be driven out under its own power.
- Limit the vehicle speed to 10 mph (15 km/h) and drive less than 1 mile (1.5 km) when towing to avoid serious damage to transmission. (for Automated manual transmission vehicle)
- The vehicle should be towed at a speed of 15 mph (25 km/h) or less within the distance of 12 miles (20 km). (for Manual transmission vehicle)

### **EMERGENCY COMMODITY (IF EQUIPPED)**

Your vehicle is equipped with emergency commodities to help you respond to emergency situation.

### Fire extinguisher

If there is small fire and you know how to use the fire extinguisher, follow these steps carefully.

- Pull out the safety pin at the top of the extinguisher that keeps the handle from being accidentally pressed.
- 2. Aim the nozzle towards the base of the fire
- Stand about 2.5 m (8 ft) away from the fire and squeeze the handle to discharge the extinguisher. If you release the handle, the discharge will stop.
- Sweep the nozzle back and forth at the base of the fire. After the fire appears to be out, watch carefully since it may re-ignite.

### First aid kit

Supplies for use in giving first aid such as scissors, bandage and adhesive tape, etc., are provided.

### **Triangle reflector**

Place the triangle reflector on the road to warn oncoming vehicles during emergencies, such as when the vehicle is parked by the roadside due to problems.

# Tyre pressure gauge (if equipped)

Tyres normally lose some air in day-today use, and you may have to add a air periodically and usually it is not a sign of a leaking tyre, but of normal wear. Always check tyre pressure when the tyres are cold because tyre pressure increases with temperature.

To check the tyre pressure, take the following steps:


- 1. Unscrew the inflation valve cap that is located on the rim of the tyre.
- Press and hold the gauge against the tyre valve. Some air will leak as you begin and more will leak if you don't press the gauge in firmly.
- 3. A firm non-leaking push will activate the gauge.
- Read the tyre pressure on the gauge to see whether the tyre pressure is low or high.
- 5. Adjust the tyre pressure to the specified pressure. Refer to "Tyres and Wheels" section in chapter 2.
- 6. Reinstall the inflation valve cap.

### PAN-EUROPEAN ECALL SYSTEM (IF EOUIPPED)

The vehicle is equipped with a device\* connected with the Pan-European eCall system for making emergency call to response teams. The Pan-European eCall system is an automatic emergency call service made in event of a traffic accident or other\*\* accidents on the roads of Europe. (only in countries with regulation on this system)

The system allows contacting with an officer of the single duty dispatch service in case of accidents on the roads of Europe. (only in countries with regulation on this system)


The Pan-European eCall system given conditions, stated in the Owner's Manual as well as Warranty and Service book transmits data to the Public Safety Answering Point (PSAP) including such information as vehicle location, vehicle type, VIN (vehicle identification number of the vehicle).



- 1. Road accident
- 2. Wireless network
- 3. Public Safety Answering Point (PSAP)
- 4. Rescue
- \* Pan-European eCall device in the Owner's Manual means equipment, installed in the vehicle, which provides connection with the Pan-European eCall system.
- \*\* "Other accidents" mean any accidents on the roads of Europe (only in countries with regulation on this system) resulted in injured people and/or necessity of provision of assistance. In case of registration of any accident, it is necessary to stop a vehicle, press button SOS (location of the button is specified on the picture in the chapter "Pan-European eCall (IF EQUIPPED)") of the Owner's Manual. When making a call, the system gathers information about the vehicle (from which a call was made), after which connects the car with an officer of the Public Safety Answering Point (PSAP) to tell about the reason of the emergency call.

Once the data which is stored in the Pan-European eCall system is delivered to the rescue centre to assist the driver and passengers with proper rescue operations, the data will be deleted after rescue operation is completed.

### Description of the ecall in-vehicle system



Overview of the 112-based eCall in-vehicle system, its operation and functionalities: refer to this section. The 112-based eCall service is a public service of general interest and is accessible free of charge.

The 112-based eCall in-vehicle system is activated by default. It is activated automatically by means of in- vehicle sensors in the event of a severe accident.

It will also be triggered automatically when the vehicle is equipped with a TPS system which does not function in the event of a severe accident.

The 112-based eCall in-vehicle system can also be triggered manually, if needed. Instructions for manual activation of the system: refer to this section.

In the event of a critical system failure that would disable the 112-based eCall in-vehicle system, the following warning will be given to the occupants of the vehicle: refer to this section.

### Information on data processing

Any processing of personal data through the 112-based eCall in-vehicle system shall comply with the personal data protection rules provided for in Directives 95/46/EC (1) and 2002/58/EC (2) of the European Parliament and of the Council, and in particular, shall be based on the necessity to protect the vital interests of the individuals in accordance with Article 7(d) of Directive 95/46/EC (3).

Processing of such data is strictly limited to the purpose of handling the emergency eCall to the single European emergency number 112.

### Types of data and its recipients

The 112-based eCall in-vehicle system may collect and process only the following data:

- Vehicle Identification Number
- Vehicle type (passenger vehicle or light commercial vehicle)
- Vehicle propulsion storage type (petrol/diesel/CNG/LPG/electric/hydrogen)
- Vehicle recent locations and direction of travel
- Log file of the automatic activation of the system and its timestamp
- Any additional data (if applicable):
   Not applicable

Recipients of data processed by the 112-based eCall in-vehicle system are the relevant public safety answering points designated by the respective public authorities of the country on which territory they are located, to first receive and handle eCalls to the single European emergency number 112. Additional information (if available): Not applicable

- (1) Directive 95/46/EC of the European Parliament and of the Council of 24 October 1995 on the protection of individuals with regard to the processing of personal data and on the free movement of such data (OJ L 281, 23.11.1995, p. 31).
- (2) Directive 2002/58/EC of the European Parliament and of the Council of 12 July 2002 concerning the processing of personal data and the protection of privacy in the electronic communications sector (Directive on privacy and electronic communications) (OJ L 201, 31.7.2002, p. 37).
- (3) Directive 95/46/EC is repealed by Regulation (EU) 2016/679 of the European Parliament and of the Council of 27 April 2016 on the protection of natural persons with regard to the processing of personal data and on the free movement of such data (General Data Protection Regulation) (OJ L 119, 4.5.2016, p. 1). The Regulation applies from 25 May 2018.

## Arrangements for data processing

The 112-based eCall in-vehicle system is designed in such a way as to ensure that the data contained in the system memory is not available outside the system before an eCall is triggered. Additional remarks (if any): Not applicable

The 112-based eCall in-vehicle system is designed in such a way as to ensure that it is not traceable and not subject to any constant tracking in its normal operation status. Additional remarks (if any): Not applicable

The 112-based eCall in-vehicle system is designed in such a way as to ensure that data in the system internal memory is automatically and continuously removed.

The vehicle location data is constantly overwritten in the internal memory of the system so as always to keep maximum of the last three up-to-date locations of the vehicle necessary for the normal functioning of the system.

The log of activity data in the 112-based eCall in-vehicle system is kept for no longer than necessary for attaining the purpose of handling the emergency eCall and in any case not beyond 13 hours from the moment an emergency eCall was initiated. Additional remarks (if any): Not applicable

# Modalities for exercising data subject's rights

The data subject (the vehicle's owner) has a right of access to data and as appropriate to request the rectification, erasure or blocking of data, concerning him or her, the processing of which does not comply with the provisions of Directive 95/46/EC. Any third parties to whom the data have been disclosed have to be notified of such rectification, erasure or blocking carried out in compliance with this Directive, unless it proves impossible or involves a disproportionate effort.

The data subject has a right to complain to the competent data protection authority if he or she considers that his or her rights have been infringed as a result of the processing of his or her personal data.

Contact service responsible for handling access requests (if any): Not applicable

### Pan-European eCall System



Elements of the Pan-European eCall system, installed in passenger compartment:

- (1) SOS button
- (2) LED

#### SOS button:

The driver/passenger makes an emergency call to the single duty dispatch service by pressing the button.

### • LED:

The green LED illuminates for 3 seconds when the ignition switch is in the ON position. After that they will switch off at normal operation of the system. If there are some problems in the system, the SOS indicator light illuminates in the instrument cluster.

### Automatic accident reporting



The Pan-European eCall device automatically makes an emergency call to the Public Safety Answering Point (PSAP) for proper rescuing operations in event of vehicle accident.

For proper emergency services and support the Pan-European eCall system automatically transmits the accident data to the Public Safety Answering Point (PSAP) when a traffic accident is detected.

In this case, the emergency call cannot be hung up by pressing the SOS button and the Pan-European eCall system remains connected until the emergency service officer, receiving the call, disconnects the emergency call.


In minor traffic accidents the Pan-European eCall system may not execute an emergency call. However, an emergency call may be made manually by pressing the SOS button.



### **CAUTION**

Operation of the system is impossible in case of absence of mobile transmission and GPS and Galileo signals.

### Manual accident reporting



The driver or passenger manually can make an emergency call in the Public Safety Answering Point(PSAP), by pressing SOS button to call the necessary emergency services.

A call to the emergency services through the Pan-European eCall system can be cancelled by pressing the SOS button again only before the call connection.

After activation of emergency call in the manual mode (for proper emergency services and support), the Pan-European eCall system automatically transmits the road accident data / or data on other accident to the officer of the Public Safety Answering Point(PSAP) (during emergency call) by pressing the SOS button.

If the driver or passenger accidentally presses the SOS button, it can be cancelled by pressing the button again.

In case of road accident or other accident for activation of emergency call in manual mode it is necessary:

- Stop the vehicle in accordance with traffic rules to ensure safety to yourself and other participants of road traffic;
- 2. Press the SOS button, when pressing the button SOS registration of the device in the wireless telephonic communication networks is carried out, minimum data set about vehicle and its location is collected in accordance with of the technical requirements of the device. After that connection with the officer of the Pan-European eCall system is made for clearing up reasons (conditions) of the emergency call.
- After clearing up reasons of the emergency call, the officer of the Public Safety Answering Point(PSAP) sends emergency services and completes the emergency call.

If the emergency call is not carried out in accordance with the procedure, mentioned above, the emergency call will be considered as erroneous.

## **MARNING**

Emergency power supply of the Pan-European eCall system from the battery

- The Pan-European eCall system battery supplies power during 1 hour in case main power source of the vehicle is cut off due to the collision during the emergency situations.
- The Pan-European eCall system battery should be replaced every 4 years.

LED illumination in red (system malfunction)

If red LED illuminates in normal driving conditions, this can indicate malfunction of the Pan-European eCall system. We recommend that you have the Pan-European eCall system checked by a HYUNDAI authorised repairer as soon as possible. Otherwise correct operation of the Pan-European eCall system device, installed in your vehicle is not guaranteed. Owner of the vehicle incurs liability for consequences, occurred as a result of nonobservance of conditions, mentioned above.

### **Arbitrary Removal or Modification**

The Pan-European eCall system calls emergency services for assistance. Thus, any arbitrary removal or changes to the Pan-European eCall system settings may affect your driving safety. Also, it may even make an erroneous emergency call to the Public Safety Answering Point (PSAP). Thereby, we kindly ask you not to make any changes by yourself or by the third parties in the settings of the equipment of the Pan-European eCall system, installed in your vehicle.

# 9. Maintenance

Engine compartment	9-3
Maintenance services Owner's responsibility Owner maintenance precautions	9-4
Owner maintenance Owner maintenance schedule	9-5
Scheduled maintenance services	9-7
Explanation of scheduled maintenance items	9-8
Engine oilChecking the engine oil level	9-11
Engine coolant	9-14
Brake/Clutch fluidChecking the brake/clutch fluid level	
Washer fluidChecking the washer fluid level	
Parking brakeChecking the parking brake	
Air cleanerFilter replacement	
Climate control air filter Filter inspection Filter replacement	9-22
Wiper bladesBlade inspectionBlade replacement	9-24
Battery For best battery service	
Battery capacity label	
Battery recharging	
Reset items	9-29

	Tyres and wheels	
	Tyre care	
	Recommended cold tyre inflation pressures	
	Check tyre inflation pressure	
	Tyre rotation	
	Wheel alignment and tyre balance	
	Tyre replacement	
	Wheel replacement	
	Tyre traction	
	Tyre maintenance	
	Tyre sidewall labelling	
	Low aspect ratio tyres	
	Fuses	
	Instrument panel fuse replacement	
	Engine compartment panel fuse replacement	
	Fuse/relay panel description	9-42
	Light bulbs	
	Headlight, position light, turn signal light, fog light and daytime	
	running light, low beam assist-static light bulb replacement	
	Headlight and front fog light aiming	9-61
	Side repeater light replacement	9-66
	Rear combination light bulb replacement	9-66
	High mounted stop light replacement	9-68
	License plate light bulb replacement	9-68
	Interior light bulb replacement	9-69
a	Appearance care	9-70
9	Exterior care	9-70
	Interior care	9-76
	Emission control system	
	Crankcase emission control system	
	2. Evaporative emission control system	9-79
	3. Exhaust emission control system	9-80

### **ENGINE COMPARTMENT**

■ Smartstream G1.0



■ Smart stream G1.0 T-GDi



■ Smartstream G1.2



The actual engine room in the vehicle may differ from the illustration.

OAC3089001R/OAC3N080001R/OAC3089002R

- 1. Engine coolant reservoir
- 2. Engine oil filler cap
- 3. Brake/clutch\* fluid reservoir
- 4. Air cleaner
- 5. Fuse box

- 6. Battery
- 7. windscreen washer fluid reservoir
- 8. Radiator cap
- 9. Engine oil dipstick
- \*: if equipped

### **MAINTENANCE SERVICES**

You should exercise the utmost care to prevent damage to your vehicle and injury to yourself whenever performing any maintenance or inspection procedures.

We recommend you have your vehicle maintained and repaired by a HYUN-DAI authorised repairer. A HYUNDAI authorised repairer meets HYUNDAI's high service quality standards and receives technical support from HYUN-DAI in order to provide you with a high level of service satisfaction.

### Owner's responsibility

Maintenance service and record retention are the owner's responsibility.

You should retain documents that show proper maintenance has been performed on your vehicle in accordance with the scheduled maintenance service charts shown on the following pages. You need this information to establish your compliance with the servicing and maintenance requirements of your vehicle warranties.

Detailed warranty information is provided in your Warranty Booklet.

Repairs and adjustments required as a result of improper maintenance or a lack of required maintenance are not covered.

# Owner maintenance precautions

Inadequate, incomplete or insufficient servicing may result in operational problems with your vehicle that could lead to vehicle damage, an accident, or personal injury. This chapter provides instructions only for the maintenance items that are easy to perform.

Your vehicle should not be modified in any way. Such modifications may adversely affect the performance, safety or durability of your vehicle and may, in addition, violate conditions of the limited warranties covering the vehicle.

### NOTICE

Improper owner maintenance during the warranty period may affect warranty coverage. For details, read the separate Warranty Booklet provided with the vehicle. If you're unsure about any servicing or maintenance procedure, we recommend that the system be serviced by a HYUNDAI authorised repairer.

### **OWNER MAINTENANCE**

### **⚠** WARNING

Performing maintenance work on a vehicle can be dangerous. If you lack sufficient knowledge and experience or the proper tools and equipment to do the work, we recommend that the system be serviced by a HYUNDAI authorised repairer. AL-WAYS follow these precautions for performing maintenance work:

- · Park your vehicle on level ground, move the shift lever into the N (Neutral, for Automated Manual Transmission vehicle) position or 1st gear (for Manual transmission vehicle) position, apply the parking brake, and place the ignition switch in the LOCK/ OFF position.
- Block the tyres (front and back) to prevent the vehicle from moving. Remove loose clothing or iewellery that can become entangled in moving parts.
- · If you must run the engine during maintenance, do so in an outdoor area or in an area with plenty of ventilation.
- · Keep flames, sparks, or smoking materials away from the battery and fuel-related parts.

The following lists are vehicle checks and inspections that should be performed by the owner or a HYUNDAI authorised repairer at the frequencies indicated to help ensure safe, dependable operation of your vehicle.

Any adverse conditions should be brought to the attention of your dealer as soon as possible.

These Owner Maintenance vehicle checks are generally not covered by warranties and you may be charged for labour, parts and lubricants used.

### Owner maintenance schedule When you stop for fuel:

- Check the coolant level in the engine coolant reservoir.
- Check the windscreen washer fluid level.
- Check for low or under-inflated tyres.
- Check the radiator and condenser. Check if the front of the radiator and condenser are clean and not blocked with leaves, dirt or insects, etc.

If any of the above parts are extremely dirty or you are not sure of their condition, we recommend that you contact a HYUNDAI authorised repairer.



### **!** WARNING

Be careful when checking your coolant level if the engine is hot. This may result in coolant being blown out of the opening and cause serious burns and other injuries.

### Whilst operating your vehicle:

- Note any changes in the sound of the exhaust or any smell of exhaust fumes in the vehicle.
- Check for vibrations in the steering wheel. Notice if there is any increased steering effort or looseness in the steering wheel, or change in its straight-ahead position.
- Notice if your vehicle constantly turns slightly or "pulls" to one side when travelling on smooth, level road.
- When stopping, listen and check for unusual sounds, pulling to one side, increased brake pedal travel or "hardto-push" brake pedal.
- If any slipping or changes in the operation of your transmission occurs, check the transmission fluid level.
- · Check the parking brake.
- Check for fluid leaks under your vehicle (water dripping from the air conditioning system during or after use is normal).

### At least monthly:

- Check coolant level in the engine coolant reservoir.
- Check the operation of all exterior lights, including the stoplights, turn signals and hazard warning flashers.
- Check the inflation pressures of all tyres including the spare for tyres that are worn, show uneven wear, or are damaged.
- · Check for loose wheel lug nuts.

### At least twice a year: (for example, every Spring and Autumn)

- Check radiator, heater and air conditioning hoses for leaks or damage.
- Check windscreen washer spray and wiper operation. Clean wiper blades with a clean cloth dampened with washer fluid.
- · Check headlight alignment.
- Check muffler, exhaust pipes, shields and clamps.
- Check the seat belts for wear and function.

### At least once a year:

- · Clean body and door drain holes.
- Lubricate door hinges and bonnet hinges.
- Lubricate door and bonnet locks and latches.
- Lubricate door rubber weather strips.
- · Lubricate door checker
- Check the air conditioning system.
- Inspect and lubricate Automated manual transmission linkage and controls.
- Clean the battery and terminals.
- Check the brake fluid level.

### SCHEDULED MAINTENANCE SERVICES

Follow Normal Maintenance Schedule if the vehicle is usually operated where none of the following conditions apply.

If any of the following conditions apply, you must follow the Maintenance Under Severe Usage Conditions.

- Repeated driving short distance of less than 5 mi. (8 km) in normal temperature or less than 10 mi. (16 km) in freezing temperature
- · Low speed driving for long distances
- Driving on rough, dusty, muddy, unpaved, graveled or salt-spread roads
- Driving in areas using salt or other corrosive materials or in very cold weather
- Driving in heavy dust condition
- · Driving in heavy traffic area
- · Driving on uphill, downhill, or mountain roads repeatedly
- Towing a trailer or using a camper, or driving with loads on the roof
- Driving as a patrol car, taxi, other commercial use of vehicle towing
- Frequently driving under high speed or rapid acceleration/deceleration
- Frequently driving in stop-and-go conditions
- Engine oil usage which is not recommended (Mineral type, Semi-synthetic, Lower grade, etc.)

If your vehicle is operated under the above conditions, you should inspect, replace or refill more frequently than Normal Maintenance Schedule which is provided in your Service Passport.



### Information

- As it is normal for engine oil to be consumed during driving, the engine oil level should be checked on regular basis.
- The engine oil change interval for normal operating conditions is based on the use of the recommended engine specification. If the recommended engine oil specification is not used, then replace the engine oil according to the maintenance schedule under severe operating conditions.

### **EXPLANATION OF SCHEDULED MAINTENANCE ITEMS**

### **Engine oil and filter**

The engine oil and filter should be changed at the intervals specified in the maintenance schedule. If the vehicle is being driven in severe conditions, more frequent oil and filter changes are required.

### **Drive belts**

Inspect all drive belts for evidence of cuts, cracks, excessive wear or oil saturation and replace if necessary. Drive belts should be checked periodically for proper tension and adjusted as necessary.



### CAUTION

When you are inspecting the belt, place the ignition switch to the lock/ off or ACC position.

### **Fuel filter**

This petrol powered vehicle is equipped with a lifetime fuel filter that is integrated with the fuel tank. Regular maintenance or replacement is not needed; however, the quality of fuel used may impact the frequency of maintenance needed. If there are any fuel related problems like fuel flow restriction, surging, loss of power, hard starting problem etc, fuel filter inspection or replacement may be needed. We recommend the fuel filter be inspected or replaced by a HYUNDAI authorised repairer.

## Fuel lines, fuel hoses and connections

Check the fuel lines, fuel hoses and connections for leakage and damage. We recommend that the fuel lines, fuel hoses and connections be replaced by a HYUNDAI authorised repairer.

### Vapour hose and fuel filler cap

The vapour hose and fuel filler cap should be inspected at those intervals specified in the maintenance schedule. Make sure that a new vapour hose or fuel filler cap is correctly replaced.

# Vacuum crankcase ventilation hoses (if equipped)

Inspect the surface of hoses for evidence of heat and/or mechanical damage. Hard and brittle rubber, cracking, tears, cuts, abrasions, and excessive swelling indicate deterioration. Particular attention should be paid to examine those hose surfaces nearest to high heat sources, such as the exhaust manifold.

Inspect the hose routing to assure that the hoses do not come in contact with any heat source, sharp edges or moving component which might cause heat damage or mechanical wear. Inspect all hose connections, such as clamps and couplings, to make sure they are secure, and that no leaks are present. Hoses should be replaced immediately if there is any evidence of deterioration or damage.

### Air cleaner filter

We recommend that the air cleaner filter be replaced by a HYUNDAI authorised repairer.

# Spark plugs (for petrol engine)

Make sure to install new spark plugs of the correct heat range.

When assembling parts, be sure to wipe out foreign substances inside and outside of the boot bottom of the ignition coil and the insulator of the spark plug with a soft cloth to prevent contamination of the spark plug insulator.

## **MARNING**

Do not disconnect and inspect spark plugs when the engine is hot. You may burn yourself.

### **Cooling system**

Check the cooling system parts, such as radiator, coolant reservoir, hoses and connections for leakage and damage. Replace any damaged parts.

### **Engine coolant**

The coolant should be changed at the intervals specified in the maintenance schedule.

# Manual transmission fluid (if equipped)

Inspect the manual transmission fluid according to the maintenance schedule.

# Automated manual transmission fluid (if equipped)

Inspect the Automated manual transmission fluid according to the maintenance schedule.

### NOTICE

The use of non-specified fluid (even marked as compatible with genuine) could result in shift quality deterioration and vibrations, eventually, the transmission failure.

Use only specified Automated manual transmission fluid. (Refer to "Recommended lubricants and capacities" in chapter 2.)

#### **Brake hoses and lines**

Visually check for proper installation, chafing, cracks, deterioration and any leakage. Replace any deteriorated or damaged parts immediately.

#### **Brake/clutch fluid (if equipped)**

Check brake/clutch fluid level in the brake fluid reservoir. The level should be between "MIN" (Minimum) and "MAX" (Maximum) marks on the side of the reservoir. Use only hydraulic brake/clutch fluid conforming to DOT4 specification.

#### Parking brake

Inspect the parking brake system including the parking brake lever and cables

# Rear brake drums and linings (if equipped)

Check the rear brake drums and linings for scoring, burning, leaking fluid, broken parts, and excessive wear.

#### Brake pads, calipers and rotors

Check the pads for excessive wear, discs for run out and wear, and calipers for fluid leakage.

For more information on checking the pads or lining wear limit, refer to the HYUNDAI web site.

(http://service.hyundai-motor.com)

#### **Suspension mounting bolts**

Check the suspension connections for looseness or damage. Retighten to the specified torque.

# Steering gear box, linkage & boots/lower arm ball joint

With the vehicle stopped and engine off, check for excessive free-play in the steering wheel.

Check the linkage for bends or damage. Check the dust boots and ball joints for deterioration, cracks, or damage. Replace any damaged parts.

#### **Drive shafts and boots**

Check the drive shafts, boots and clamps for cracks, deterioration, or damage. Replace any damaged parts and, if necessary, repack the grease.

# Air conditioning refrigerant/compressor


Check the air conditioning lines and connections for leakage and damage.

#### **ENGINE OIL**

#### Checking the engine oil level

Engine oil is used for lubricating, cooling, and operating various hydraulic components in the engine. Engine oil consumption whilst driving is normal, and it is necessary to check and refill the engine oil regularly. Also, check and refill the oil level within the recommended maintenance schedule to prevent deterioration of oil performance.

Check the engine oil following the below procedure.



- Follow all of the oil manufacturer's precautions.
- Be sure the vehicle is on the level ground in P (Park) with the parking brake set and the wheels blocked.
- Turn the engine on and warm the engine up until the coolant temperature reaches a constant normal temperature.
- Turn the engine off, remove the oil filler cap and pull the dipstick out. Wait for 15 minutes for the oil to return to the oil pan.
- 5. Wipe the dipstick clean and re-insert it fully.
- Pull the dipstick out again and check the level. The level should be between F (Full) and L (Low).


## **⚠** WARNING

#### Radiator hose

Be very careful not to touch the radiator hose when checking or adding the engine oil as it may be hot enough to burn you.

#### NOTICE

- Do not overfill the engine oil. It may damage the engine.
- Do not spill engine oil, when adding or changing engine oil. If you drop the engine oil on the engine room, wipe it off immediately.
- When you wipe the oil level gauge, you should wipe it with a clean cloth. When mixed with debris, it can cause engine damage.



7. If the oil level is near or below the L, add enough oil to bring the level to F. Use a funnel to help prevent oil from being spilled on engine components. Use only the specified engine oil. (Refer to "Recommended lubricants and capacities" in chapter 2.)

#### NOTICE

To prevent damage to your engine:

- Do not spill engine oil when adding or changing engine oil. Wipe off spilled oil immediately.
- The engine oil consumption may increase whilst you break in a new vehicle and it will be stabilized after driving 4,000 miles (6,000 km).
- The engine oil consumption can be affected by driving habits, climate conditions, traffic conditions, oil quality, etc. Therefore, it is recommended that you inspect the engine oil level regularly and refill it if necessary.

## Checking the engine oil and filter



- We recommend that the engine oil and filter be replaced by a HYUNDAI authorised repairer.
- If the maintenance schedule to replace engine oil is exceeded, the engine oil performance may deteriorate, and the engine condition may be affected. Therefore, replace the engine oil according to the maintenance schedule.
- To keep the engine in optimal condition, use the recommended engine oil and filter. If the recommended engine oil and filter are not used, replace it according to the maintenance schedule under severe usage conditions.
- The purpose of the maintenance schedule for engine oil replacement is to prevent oil deterioration and it is irrelevant to oil consumption. Check and refill engine oil regularly.

## Information

When the oil pressure is low due to insufficient engine oil, the Engine Oil Pressure ( ) warning light will illuminate. In addition, the enhanced engine protection system, which limits the engine's power is activated and the Malfunction Indicator Light ( ) will illuminate when the vehicle is driven in this state continuously. When oil pressure is restored, the Engine Oil Pressure warning light will turn off and the engine power will no longer be limited.

## **CAUTION**

The engine oil is very hot immediately after the vehicle has been driven and can cause burns during replacement. Replace the engine oil after the engine oil has cooled down.

### **WARNING**

Used engine oil may cause irritation or cancer of the skin if left in contact with the skin for prolonged periods of time. Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing your hands thoroughly with soap and warm water as soon as possible after handling used oil.

#### NOTICE

Never add any additives to the engine oil. Engine oil additives can change the properties of engine oil and may cause serious engine failure.

#### **ENGINE COOLANT**

The high-pressure cooling system has a reservoir filled with year-round anti-freeze coolant. The reservoir is filled at the factory.

Check the antifreeze protection and coolant concentration level at least once a year, at the beginning of the winter season, and before travelling to a colder climate.

#### NOTICE

- When the engine overheats from low engine coolant, suddenly adding engine coolant may cause cracks in the engine. To prevent damage, add engine coolant slowly in small quantities.
- Do not drive with no engine coolant. It may cause water pump failure and engine seizure, etc.

#### Checking the coolant level



Check the condition and connections of all cooling system hoses and heater hoses. Replace any swollen or deteriorated hoses.

The coolant level should be filled between F (Full) and L (Low) marked on the side of the coolant reservoir when the engine is cool.

If the coolant level is low, add enough distilled (deionized) water.

Bring the level to F (Full), but do not overfill. If frequent additions are required, we recommend that the system be inspected by a HYUNDAI authorised repairer.

#### Recommended engine coolant


- When adding coolant, use only distilled (deionized) water for your vehicle and never mix hard water in the coolant filled at the factory. An incorrect coolant mixture can result in serious malfunction or engine damage.
- The engine in your vehicle has aluminium engine parts and must be protected by an phosphate based ethylene-glycol coolant to prevent corrosion and freezing.
- DO NOT USE alcohol or methanol coolant or mix them with the specified coolant.
- Do not use a solution that contains more than 60% antifreeze or less than 35% antifreeze, which would reduce the effectiveness of the solution.

For mixture percentage, refer to the following table.

Ambient	Mixture Percentage (volume)		
Temperature	Antifreeze	Water	
-15°C (5°F)	35	65	
-25°C (-13°F)	40	60	
-35°C (-31°F)	50	50	
-45°C (-49°F)	60	40	

## *i* Information

If in doubt about the mix ratio, a 50% water and 50% antifreeze mix is the easiest to mix together as it will be the same quantity of each. It is suitable to use for most temperature ranges of -35°C (-31°F) and higher.



## **⚠** WARNING



Never remove the radiator cap or the drain plug whilst the engine and radiator are hot. Hot coolant and steam may blow out

under pressure, causing serious injury.

Turn the engine off and wait until the engine cools down. Use extreme care when removing the radiator cap. Wrap a thick towel around it, and turn it counterclockwise slowly to the first stop. Step back whilst the pressure is released from the cooling system. When you are sure all the pressure has been released, press down on the cap, using a thick towel, and continue turning counterclockwise to remove it.

## **⚠** WARNING



The electric motor for the cooling fan may continue to operate or start up when the engine is not running and can cause

serious injury.

Keep hands, clothing and tools away from the rotating fan blades of the cooling fan.

#### Changing the engine coolant

We recommend that the coolant be replaced by a HYUNDAI authorised repairer.

#### NOTICE

Put a thick cloth or fabric around the radiator cap before refilling the coolant in order to prevent the coolant from overflowing into engine parts such as alternator.



#### WARNING

Do not use engine coolant or antifreeze in the washer fluid reservoir. Engine coolant can severely obscure visibility when sprayed on the windscreen and may cause loss of vehicle control or damage to paint and body trim.

#### **BRAKE/CLUTCH FLUID (IF EQUIPPED)**

# Checking the brake/clutch fluid level



Check the fluid level in the reservoir periodically. The fluid level should be between MAX and MIN marks on the side of the reservoir.

Before removing the reservoir cap and adding brake/clutch fluid, clean the area around the reservoir cap thoroughly to prevent brake/clutch fluid contamination.

If the level is low, add fluid to the MAX level. The level will fall with accumulated mileage. This is a normal condition associated with the wear of the brake linings.

If the fluid level is excessively low,

we recommend that the system be checked by a HYUNDAI authorised repairer.

## *i* Information

Use only the specified brake/clutch fluid. Refer to "Recommended lubricants and capacities" in chapter 2.

### Information

Before removing the brake/clutch filler cap, read the warning on the cap.

### *i* Information

Clean the filler cap before removing. Use only DOT4 brake/clutch fluid from a sealed container.

### **MARNING**

If the brake/clutch system requires frequent additions of fluid this could indicate a leak in the brake/clutch system. We recommend that the vehicle be inspected by a HYUNDAI authorised repairer.

## **MARNING**

Do not let brake/clutch fluid enter into your eyes. If brake/clutch fluid gets in your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention.

#### NOTICE

- Do not allow brake/clutch fluid to contact the vehicle's body paint, as it will result in paint damage.
- NEVER use brake/clutch fluid which has been exposed to open air for an extended time, as its quality cannot be guaranteed. It should be disposed of properly.
- Don't put in the wrong type of fluid. A few drops of mineral-based oil, such as engine oil in your brake/clutch system can damage system parts.

# WASHER FLUID Checking the washer fluid level



Check the fluid level in the washer fluid reservoir and add fluid if necessary.

Plain water may be used if washer fluid is not available

However, use washer solvent with antifreeze characteristics in cold climates to prevent freezing.



#### **WARNING**

To prevent serious injury or death, take the following safety precautions when using washer fluid:

- Do not use engine coolant or antifreeze in the washer fluid reservoir. Engine coolant can severely obscure visibility when sprayed on the windscreen and may cause loss of vehicle control resulting in an accident or damage to paint and body trim.
- Do not allow sparks or flames to contact the washer fluid or the washer fluid reservoir. Washer fluid may contain alcohol and can be flammable.
- Do not drink washer fluid and avoid contact with skin. Washer fluid is poisonous to humans and animals.
- Keep washer fluid away from children and animals.

# PARKING BRAKE Checking the parking brake



Check the stroke of the parking brake by counting the number of "clicks" heard whilst fully applying it from the released position.

Also, the parking brake alone should securely hold the vehicle on a fairly steep grade. If the stroke is more or less than specified, we recommend that the system be inspected by a HYUN-DAI authorised repairer.

Stroke : 5-7 "clicks" at a force of 20 kg (44 lbs, 196 N).

#### **AIR CLEANER**

#### Filter replacement

#### Type A



The air cleaner filter can be cleaned for inspection using compressed air.

Do not attempt to wash or to rinse it, as water will damage the filter.


If soiled, the air cleaner filter must be replaced.





Remove the cleaner cover by opening the clips.

- 2. Remove the used filter and wipe the inside of the air cleaner housing to remove dust in cover housing.
- Replace the new filter with clean hands and ensure the rubber gasket is not taken off.
- Reassemble in the reverse order of removal




5. The protrusions in the filter should be mounted either on the left or right side of the air cleaner upper side. If incorrectly installed to the bottom side, it may be difficult to assemble.


Type B




The air cleaner filter can be cleaned for inspection using compressed air. Do not attempt to wash or to rinse it, as water will damage the filter. If soiled, the air cleaner filter must be replaced.



1. Push the open button in the direction of the arrow (1).



 Open the air cleaner filter cover by lifting the lock(2) in the direction of the arrow.



- 3. Pull down the lever to the "UNLOCK" position.
- 4. Remove the used filter and wipe the inside of the air cleaner housing to remove dust in cover housing.
- 5. Replace the new filter with clean hands and ensure the rubber gasket is not taken off.

## *i* Information

If the vehicle is operated in extremely dusty or sandy areas, replace the element more often than the usual recommended intervals.

#### NOTICE

- Do not drive with the air cleaner filter removed. This will result in excessive engine wear.
- When removing the air cleaner filter, be careful that dust or dirt does not enter the air intake, or damage may result.
- Use HYUNDAI genuine parts or the equivalent speficied for your vehicle. Use of parts without the matching quality could damage the engine.

# CLIMATE CONTROL AIR FILTER

#### **Filter inspection**


The climate control air filter should be replaced according to the Maintenance Schedule. If the vehicle is operated in severely air-polluted cities or on dusty rough roads for a long period, it should be inspected more frequently and replaced earlier. When you replace the climate control air filter, replace it performing the following procedure, and be careful to avoid damaging other components.

Replace the filter according to the Maintenance Schedule.

#### Filter replacement




1. Open the glove box.



Push in both sides of the glove box as shown. This will ensure that the glove box stopper pins will get released from its holding location allowing the glove box to hang.



3. Remove the climate control air filter cover.



- 4. Replace the climate control air filter.
- 5. Reassemble in the reverse order of disassembly.

#### NOTICE

Install a new climate control air filter in the correct direction with the arrow symbol (1) facing downwards, otherwise, it may be noisy and the effectiveness of the filter may be reduced.

#### **WIPER BLADES**

#### **Blade inspection**

Contamination of either the windscreen or the wiper blades with foreign matter can reduce the effectiveness of the windscreen wipers.

Common sources of contamination are insects, tree sap, and hot wax treatments used by some commercial car washes. If the blades are not wiping properly, clean both the window and the blades with a good cleaner or mild detergent, and rinse thoroughly with clean water.

#### NOTICE

To prevent damage to the wiper blades, arms or other components, do not:

- Use petrol, kerosene, paint thinner, or other solvents on or near them.
- Attempt to move the wipers manually.
- · Use non-specified wiper blades.

## Information

Commercial hot waxes applied by automatic car washes have been known to make the windscreen difficult to clean.

## *i* Information

Wiper blades are consumable item. Normal wear of the wipers may not be covered by your vehicle warranty.

#### **Blade replacement**


When the wipers no longer clean adequately, the blades may be worn or cracked, and require replacement.



#### CAUTION

Do not allow the wiper arm to fall against the windscreen, since it may chip or crack the windscreen.

#### Front windscreen wiper blade



- 1. Lift up the wiper blade clip. Then lift up the wiper blade.
- 2. Whilst pushing the lock (1), pull down the wiper blade (2).



- 3. Remove the wiper blade from the wiper arm.
- 4. Install a new wiper blade assembly in the reverse order of removal.
- Return the wiper arm on the windscreen.

# Rear window wiper blade (if equipped)



- 1. Raise the wiper arm and rotate the wiper blade assembly (1).
- 2. Pull out the wiper blade assembly.



- Install the new blade assembly by inserting the centre part into the slot in the wiper arm until it clicks into place.
- Make sure the blade assembly is installed firmly by trying to pull it slightly.

To prevent damage to the wiper arms or other components, we recommend that the wiper blade be replaced by a HYUNDAI authorised repairer.

#### **BATTERY**

#### For best battery service




- · Keep the battery securely mounted.
- · Keep the battery top clean and dry.
- Keep the terminals and connections clean, tight, and coated with petroleum jelly or terminal grease.
- Rinse any spilled electrolyte from the battery immediately with a solution of water and baking soda.
- If the vehicle is not going to be used for an extended time, disconnect the battery cables.

## i

#### Information

 For batteries marked with UPPER and LOWER



If your vehicle is equipped with a battery marked with LOWER (MIN) and UPPER (MAX) on the side, you should check the electrolyte level. The electrolyte level should be between LOWER (MIN) and UPPER (MAX). When the electrolyte level is low, add distilled (or de-mineralized) water. (Never add sulfuric acids or other electrolyte).

Be careful not to spill distilled (or demineralized) water over the battery surface or other adjacent components.

Also, do not overfill the battery cells.

If not, it may corrode the battery or other components. Finally, securely close the cell cap. However, we recommend you to contact a HYUNDAI authorised repairer for better battery service.



#### ! WARNING

To prevent SERIOUS INJURY or DEATH to you or bystanders, always follow these precautions when working near or handling the battery:



Always read and follow instructions carefully when handling a battery.



Wear eye protection designed to protect the eyes from acid splashes.



Keep all flames, sparks, or smoking materials away from the battery.



Hydrogen is always present in battery cells, is highly combustible, and may explode if ignited.



Batteries contain sulfuric acid which is highly corrosive. Do not allow acid to contact your eyes, skin or clothing.

If acid gets into your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If acid gets on your skin, thoroughly wash the area. If you feel pain or a burning sensation, get medical attention immediately.

- When lifting a plastic-cased battery, excessive pressure on the case may cause battery acid to leak. Lift with a battery carrier or with your hands on opposite corners.
- Do not attempt to jump start your vehicle if your battery is frozen.
- NEVER attempt to recharge the battery when the vehicle's battery cables are connected to the battery.
- The electrical ignition system works with high voltage. NEVER touch these components with the engine running or when the ignition switch is in the ON position.
- Do not allow the (+) and (-) jumper cables to touch. It may cause sparks.


- The battery may rupture or explode when you jump start with a low or frozen battery.
- Leaked battery electrolyte due to repeated driving on sharp curves (for example, on circuits) may cause safety problem. Avoid repeated driving on sharp curves.

#### NOTICE

Always follow these instructions when handling your vehicle's battery to prevent damage to your battery:

- When you do not use the vehicle for a long time in a low temperature area, disconnect the battery and keep it indoors.
- Always charge the battery fully to prevent battery case damage in low temperature areas.
- Prevent liquid from wetting the battery terminals. The performance of the battery may be degraded, and may cause injury. Be cautious when loading liquid in the boot.
- · Do not tilt the battery.
- If you connect unauthorised electronic devices to the battery, the battery may be discharged. Never use unauthorised devices.

#### **Battery capacity label**



- \* The actual battery label in the vehicle may differ from the illustration.
- 1. AGM50L-DIN : The HYUNDAI model name of battery
- 2. 12V: The nominal voltage
- 3. 50Ah (20HR) : The nominal capacity (in Ampere hours)
- 4. RC 80 : The nominal reserve capacity (in min.)
- CCA 560A : Cold-test current in amperes by SAE/EN

#### **Battery recharging**

Your vehicle has a maintenance-free, calcium-based battery.

- If the battery becomes discharged over a short time (because, for example, the headlights or interior lights were left on whilst the vehicle was not in use), recharge it by slow charging (trickle) for 10 hours.
- If the battery gradually discharges because of high electrical load whilst the vehicle is being used, recharge it at 20-30A for two hours.

## **WARNING**

When recharging the battery, observe the following precautions:

- Before performing maintenance or recharging the battery, turn off all accessories and stop the engine.
- Do not allow cigarettes, sparks, or flame near the battery.
- Wear eye protection when checking the battery during charging.
- The battery must be removed from the vehicle and placed in an area with good ventilation.
- Watch the battery during charging, and stop or reduce the charging rate if the battery cells begin gassing (boiling) violently or if the temperature of the electrolyte of any cell exceeds 49°C (120°F).
- The negative battery cable must be removed first and installed last when the battery is disconnected.
- Disconnect the battery charger in the following order.
  - 1. Turn off the battery charger main switch.
  - 2. Unhook the negative clamp from the negative battery terminal
  - 3. Unhook the positive clamp from the positive battery terminal.

#### NOTICE

AGM battery (if equipped)

- Absorbent Glass Mat (AGM) batteries are maintenance-free and we recommend that the AGM battery be serviced by a HYUNDAI authorised repairer. For charging your AGM battery, use only fully automatic battery chargers that are specially developed for AGM batteries.
- When replacing the AGM battery, we recommend that you use parts for replacement from a HYUNDAI authorised repairer.
- Do not open or remove the cap on top of the battery. This may cause leaks of internal electrolyte that could result in severe injury.

#### By jump starting

After a jump start from a good battery, drive the vehicle for at least 30 minutes or operate at idle for at least 60 minutes before it is shutoff. The vehicle may not restart if you shut it off before the battery had a chance to adequately recharge. See "Jump Starting" in chapter 8 for more details on jump starting procedures.

## information



An inappropriately disposed battery can be harmful to the environment and human health. Dispose of the battery according to your local law(s) or regulation.

#### **Reset items**

Items should be reset after the battery has been discharged or the battery has been disconnected.

- Auto up/down window (See chapter 5)
- Trip computer (See chapter 4)
- Climate control system (See chapter 5)

#### **TYRES AND WHEELS**



#### **! WARNING**

Tyre failure may cause loss of vehicle control resulting in an accident. To reduce risk of SERIOUS INJURY or DEATH, take the following precautions:

- Inspect your tyres monthly for proper inflation as well as wear and damage.
- The recommended cold tyre pressure for your vehicle can be found in this manual and on the tyre label located on the driver's side centre pillar. Always use a tyre pressure gauge to measure tyre pressure. Tyres with too much or too little pressure wear unevenly causing poor handling.
- Check the pressure of the spare every time you check the pressure of the other tyres on your vehicle.
- Replace tyres that are worn, show uneven wear, or are damaged.
   Worn tyres can cause loss of braking effectiveness, steering control, or traction.
- ALWAYS replace tyres with the same size as each tyre that was originally supplied with this vehicle. Using tyres and wheels other than the recommended sizes could cause unusual handling characteristics, poor vehicle control, or negatively affect your vehicle's Anti-Lock Brake System (ABS) resulting in a serious accident.

#### Tyre care

For proper maintenance, safety, and maximum fuel economy, you must always maintain recommended tyre inflation pressures and stay within the load limits and weight distribution recommended for your vehicle.



All specifications (sizes and pressures) can be found on a label attached to the left side centre pillar.

# Recommended cold tyre inflation pressures

All tyre pressures (including the spare) should be checked when the tyres are cold. "Cold tyres" means the vehicle has not been driven for at least three hours or has been driven for less than 1 mile (1.6 km).

Warm tyres normally exceed recommended cold tyre pressures by 28 to 41 kPa (4 to 6 psi). Do not release air from warm tyres to adjust the pressure or the tyres will be under-inflated. For recommended inflation pressure, refer to "Tyre and Wheels" in chapter 8.



#### **WARNING**

Recommended pressures must be maintained for the best ride, vehicle handling, and minimum tyre wear.

Over-inflation or under-inflation can reduce tyre life, adversely affect vehicle handling, and lead to sudden tyre failure that could result in loss of vehicle control resulting in an accident.

Severe under-inflation can lead to severe heat build-up, causing blowouts, tread separation and other tyre failures that can result in the loss of vehicle control resulting in an accident. This risk is much higher on hot days and when driving for long periods at high speeds.

#### **NOTICE**

- Under-inflation results in excessive wear, poor handling and reduced fuel economy. Wheel deformation is also possible. Keep your tyre pressures at the proper levels. If a tyre frequently needs refilling, we recommend it be checked by a HYUNDAI authorised repairer.
- Over-inflation produces a harsh ride, excessive wear at the centre of the tyre tread, and a greater possibility of damage from road hazards.

#### **Check tyre inflation pressure**

Check your tyres, including the spare tyre, once a month or more.

#### How to check

Use a good quality tyre pressure gauge to check tyre pressure. You can not tell if your tyres are properly inflated simply by looking at them. Radial tyres may look properly inflated when they are under-inflated.

Remove the valve cap from the tyre valve stem. Press the tyre gauge firmly onto the valve to get a pressure measurement. If the cold tyre inflation pressure matches the recommended pressure on the tyre and loading information label, no further adjustment is necessary. If the pressure is low, add air until you reach the recommended pressure. Make sure to put the valve caps back on the valve stems. Without the valve cap, dirt or moisture could get into the valve core and cause air leakage. If a valve cap is missing, install a new one as soon as possible.


If you overfill the tyre, release air by pushing on the metal stem in the centre of the tyre valve. Recheck the tyre pressure with the tyre gauge. Be sure to put the valve caps back on the valve stems. Without the valve cap, dirt or moisture could get into the valve core and cause air leakage. If a valve cap is missing, install a new one as soon as possible.

#### Tyre rotation

To equalize tread wear, HYUNDAI recommends that the tires be rotated according to the maintenance schedule or sooner if irregular wear develops.

During rotation, check the tyres for correct balance.

When rotating tyres, check for uneven wear and damage. Abnormal wear is usually caused by incorrect tyre pressure, improper wheel alignment, out-of-balance wheels, severe braking or severe cornering. Look for bumps or bulges in the tread or side of the tyre. Replace the tyre if you find any of these conditions. Replace the tyre if fabric or cord is visible. After rotation, be sure to bring the front and rear tyre pressures to specification and check lug nut tightness (proper torque is 11-13 kgf·m [79-94 lbf·ft]).



Disc brake pads should be inspected for wear whenever tyres are rotated.

### Information

The outside and inside of the unsymmetrical tyre is distinguishable. When installing an unsymmetrical tyre, be sure to install the side marked "outside" face the outside. If the side marked "inside" is installed on the outside, it will have a negative effect on vehicle performance.

### **MARNING**

- Do not use the compact spare tyre for tyre rotation.
- Do not mix bias ply and radial ply tyres under any circumstances.
   This may cause unusual handling characteristics that may cause loss of vehicle control resulting in an accident.

# Wheel alignment and tyre balance

The wheels on your vehicle were aligned and balanced carefully at the factory to give you the longest tyre life and best overall performance.

In most cases, you will not need to have your wheels aligned again. However, if you notice unusual tyre wear or your vehicle pulling one way or the other, the alignment may need to be reset.

If you notice your vehicle vibrating when driving on a smooth road, your wheels may need to be rebalanced.

#### NOTICE

Incorrect wheel weights can damage your vehicle's aluminium wheels. Use only approved wheel weights.

#### Tyre replacement



If the tyre is worn evenly, a tread wear indicator will appear as a solid band acros s the tread. This shows there is less than 1/16 in. (1.6 mm) of tread left on the tyre. Replace the tyre when this happens.

Do not wait for the band to appear across the entire tread before replacing the tyre.

## **MARNING**

To reduce the risk of DEATH or SE-RIOUS INJURY:

- Replace tyres that are worn, show uneven wear, or are damaged.
   Worn tyres can cause loss of braking effectiveness, steering control, and traction.
- Always replace tyres with the same size as each tyre that was originally supplied with this vehicle. Using tyres and wheels other than the recommended sizes could cause unusual handling characteristics, poor vehicle control, or negatively affect your vehicle's Anti-Lock Brake System (ABS) resulting in a serious accident.
- When replacing tyres (or wheels), it is recommended to replace the two front or two rear tyres (or wheels) as a pair. Replacing just one tyre can seriously affect your vehicle's handling.
- Tyres degrade over time, even when they are not being used. Regardless of the remaining tread, HYUNDAI recommends that tyres be replaced after six (6) years of normal service.
- Heat caused by hot climates or frequent high loading conditions can accelerate the aging process. Failure to follow this warning may cause sudden tyre failure, which could lead to a loss of vehicle control resulting in an accident.

# Compact spare tyre replacement (if equipped)

A compact spare tyre has a shorter tread life than a regular size tyre. Replace it when you can see the tread wear indicator bars on the tyre. The replacement compact spare tyre should be the same size and design tyre as the one provided with your new vehicle and should be mounted on the same compact spare tyre wheel. The compact spare tyre is not designed to be mounted on a regular size wheel, and the compact spare tyre wheel is not designed for mounting a regular size tyre.



#### WARNING

The original tyre should be repaired or replaced as soon as possible to avoid failure of the spare and loss of vehicle control resulting in an accident. The compact spare tyre is for emergency use only. Do not operate your vehicle over 50 mph (80 km/h) when using the compact spare tyre.

#### Wheel replacement

When replacing the metal wheels for any reason, make sure the new wheels are equivalent to the original factory units in diameter, rim width and offset.

#### Tyre traction

Tyre traction can be reduced if you drive on worn tyres, tyres that are improperly inflated or on slippery road surfaces. Tyres should be replaced when tread wear indicators appear. To reduce the possibility of losing control, slow down whenever there is rain, snow or ice on the road.


#### Tyre maintenance

In addition to proper inflation, correct wheel alignment helps to decrease tyre wear. If you find a tyre is worn unevenly, have a authorised repairer check the wheel alignment.

When you have new tyres installed, make sure they are balanced. This will increase vehicle ride comfort and tyre life. Additionally, a tyre should always be rebalanced if it is removed from the wheel.

#### Tyre sidewall labelling

This information identifies and describes the fundamental characteristics of the tyre and also provides the tyre identification number (TIN) for safety standard certification. The TIN can be used to identify the tyre in case of a recall.



# Manufacturer or brand name Manufacturer or brand name is shown.

#### 2. Tyre size designation

A tyre's sidewall is marked with a tyre size designation. You will need this information when selecting replacement tyres for your vehicle. The following explains what the letters and numbers in the tyre size designation mean.

Example tyre size designation:

(These numbers are provided as an example only; your tyre size designator could vary depending on your vehicle.)

#### 175/65R14 86T

175 - Tyre width in millimeters.

- 65 Aspect ratio. The tyre's section height as a percentage of its width.
- R Tyre construction code (Radial).
- 14 Rim diameter in inches.
- 86 Load Index, a numerical code associated with the maximum load the tyre can carry.
- T Speed Rating Symbol. See the speed rating chart in this section for additional information.

#### Wheel size designation

Wheels are also marked with important information that you need if you ever have to replace one. The following explains what the letters and numbers in the wheel size designation mean.

#### Example wheel size designation:

#### 5.5J X 14

5.5 - Rim width in inches.

J - Rim contour designation.

14 - Rim diameter in inches.

#### Tyre speed ratings

The chart below lists many of the different speed ratings currently being used for passenger vehicle tyres. The speed rating is part of the tyre size designation on the sidewall of the tyre. This symbol corresponds to that tyre's designed maximum safe operating speed.

Speed Rating Symbol	Maximum Speed
S	112 mph (180 km/h)
Т	118 mph (190 km/h)
Н	130 mph (210 km/h)
V	149 mph (240 km/h)
W	168 mph (270 km/h)
Υ	186 mph (300 km/h)

## 3. Checking tyre life (TIN : Tyre Identification Number)

Any tyres that are over six years old, based on the manufacturing date, (including the spare tyre) should be replaced by new ones. You can find the manufacturing date on the tyre sidewall (possibly on the inside of the wheel), displaying the DOT Code. The DOT Code is a series of numbers on a tyre consisting of numbers and English letters. The manufacturing date is designated by the last four digits (characters) of the DOT code.

#### DOT: XXXX XXXX OOOO

The front part of the DOT shows a plant code number, tyre size and tread pattern and the last four numbers indicate week and year manufactured.

For example:

DOT XXXX XXXX 1523 represents that the tyre was produced in the 15th week of 2023.

## 4. Tyre ply composition and material

The number of layers or plies of rubbercoated fabric in the tyre. Tyre manufacturers also must indicate the materials in the tyre, which include steel, nylon, polyester, and others. The letter "R" means radial ply construction; the letter "D" means diagonal or bias ply construction; and the letter "B" means belted-bias ply construction.

# 5. Maximum permissible inflation pressure

This number is the greatest amount of air pressure that should be put in the tyre. Do not exceed the maximum permissible inflation pressure. Refer to the Tyre and Loading Information label for recommended inflation pressure.

#### 6. Maximum load rating

This number indicates the maximum load in kilograms and pounds that can be carried by the tyre. When replacing the tyres on the vehicle, always use a tyre that has the same load rating as the factory installed tyre.

#### 7. Uniform tyre quality grading

Quality grades can be found where applicable on the tyre sidewall between tread shoulder and maximum section width

For example: TREADWEAR 200 TRACTION AA TEMPERATURE A

#### Tread wear

The tread wear grade is a comparative rating based on the wear rate of the tyre when tested under controlled conditions on a specified government test course. For example, a tyre graded 150 would wear one-and-a-half times (1½) as well on the government course as a tyre graded 100.

The relative performance of tyres depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

These grades are molded on the sidewalls of passenger vehicle tyres. The tyres available as standard or optional equipment on your vehicle may vary with respect to grade.

#### Traction - AA, A, B & C

The traction grades, from highest to lowest, are AA, A, B and C. Those grades represent the tyre's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tyre marked C may have poor traction performance.

## **MARNING**

The traction grade assigned to this tyre is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

#### Temperature - A, B & C

The temperature grades are A (the highest), then B and C representing the tyre's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel

Sustained high temperature can cause the material of the tyre to degenerate and reduce tyre life, and excessive temperature can lead to sudden tyre failure. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.



#### **!** WARNING

The temperature grade for this tyre is established for a tyre that is properly inflated and not overloaded. Excessive speed, under-inflation, overinflation, or excessive loading, either separately or in combination, can cause heat build-up and possible sudden tyre failure. This may cause loss of vehicle control resulting in an accident.

#### Low aspect ratio tyres

Low aspect ratio tyres, the aspect ratio is lower than 50, are provided for sporty looks.

Because low aspect ratio tyres are optimised for handling and braking, their sidewall is a little stiffer than a standard tyre. Also low aspect ratio tyres tend to be wider and consequently have a greater contact patch with the road surface. In some instances they may generate more road noise compared with standard tyres.




#### **CAUTION**

Because the sidewall of a low aspect ratio tyre is shorter than a standard tyre, the rim of the wheel and the tyre itself is more easily susceptible to damage. Use caution when driving and follow the guidelines below to help minimise damage to the wheel and tyre:

- · When driving on a rough road or driving off a road, be careful not to damage the tyres and wheels. After driving, inspect the tyres and wheels.
- · When passing over a pothole, speed bump, manhole, or curb stone, drive the vehicle slowly so as not to damage the tyres and wheels.
- · If the tyre is subjected to a severe impact, we recommend you have the tyre and wheel inspected by a HYUNDAI authorised repairer.
- Inspect the tyre condition and pressure every 1,800 miles (3,000 km) to prevent tyre damage.
- · It is not easy to recognise tyre damage with your own eyes. But if there is the slightest hint of tyre damage, have the tyre checked or replaced because the tyre damage may cause air leakage from the tvre.
- If the tyre is damaged by driving on a rough road, off road, pothole, manhole, or kerb stone, it will not be covered by the warranty.

#### **FUSES**



A vehicle's electrical system is protected from electrical overload damage by fuses

This vehicle has 2 (or 3) fuse panels, one located in the driver's side panel bolster, the other in the engine compartment.

If any of your vehicle's lights, accessories, or controls do not work, check the appropriate circuit fuse. If a fuse has blown, the element inside the fuse will be melted or broken.

If the electrical system does not work, first check the driver's side fuse panel. Before replacing a blown fuse, turn the engine and all switches off, and then disconnect the negative battery cable. Always replace a blown fuse with one of the same rating.

If the replacement fuse blows, this indicates an electrical problem. Avoid using the system involved. We recommend that you immediately consult a HYUNDAI authorised repairer.

### *i* Information

Three kinds of fuses are used: blade type for lower amperage rating, cartridge type, and multi fuse for higher amperage ratings.

### **MARNING**

NEVER replace a fuse with anything but another fuse of the same rating.

- A higher capacity fuse could cause damage and possibly cause a fire.
- Do not install a wire or aluminium foil instead of the proper fuse even as a temporary repair. It may cause extensive wiring damage and possibly a fire.

#### NOTICE

Do not use a screwdriver or any other metal object to remove fuses because it may cause a short circuit and damage the system.

# Instrument panel fuse replacement



- 1. Turn the vehicle off.
- 2. Turn all other switches OFF.
- 3. Open the fuse panel cover.
- Refer to the label on the inside of the fuse panel cover to locate the suspected fuse location.



- 5. Pull the suspected fuse straight out. Use the removal tool provided in the engine compartment fuses panel.
- Check the removed fuse; replace it if it is blown. Spare fuses are provided in the instrument panel fuse panels (or in the engine compartment fuse panel).

Push in a new fuse of the same rating, and make sure it fits tightly in the clips. If it fits loosely, we recommend that you consult a HYUNDAI authorised repairer.

In an emergency, if you do not have a spare fuse, use a fuse of the same rating from a circuit you may not need for operating the vehicle, such as the cigarette lighter fuse.

If the headlights or other electrical components do not work and the fuses are undamaged, check the fuse panel in the engine compartment. If a fuse is blown, it must be replaced with the same rating.

# Engine compartment panel fuse replacement




- 1. Turn the vehicle off.
- 2. Turn all other switches OFF.
- 3. Remove the fuse panel cover by pressing the tab and pulling up.
- Check the removed fuse; replace it if it is blown. To remove or insert the fuse, use the removal tool in the engine compartment fuse panel cover.
- Push in a new fuse of the same rating, and make sure it fits tightly in the clips. If it fits loosely, we recommend that you consult a HYUNDAI authorised repairer.

### NOTICE

from water contact.

After checking the fuse panel in the engine compartment, securely install the fuse panel cover. You may hear a clicking sound if the cover is securely latched. If it is not securely latched, electrical failure may occur

#### Multi fuse (Main fuse)



If the multi fuse is blown, it must be removed as follows:

- 1. Turn the vehicle off.
- 2. Disconnect the negative battery cable.
- 3. Remove the fuse panel cover by pressing the tab and pulling it up.
- 4. Remove the nuts shown in the picture above.
- 5. Replace the fuse with a new one of the same rating.
- Reinstall in the reverse order of removal.

If the multi fuse is blown, we recommend that you consult a HYUNDAI authorised repairer.


#### Fuse/relay panel description Driver's side fuse panel



Inside the fuse/relay box covers, you can find the fuse/relay label describing fuse/relay names and ratings.

### *i* Information

Not all fuse panel descriptions in this manual may be applicable to your vehicle. It is accurate at the time of printing. When you inspect the fuse box on your vehicle, refer to the fuse box label.



### Driver's side fuse panel

	FUSE NAME	SYMBOL	FUSE RATING	CIRCUIT PROTECTED
01	AIRBAG 2	2	10A	SRS Control Module
02	HEATED MIRROR	4	10A	A/C Control Module, Driver/ Passenger Power Outside MIrror
03	SAFETY P/ WINDOW	SAFETY	25A	Driver Safety Power Window Module
04	SEAT WARMER	₩/	20A	Driver/Passenger Seat Warmer Control Module
05	P/WINDOW RH	RH	25A	Power Window Main Switch, [LHD] Passenger Power Window Switch
06	TCU	τ <b>(</b>	10A	TCM, ATM Shift Lever, Back-Up Lamp Switch
08	MODULE 8	8 MODULE	10A	Hazard Door Lock Switch, Data Link Connector
09	MEMORY	MEMORY	10A	Outside Mirror Folding/Unfolding Relay, A/C Control Module, Instrument Cluster
12	P/WINDOW LH	LH	25A	Power Window Main Switch, [RHD] Passenger Power Window Switch
14	MODULE 2	2 MODULE	10A	Stop Lamp Switch
16	MULTIMEDIA	MULTI MEDIA	20A	A/V & Navigation Head Unit, Audio, Low DC-DC Converter
17	AIRBAG 1	1	10A	SRS Control Module
19	USB CHARGER	USB CHARGER	10A	Front USB Charger, Wireless Charger Indicator
20	A/C 3	³A/C	7.5A	A/C Control Module
21	DOOR LOCK		20A	Tailgate Unlock Relay, Door Lock/ Unlock Relay
22	E-CALL	E-CALL	7.5A	E-Call Unit


### Driver's side fuse panel

	FUSE NAME	SYMBOL	FUSE RATING	CIRCUIT PROTECTED
23	MODULE 5	5 MODULE	10A	Wireless Cjarger Unit, Data Link Connector, E-Call Unit, ATM Shift Lever ILL., Low DC-DC Converter, Driver/Passenger Seat Warmer Control Module, Head Lamp LH/RH, Head Lamp Leveling Device Switch, A/C Control Module, A/V & Navigation Head Unit, Audio
24	ESP 3	³ <b>த</b>	10A	ESP Control Module
25	BRAKE SWITCH	BRAKE SWITCH	7.5A	IBU, Stop Lamp Switch
26	START	C	7.5A	IBU, ECM
27	CLUSTER	CLUSTER	10A	Instrument Cluster
28	MODULE 4	4 MODULE	10A	IBU, Console Switch, ESP Control Module, Clutch Sensor, Front View Camera, Ignition Lock & Clutch Switch
29	IBU 2	<sup>2</sup> IBU	15A	IBU
30	ACC	ACC	10A	Power Outlet Relay, Power Outside Mirror Switch, IBU, Rear USB Charger, E-Call Unit, A/V & Navigation Unit, Audio, Low DC-DC Converter, Front Power Outlet
32	MODULE 7	7 MODULE	10A	Driver/Passenger Seat Warmer Control Module
33	WASHER	₩	15A	Multifunction Switch
34	MODULE 6	6 MODULE	7.5A	IBU
35	POWER OUTLET	POWER OUTLET	20A	Front Power Outlet

### Driver's side fuse panel

	FUSE NAME	SYMBOL	FUSE RATING	CIRCUIT PROTECTED
36	IBU 1	¹ IBU	10A	IBU
37	A/BAG IND	IND	10A	A/C Control Module, Instrument Cluster
39	A/C 1	¹ <b>A/C</b>	7.5A	A/C Control Module, E/R Junction Block (RLY. 12)
40	WIPER RR	4	15A	Rear Wiper Motor, E/R Junction Block (RLY. 3)
41	WIPER FRT 2	² <b>(</b>	20A	Front Wiper Motor, E/R Junction Block (RLY. 11)
44	ECU 5		10A	ECM
45	MDPS 2	<b>⊘</b> ²	10A	MDPS Unit


### Engine compartment fuse panel



Inside the fuse/relay box covers, you can find the fuse/relay label describing fuse/relay names and ratings.

### *i* Information

Not all fuse panel descriptions in this manual may be applicable to your vehicle. It is accurate at the time of printing. When you inspect the fuse box on your vehicle, refer to the fuse box label.



### Engine compartment fuse panel (for Smartstream G1.0)

RELAY N	UMBER	SYMBOL	RELAY NAME	TYPE
RLY.1	E178	MAIN	Main Relay	MINI
RLY.2	E179	FUEL PUMP	Fuel Pump Relay	MICRO
RLY.3	E180	P	Rear Wiper Relay	MICRO
RLY.4	E181	² (X)	Cooling Fan Low Relay	MICRO
RLY.5	E182	H P	Front Wiper High Relay	MICRO
RLY.6	E183	A/C	A/CON Relay	MICRO
RLY.7	E184	C	Start Relay	MICRO
RLY.8	E185	1 XX	Cooling Fan High Relay	MICRO
RLY.9	E186	ATT.	B/Alarm Horn Relay	MICRO
RLY.10	E187		Horn Relay	MICRO
RLY.11	E188	r. <b>.</b>	Front Wiper Low Relay	MICRO
RLY.12	E189	SS	Blower Relay	MICRO

### **Engine compartment fuse panel (for Smartstream G1.0)**

FL	JSE NAME	SYMBOL	FUSE RATING	CIRCUIT PROTECTED	
01	ALT	ALT	125A (Without ISG) 150A (With ISG)	Alternator, Multi Fuse - F02, Fuse - F03/F05/F06/F07/F08	
02	MDPS	<b>⊘</b> ¹	80A	MDPS Unit	
03	BLOWER	S	40A	E/R Junction Block (RLY.12)	
05	RR DEFOG	[#]	30A	ICU Junction Block (Rear Defogger Relay)	
06	ABS2	² <b>=</b>	40A	ESP Control Module	
07	POWER OUTLET1	1 POWER OUTLET	40A	ICU Junction Block (Power Outlet Relay)	
08	ABS1	1	40A	ESP Control Module	
09	WIPER1	' <b>\P</b>	10A	Front Wiper Motor, ECM, IBU, E/R Junction Block (RLY.11)	
10	IG1	IG1	30A	[With Smart Key] PDM Relay Box (IG1, ACC Relay) [W/O Smart Key] Ignition Switch	
11	C/FAN	EF.	30A	E/R Junction Block (RLY.4, RYL.8)	
12	AMT2	<sup>2</sup> AMT	40A	ТСМ	
13	BATT3	3 = +	30A	ICU Junction Block (Long Term Load Latch Relay, Fuse - F01/F08/ F21/F25/F29)	
14	BATT2	2 - +	50A	ICU Junction Block (Power Window Relay, Fuse - F03/F04)	
15	BATT4	4 = +	40A	ICU Junction Block (IPS2 (4CH)/ IPS4 (4CH)/IPS6 (2CH)/IPS9 (2CH)/ IPS10 (1CH))	
16	ECU3		15A	ECM	
17	HORN		15A	E/R Junction Block (RLY.9, RLY.10)	
18	A/CON1	<sup>1</sup> A/C	10A	E/R Junction Block (RLY.6)	
19	BATT1	1 -+	50A	ICU Junction Block (IPS1 (4CH)/ IPS3 (4CH)/IPS5 (2CH)/IPS7 (2CH)/ IPS8 (2CH)/IPS11 (1CH))	

### Engine compartment fuse panel (for Smartstream G1.0)

FU	JSE NAME	SYMBOL	FUSE RATING	CIRCUIT PROTECTED	
20	AMT1	¹ AMT	40A	TCM	
21	IG2	IG2 30A		E/R Junction Block (RLY.7) [With Smart Key] PDM Relay Box (IG2 Relay)[W/O Smart Key] Ignition Switch	
23	AMT3	<sup>3</sup> AMT	15A	ТСМ	
24	FUEL PUMP	FUEL PUMP	15A	E/R Junction Block (RLY.2)	
25	AMS	AMS	10A	Battery Sensor	
27	ECU4	E4 +() [[]]	15A	ECM, Ignition Lock & Clutch Switch	
29	ECU1	E1 (1)	30A	E/R Junction Block (RLY.1)	
30	IGN COIL	IGN COIL	15A	Ignition Coil #1/#2/#3	
31	INJECTOR	INJECTOR	15A	ECM, E/R Junction Block (RLY.2), Injector #1-1/#1-2/#2-1/#2-2/#3- 1/#3-2	
34	ECU2		15A	E/R Junction Block (RLY.4, RLY.6, RLY. 8), ECM, Oil Control Valve #1/#2 (Intake/ Exhaust), Oxygen Sensor (Up/Down), Purge Control Solenoid Valve	

### Engine compartment fuse panel (for Smartstream G1.2)

RELAY N	UMBER	SYMBOL	RELAY NAME	TYPE
RLY.1	E278	MAIN	Main Relay	MINI
RLY.2	E279	FUEL PUMP	Fuel Pump Relay	MICRO
RLY.3	E280	Þ	Rear Wiper Relay	MICRO
RLY.4	E281	2 XX	Cooling Fan Low Relay	MICRO
RLY.5	E282	H P	Front Wiper High Relay	MICRO
RLY.6	E283	A/C	A/CON Relay	MICRO
RLY.7	E284	C	Start Relay	MICRO
RLY.8	E285	1 %	Cooling Fan High Relay	MICRO
RLY.9	E286	<b>7711</b>	B/Alarm Horn Relay	MICRO
RLY.10	E287		Horn Relay	MICRO
RLY.11	E288	г. <b>Ф</b>	Front Wiper Low Relay	MICRO
RLY.12	E289	SS	Blower Relay	MICRO

### Engine compartment fuse panel (for Smartstream G1.2)

Fl	JSE NAME	SYMBOL	FUSE RATING	CIRCUIT PROTECTED
01	ALT	ALT	125A (Without ISG) 150A (With ISG)	Alternator, Multi Fuse - F02, Fuse - F03/F05/F06/F07/F08
02	MDPS	<b>⊘</b> ¹	80A	MDPS Unit
03	BLOWER	S	40A	E/R Junction Block (RLY.12)
05	RR DEFOG	#	30A	ICU Junction Block (Rear Defogger Relay)
06	ABS2	² 📻	40A	ESP Control Module
07	POWER OUTLET1	1 POWER OUTLET	40A	ICU Junction Block (Power Outlet Relay)
08	ABS1	1 🚉	40A	ESP Control Module
09	WIPER1	' <b>P</b>	10A	Front Wiper Motor, ECM, IBU, E/R Junction Block (RLY.11)
10	IG1	IG1	30A	[With Smart Key] PDM Relay Box (IG1, ACC Relay) [W/O Smart Key] Ignition Switch
11	C/FAN	T.	30A	E/R Junction Block (RLY.4, RYL.8)
12	AMT2	<sup>2</sup> AMT	40A	ТСМ
13	BATT3	3 — +	30A	ICU Junction Block (Long Term Load Latch Relay, Fuse - F01/F08/F21/F25/ F29)
14	BATT2	2 - +	50A	ICU Junction Block (Power Window Relay, Fuse - F03/F04)
15	BATT4	4 — +	40A	ICU Junction Block (IPS2 (4CH)/IPS4 (4CH)/IPS6 (2CH)/IPS9 (2CH)/IPS10 (1CH))
16	ECU3		15A	ECM
17	HORN	M	15A	E/R Junction Block (RLY.9, RLY.10)
18	A/CON1	<sup>1</sup> A/C	10A	E/R Junction Block (RLY.6)
19	BATT1	1	50A	ICU Junction Block (IPS1 (4CH)/IPS3 (4CH)/IPS5 (2CH)/IPS7 (2CH)/IPS8 (2CH)/IPS11 (1CH))

### Engine compartment fuse panel (for Smartstream G1.2)

FU	FUSE NAME SYM		FUSE RATING	CIRCUIT PROTECTED	
20	AMT1	1 AMT	40A	ТСМ	
21	IG2	IG2	30A	E/R Junction Block (RLY.7) [With Smart Key] PDM Relay Box (IG2 Relay) [W/O Smart Key] Ignition Switch	
23	АМТ3	<sup>3</sup> AMT	15A	TCM	
24	FUEL PUMP	FUEL PUMP	15A	E/R Junction Block (RLY.2)	
25	AMS	AMS	10A	Battery Sensor	
27	ECU4	E4 + \( \) []	15A	ECM, Ignition Lock & Clutch Switch	
29	ECU1	E1 (1)	30A	E/R Junction Block (RLY.1)	
30	IGN COIL	IGN COIL	15A	Ignition Coil #1/#2/#3	
31	INJECTOR	INJECTOR	15A	ECM, E/R Junction Block (RLY.2), Injector #1-1/#1-2/#2-1/#2-2/#3-1/#3- 2/#4-1/#4-2	
34	ECU2		15A	E/R Junction Block (RLY.4, RLY.6, RLY. 8), ECM, Oil Control Valve #1/#2 (Intake/ Exhaust), Oxygen Sensor (Up/Down), Purge Control Solenoid Valve	

### Engine compartment fuse panel (for Smart stream G1.0 T-GDi)

RELAY N	UMBER	SYMBOL	RELAY NAME	TYPE
RLY.1	E378	MAIN	Main Relay	MINI
RLY.2	E379	FUEL PUMP	Fuel Pump Relay	MICRO
RLY.3	E380	$\Box$	Rear Wiper Relay	MICRO
RLY.4	E381	² 🔀	Cooling Fan Low Relay	MICRO
RLY.5	E382	H P	Front Wiper High Relay	MICRO
RLY.6	E383	A/C	A/CON Relay	MICRO
RLY.7	E384	C	Start Relay	MICRO
RLY.8	E385	¹ ∰	Cooling Fan High Relay	MICRO
RLY.9	E386	Ant.	B/Alarm Horn Relay	MICRO
RLY.10	E387		Horn Relay	MICRO
RLY.11	E388	r. <b></b>	Front Wiper Low Relay	MICRO
RLY.12	E389	SS	Blower Relay	MICRO

### Engine compartment fuse panel (for Smart stream G1.0 T-GDi)

F	USE NAME	SYMBOL	FUSE RATING	CIRCUIT PROTECTED	
01	ALT	ALT	125A (Without ISG) 150A (With ISG)	Alternator, Multi Fuse - F02, Fuse - F03/F05/F06/F07/F08	
02	MDPS	(With 13G)  80A		MDPS Unit	
03	BLOWER	R	40A	E/R Junction Block (RLY.12)	
05	RR DEFOG	#	30A	ICU Junction Block (Rear Defogger Relay)	
06	ABS2	² 📻	40A	ESP Control Module	
07	POWER OUTLET1	1 POWER OUTLET	40A	ICU Junction Block (Power Outlet Relay)	
80	ABS1	1 🚍	40A	ESP Control Module	
09	WIPER1	¹ <b>\P</b>	10A	Front Wiper Motor, ECM, IBU, E/R Junction Block (RLY.11)	
10	IG1	IG1	30A	[With Smart Key] PDM Relay Box (IG1, ACC Relay) [W/O Smart Key] Ignition Switch	
11	C/FAN	£	30A	E/R Junction Block (RLY.4, RYL.8)	
12	AMT2	<sup>2</sup> AMT	40A	ТСМ	
13	BATT3	3 — +	30A	ICU Junction Block (Long Term Load Latch Relay, Fuse - F01/F08/ F21/F25/F29)	
14	BATT2	2 -+	50A	ICU Junction Block (Power Window Relay, Fuse - F03/F04)	
15	BATT4	4 — +	40A	ICU Junction Block (IPS2 (4CH)/ IPS4 (4CH)/IPS6 (2CH)/IPS9 (2CH)/IPS10 (1CH))	
16	ECU3		15A	ECM	
17	HORN		15A	E/R Junction Block (RLY.9, RLY.10)	
18	A/CON1	<sup>1</sup> A/C	10A	E/R Junction Block (RLY.6)	
19	BATT1	1 — +	50A	ICU Junction Block (IPS1 (4CH)/ IPS3 (4CH)/IPS5 (2CH)/IPS7 (2CH)/IPS8 (2CH)/IPS11 (1CH))	

### Engine compartment fuse panel (for Smart stream G1.0 T-GDi)

FUSE NAME		SYMBOL	FUSE RATING	CIRCUIT PROTECTED	
20	AMT1	¹ AMT	40A	тсм	
21	IG2	IG2	30A	E/R Junction Block (RLY.7) [With Smart Key] PDM Relay Box (IG2 Relay)[W/O Smart Key] Ignition Switch	
23	АМТЗ	<sup>3</sup> AMT	15A	ТСМ	
24	FUEL PUMP	FUEL PUMP	15A	E/R Junction Block (RLY.2)	
25	AMS	AMS	10A	Battery Sensor	
27	ECU4	E4 ( ) [	15A	ECM, Ignition Lock & Clutch Switch	
29	ECU1	E1 (1)	30A	E/R Junction Block (RLY.1)	
30	IGN COIL	IGN COIL	15A	Ignition Coil #1/#2/#3	
31	INJECTOR	INJECTOR	15A	ECM, E/R Junction Block (RLY.2), Injector #1-1/#1-2/#2-1/#2-2/#3- 1/#3-2	
34	ECU2	E2 (1)	15A	E/R Junction Block (RLY.4, RLY.6, RLY. 8), ECM, Oil Control Valve #1/#2 (Intake/ Exhaust), Oxygen Sensor (Up/Down), Purge Control Solenoid Valve	

#### LIGHT BULBS

We recommend that you consult a HYUNDAI authorised repairer to replace most vehicle light bulbs. It is difficult to replace vehicle light bulbs because other parts of the vehicle must be removed before you can get to the bulb. This is especially true for removing the headlight assembly to get to the bulb(s).

Removing/installing the headlight assembly can result in damage to the vehicle.



### ! WARNING

Prior to replacing a light, depress the foot brake, move the shift lever into the N (Neutral, for Automated manual transmission vehicle) or neutral (for manual transmission vehicle), apply the parking brake, place the ignition switch in the LOCK/OFF position, and take the key with you when leaving the vehicle to avoid sudden movement of the vehicle and to prevent possible electric shock.

Be aware the bulbs may be hot and may burn your fingers.

### NOTICE

Be sure to replace the burned-out bulb with one of the same wattage rating. Otherwise, it may cause damage to the fuse or electric wiring system



### i Information

The headlight and tail light lenses could appear frosty if the vehicle is washed after driving or the vehicle is driven at night in wet weather. This condition is caused by temperature difference between the light inside and outside and, it does not indicate a problem with your vehicle. When moisture condenses in the light, it will be removed after driving with the headlight on. The removable level may differ depending on light size, light position and environmental condition. However, if moisture is not removed, we recommend that your vehicle is inspected by a HYUNDAI authorised repairer.




### **Information (For Europe)**


### Traffic Change

The low beam light distribution is asymmetric. If you go abroad to a country with opposite traffic direction, this asymmetric part will dazzle oncoming car driver. To prevent dazzle, ECE regulation demand several technical solutions (for example, automatic change system, adhesive sheet, down aiming). These headlights are designed not to dazzle opposite drivers. So, you need not change your headlights in a country with opposite traffic direction.

### Headlight, Position Light, Turn signal Light, Fog Light and Daytime Running Light, Low Beam Assist-Static light bulb replacement



- (1) Headlight (Low/High) \*1
- (2) Turn Signal Light
- (3) Daytime Running Light & Position Light
- (4) Front Fog Light (if equipped)
- \*1: MFR (Multi Focus Reflector) Headlight





- (1) Headlight (Low/High) \*2
- (2) Low Beam Assist-Static Light
- (3) Turn Signal Light
- (4) Daytime Running Light & Position Light
- (5) Front Fog Light (if equipped)
- \*2 : Bi-Function Projection Headlight



### **WARNING**


- Handle halogen bulbs with care. Halogen bulbs contain pressurized gas that will produce flying pieces of glass that could cause injuries if broken.
- Wear eye protection when changing a bulb. Allow the bulb to cool down before handling it.
- Always handle them carefully, and avoid scratches and abrasions. If the bulbs are lit, avoid contact with liquids.
- Never touch the glass with bare hands. Residual oil may cause the bulb to overheat and burst when lit.
- A bulb should be operated only when installed in a headlight.
- If a bulb becomes damaged or cracked, replace it immediately and carefully dispose of it.

### Headlight (Low/High)


1. Turn the front tyre at a right angle.







- 2. Remove the Wheel guard clips (B), bumper cover bolt (A) and bumper upper cover bolt (C).
- Push the wheel guard aside and remove the headlight bulb cover by turning it counterclockwise.





[1]: Headlight


- Disconnect the headlight bulb socket-connector.
- Unsnap the headlight bulb retaining wire by depressing the end and pushing it upward.
- 6. Remove the bulb from the headlight assembly.
- 7. Install a new headlight bulb and snap the headlight bulb retaining wire into position by aligning the wire with the groove on the bulb.
- 8. Connect the headlight bulb socket connector.
- 9. Install the headlight bulb cover by turning it clockwise.
- 10. Install the wheel guard in the reverse order.

## *i* Information

### Bi-Function projection headlight

This headlight is bi-function type that switches the low beam to high or the high beam to low using solenoid system. So, the moving sound may be heard when the headlight switches the low beam to high or the high beam to low and it does not indicate malfunction of the headlight.





[2]: Low Beam Assist-Static Light

[3]: Turn signal light

# Turn signal light, Low Beam Assist-Static Light

- 1. Open the bonnet.
- Remove the turn signal light or low beam assist-static light bulb cover by turning it counterclockwise.

- Remove the socket from the assembly by turning the socket counterclockwise until the tabs on the socket align with the slots on the assembly.
- Insert a new bulb by inserting it into the socket and rotating it until it locks into place.
- Install the socket in the assembly by aligning the tabs on the socket with the slots in the assembly.
  - Push the socket into the assembly and turn the socket clockwise.
- Install the turn signal light or low beam assist-static light bulb cover by turning it clockwise.

# Daytime Running Light & Position Light, Front Fog Light (if equipped)





 Remove the under cover by rotating the screws and bolts.

- 2. Reach your hand into the back of the front bumper.
- 3. Disconnect the power connector from the socket.
- Remove the bulb-socket from the housing by turning the socket counterclockwise until the tabs on the socket align with the slots on the housing.
- Install the new bulb-socket into the housing by aligning the tabs on the socket with the slots in the housing. Push the socket into the housing and turn the socket clockwise.
- Connect the power connector to the socket.
- 7. Reinstall the front bumper under cover

# Daytime Running Light & Position Light (LED Type, if equipped)

Your vehicle is equipped with LED lights. LED lights do not have replaceable bulbs. If the LED light does not operate, we recommend that the vehicle be checked by a HYUNDAI authorised repairer.

# Headlight and front fog light aiming

### Headlight aiming





- Inflate the tyres to the specified pressure and remove any loads from the vehicle except the driver, spare tyre, and tools.
- 2. The vehicle should be placed on a flat floor.
- Draw vertical lines (Vertical lines passing through respective head light centres) and a horizontal line (Horizontal line passing through centre of head lights) on the screen.
- With the headlight and battery in normal condition, aim the headlights so the brightest portion falls on the horizontal and vertical lines.

 To aim the low beam left or right, turn the driver clockwise or counterclockwise. To aim the low beam up or down, turn the driver clockwise or counterclockwise.

To aim the high beam up or down, turn the driver clockwise or counter-clockwise.


### Front fog light aiming





The front fog light can be aimed as the same manner of the head lights aiming. With the front fog lights and battery normal condition, aim the front fog lights. To aim the front fog light up or down, turn the driver clockwise or counterclockwise.


### Aiming point (5 Door)



Unit: mm (in)

Vehicle condition		114	Н3	10/4	W3
		H1	Fog	W1	Fog
AAPil	Multi Focus Reflector Headlight	768 (30.23)	392	1,342 (52.8)	1,361
Without driver	Bi-Function Projection Headlight	Projection 761.5 (15.4) 1	1,357 (53.4)	(53.6)	
With driver	Multi Focus Reflector Headlight	761 (29.9)	385	1,342 (52.8)	1,361
vviiii dilver	Bi-Function Projection Headlight	754.5 (29.7)	(15.2)	1,357 (53.4)	(53.6)


### Aiming point (N line)



Unit: mm (in)


Vehicle condition		H1	Н3	W1	W3
		""	Fog	WI	Fog
VA/Cale and allohous	Multi Focus Reflector Headlight	768 (30.23)	378	1,342 (52.8)	1,309 (51.5)
Without driver	Bi-Function Projection Headlight	761.5 (29.9)	(14.9)	1,357 (53.4)	
With driver	Multi Focus Reflector Headlight	761 (29.9)	371	1,342 (52.8)	1,309
vviiii alivei	Bi-Function Projection Headlight	754.5 (29.7)	(14.6)	1,357 (53.4)	(51.5)

### Head light low beam



- 1. Turn the low beam on without driver aboard.
- 2. The cut-off line should be projected in the cut-off line shown in the picture.
- 3. When aiming the low beam, vertical aiming should be adjusted after adjusting the horizontal aiming.
- 4. If head light levelling device is equipped, adjust the head light levelling device switch with 0 positions.

### Front fog light



- 1. Turn the front fog light on with the driver (75 kg) aboard.
- 2. The cut-off line should be projected in the allowable range (shaded region).

### Side repeater light replacement



### Type A

If the LED light does not operate, we recommend you to have the vehicle checked by a HYUNDAI authorised repairer.



### Type B

- Remove the light assembly from the vehicle by prying the lens and pulling the assembly out.
- 2. Disconnect the bulb electrical connector.
- Separate the socket and the lens parts by turning the socket counterclockwise until the tabs on the socket align with the slots on the lens part.

- 4. Remove the bulb by pulling it straight out.
- 5. Insert a new bulb in the socket.
- 6. Reassemble the socket and the lens part.
- 7. Connect the bulb electrical connector.
- 8. Reinstall the light assembly to the body of the vehicle.

# Rear combination light bulb replacement




- (1) Turn Signal Light
- (2) Tail/Stop Light
- (3) Reflex Reflector Light
- (4) Rear Fog Light
- (5) Back-up Light




- (1) Tail Light
- (2) Stop Light
- (3) Turn signal light
- (4) Reflex Reflector Light
- (5) Rear fog Light
- (6) Back-up Light

### Turn Signal Light, Tail/Stop Light



1. Open the tailgate

- 2. Loosen the light assembly retaining screws with a cross-tip screwdriver.
- Remove the rear combination light assembly from the body of the vehicle.



[1]: Turn Signal Light, [2]: Tail/Stop Light

- Remove the socket from the assembly by turning the socket counterclockwise until the tabs on the socket align with the slots on the assembly.
- Remove the bulb from the socket by pressing it in and rotating it counterclockwise until the tabs on the bulb align with the slots in the socket. Pull the bulb out of the socket.
- Insert a new bulb by inserting it into the socket and rotating it until it locks into place.
- Install the socket in the assembly by aligning the tabs on the socket with the slots in the assembly. Push the socket into the assembly and turn the socket clockwise.
- 8. Reinstall the light assembly to the body of the vehicle.

### Rear fog light, Back-up Light



[1]: Rear Fog Light, [2]: Back-up Light


- Remove the rear tyre and wheel cover.
- Remove the socket from the assembly by turning the socket counterclockwise until the tabs on the socket align with the slots on the assembly.
- Remove the bulb from the socket by pressing it in and rotating it counterclockwise until the tabs on the bulb align with the slots in the socket. Pull the bulb out of the socket.
- 4. Insert a new bulb in the socket.
- 5. Reinstall the light assembly to the body of the vehicle.

# High mounted stop light replacement




If the LED light does not operate, we recommend you to have the vehicle checked by a HYUNDAI authorised repairer.


# License plate light bulb replacement



- Using a flat-blade screwdriver gently pry the lens cover from the light housing.
- Remove the socket from the assembly by turning the socket counterclockwise until the tabs on the socket align with the slots on the assembly.
- 3. Remove the bulb by pulling it straight out.
- 4. Install a new bulb.
- Reinstall in the reverse order.

### Interior light bulb replacement







- Using a flat-head screwdriver, gently pry the lens from the interior light housing.
- 2. Remove the bulb by pulling it straight out.
- 3. Install a new bulb into the socket.
- 4. Align the lens tabs with the interior light housing notches and snap the lens into place.

### NOTICE

Be careful not to damage the cover, tab, and plastic housing.

#### **APPEARANCE CARE**

#### **Exterior care**

### NOTICE

If you park your vehicle near a stainless steel sign or glass facade building, the vehicle's exterior plastic parts such as a bumper, spoiler, garnish, light or exterior mirror might be damaged due to sunlight reflected from the sign or building. To prevent damage of the exterior plastic parts, you should avoid parking in areas where light may be reflected or use a car cover. (The exterior plastic parts applied to your vehicle may vary.)

### Exterior general caution

It is very important to follow the label directions when using any chemical cleaner or polish. Read all warning and caution statements that appear on the label.

#### Finish maintenance

#### Washing

To help protect your vehicle's finish from rust and deterioration, wash it thoroughly and frequently at least once a month with lukewarm or cold water.

If you use your vehicle for off-road driving, you should wash it after each off-road trip. Pay special attention to the removal of any accumulation of salt, dirt, mud, and other foreign materials. Make sure the drain holes in the lower edges of the doors and rocker panels are kept clear and clean.

Insects, tar, tree sap, bird droppings, industrial pollution and similar deposits can damage your vehicle's finish if not removed immediately.

Even prompt washing with plain water may not completely remove all these deposits.

A mild soap, safe for use on painted surfaces, may be used.

After washing, rinse the vehicle thoroughly with lukewarm or cold water. Do not allow soap to dry on the finish.

### NOTICE

- Do not use strong soap, chemical detergents or hot water, and do not wash the vehicle in direct sunlight or when the body of the vehicle is warm.
- Be careful when washing the side windows of your vehicle.
  - Especially, with high-pressure water, water may leak through the windows and wet the interior.
- To prevent damage to the plastic parts and lights, do not clean with chemical solvents or strong detergents.

## A

### **!** WARNING

#### Wet brakes

After washing the vehicle, test the brakes whilst driving slowly to see if they have been affected by water. If braking performance is impaired, dry the brakes by applying them lightly whilst maintaining a slow forward speed.

### High-pressure washing

- When using high-pressure washers, make sure to maintain sufficient distance from the vehicle.
  - Insufficient clearance or excessive pressure can lead to component damage or water penetration.
- Do not spray the camera, sensors or its surrounding area directly with a high pressure washer. Shock applied from high pressure water may cause the device to not operate normally.
- Do not bring the nozzle tip close to boots (rubber or plastic covers) or connectors as they may be damaged if they come into contact with high pressure water.



### NOTICE

- Water washing in the engine compartment including high pressure water washing may cause the failure of electrical circuits located in the engine compartment.
- Never allow water or other liquids to come in contact with electrical/ electronic components inside the vehicle as this may damage them.

### NOTICE

# Matte paint finish vehicle (if equipped)

Automatic car wash which uses rotating brushes should not be used as this can damage the surface of your vehicle. A steam cleaner which washes the vehicle surface at high temperature may result the oil to adhere and leave stains that is difficult to remove.

Use a soft cloth (for example, microfiber towel or sponge) when washing your vehicle and dry with a microfiber towel. When you hand wash your vehicle, you should not use a cleaner that finishes with wax. If the vehicle surface is too dirty (sand, dirt, dust, contaminant, etc.), clean the surface with water before washing the car.

### Waxing

Wax the vehicle when water will no longer bead on the paint.

Always wash and dry the vehicle before waxing. Use a good quality liquid or paste wax, and follow the manufacturer's instructions. Wax all metal trim to protect it and to maintain its luster. Removing oil, tar, and similar materials with a spot remover will usually strip the wax from the finish. Be sure to re-wax these areas even if the rest of the vehicle does not yet need waxing.

### NOTICE

- Wiping dust or dirt off the body with a dry cloth will scratch the finish.
- Do not use steel wool, abrasive cleaners, or strong detergents containing highly alkaline or caustic agents on chrome-plated or anodized aluminium parts. This may result in damage to the protective coating and cause discolouration or paint deterioration.

### NOTICE

Matte paint finish vehicle (if equipped)

Do not use any polish protector such as a detergent, an abrasive and a polish. In case wax is applied, remove the wax immediately using a silicon remover and if any tar or tar contaminant is on the surface use a tar remover to clean. However, be careful not to apply too much pressure on the painted area.

### Finish damage repair

Deep scratches or stone chips in the painted surface must be repaired promptly. Exposed metal will quickly rust and may develop into a major repair expense.

### NOTICE

If your vehicle is damaged and requires any metal repair or replacement, be sure the body shop applies anti-corrosion materials to the parts repaired or replaced.

### NOTICE

Matte paint finish vehicle (if equipped)

In case of matte paint finish vehicles, it is impossible to modify only the damaged area and repair of the whole part is necessary. If the vehicle is damaged and painting is required, we recommend that you have your vehicle maintained and repaired by a HYUNDAI authorised repairer. Take extreme care, as it is difficult to restore the quality after the repair.

### Bright-metal maintenance

- To remove road tar and insects, use a tar remover, not a scraper or other sharp object.
- To protect the surfaces of bright-metal parts from corrosion, apply a coating of wax or chrome preservative and rub to a high luster.
- During winter weather or in coastal areas, cover the bright metal parts with a heavier coating of wax or preservative. If necessary, coat the parts with non-corrosive petroleum jelly or other protective compound.

### Underbody maintenance

Corrosive materials used for ice and snow removal and dust control may collect on the underbody. If these materials are not removed, accelerated rusting can occur on underbody parts such as the fuel lines, frame, floor pan and exhaust system, even though they have been treated with rust protection.

Thoroughly flush the vehicle underbody and wheel openings with lukewarm or cold water once a month, after off-road driving and at the end of each winter. Pay special attention to these areas because it is difficult to see all the mud and dirt. It will do more harm than good to wet down the road grime without removing it. The lower edges of doors, rocker panels, and frame members have drain holes that should not be allowed to clog with dirt; trapped water in these areas can cause rusting.

# **⚠** WARNING

After washing the vehicle, test the brakes whilst driving slowly to see if they have been affected by water. If braking performance is impaired, dry the brakes by applying them lightly whilst maintaining a slow forward speed.

#### Aluminium wheel maintenance

The aluminium wheels are coated with a clear protective finish.

### NOTICE

- Do not use any abrasive cleaner, polishing compound, solvent, or wire brushes on aluminium wheels.
- Clean the wheel when it has cooled.
- Use only a mild soap or neutral detergent, and rinse thoroughly with water. Also, be sure to clean the wheels after driving on salted roads.
- Do not wash the wheels with highspeed car wash brushes.
- Do not use any cleanser containing acid or alkaline detergents.

### Corrosion protection

# **Protecting your vehicle from corrosion**

By using the most advanced design and construction practices to combat corrosion, we produces vehicles of the highest quality. However, this is only part of the job. To achieve the longterm corrosion resistance your vehicle can deliver, the owner's cooperation and assistance is also required.

#### Common causes of corrosion

The most common causes of corrosion on your vehicle are:

- Road salt, dirt and moisture that is allowed to accumulate underneath the vehicle.
- Removal of paint or protective coatings; by stones, gravel, abrasion or minor scrapes and dents which leave unprotected metal exposed to corrosion.

#### **High-corrosion** areas

If you live in an area where your vehicle is regularly exposed to corrosive materials, corrosion protection is particularly important. Some of the common causes of accelerated corrosion are road salts, dust control chemicals, ocean air and industrial pollution.

#### **Moisture breeds corrosion**

Moisture creates the conditions in which corrosion is most likely to occur. For example, corrosion is accelerated by high humidity, particularly when temperatures are just above freezing. In such conditions, the corrosive material is kept in contact with the vehicle surfaces by moisture that is slow to evaporate.

Mud is particularly corrosive because it is slow to dry and holds moisture in contact with the vehicle. Although the mud appears to be dry, it can still retain moisture and promote corrosion.

High temperatures can also accelerate corrosion of parts that are not properly ventilated so the moisture can be dispersed. For all these reasons, it is particularly important to keep your vehicle clean and free of mud or accumulations of other materials. This applies not only to the visible surfaces but particularly to the underside of the vehicle.

### To help prevent corrosion

You can help prevent corrosion from getting started by observing the following:

#### Keep your vehicle clean

The best way to prevent corrosion is to keep your vehicle clean and free of corrosive materials. Attention to the underside of the vehicle is particularly important.

- If you live in a high-corrosion area—
  where road salts are used, near the
  ocean, areas with industrial pollution,
  acid rain, etc.—, you should take extra care to prevent corrosion. In winter, hose off the underside of your
  vehicle at least once a month and be
  sure to clean the underside thoroughly when winter is over.
- When cleaning underneath the vehicle, give particular attention to the components under the fenders and other areas that are hidden from view. Do a thorough job; just dampening the accumulated mud rather than washing it away will accelerate corrosion rather than prevent it. Water under high pressure and steam are particularly effective in removing accumulated mud and corrosive materials.
- When cleaning lower door panels, rocker panels and frame members, be sure that drain holes are kept open so that moisture can escape and not be trapped inside to accelerate corrosion.

### Keep your garage dry

Don't park your vehicle in a damp, poorly ventilated garage. This creates a favorable environment for corrosion. This is particularly true if you wash your vehicle in the garage or drive it into the garage when it is still wet or covered with snow, ice or mud. Even a heated garage can contribute to corrosion unless it is well ventilated so moisture is dispersed.

### Keep paint and trim in good condition

Scratches or chips in the finish should be covered with "touch-up" paint as soon as possible to reduce the possibility of corrosion. If bare metal is showing through, the attention of a qualified body and paint shop is recommended.

Bird droppings: Bird droppings are highly corrosive and may damage painted surfaces in just a few hours. Always remove bird droppings as soon as possible.

### Don't neglect the interior

Moisture can collect under the floor mats and carpeting to cause corrosion. Check under the mats periodically to be sure the carpeting is dry. Use particular care if you carry fertilizers, cleaning materials or chemicals in the vehicle.

These should be carried only in proper containers and any spills or leaks should be cleaned up, flushed with clean water and thoroughly dried.

#### Interior care

### Interior general precautions

Prevent chemicals such as perfume, cosmetic oil, sun cream, hand cleaner and air freshener from contacting the interior parts because they may cause damage or discolouration. If they do contact the interior parts, wipe them off immediately.

See the instructions that follow for the proper way to clean vehicle interior surfaces.

### NOTICE

Never allow water or other liquids to come in contact with electrical/electronic components inside the vehicle as this may damage them.

### NOTICE

When cleaning leather products (steering wheel, seats etc.), use neutral detergents or low alcohol content solutions. If you use high alcohol content solutions or acid/alkaline detergents, the colour of the leather may fade or the surface may get stripped off.

# Cleaning the upholstery and interior trim

Vehicle interior surfaces (if equipped)

Remove dust and loose dirt from interior surfaces with a whisk broom or a vacuum cleaner.

If necessary, clean interior surfaces with a mixture of warm water and mild non-detergent cleaner (test all cleaners on a concealed area before use).

### Fabric (if equipped)

Remove dust and loose dirt from fabric with a whisk broom or vacuum cleaner. Clean with a mild soap solution recommended for upholstery or carpets. Remove fresh spots immediately with a fabric spot cleaner. If fresh spots do not receive immediate attention, the fabric can be stained and its colour can be affected. Also, its fire-resistant properties can be reduced if the material is not properly maintained.

### NOTICE

Using anything but recommended cleaners and procedures may affect the fabric's appearance and fire-resistant properties.

### Leather (if equipped)

- · Features of Seat Leather
  - Leather is made from the outer skin of an animal, which goes through a special process to be available for use. Since it is a natural product, each part differs in thickness or density.
  - Wrinkles may appear as a natural result of stretching and shrinking depending on the temperature and humidity.
  - The seat is made of stretchable fabric to improve comfort.
  - The parts contacting the body are curved and the side supporting area is high which provides driving comfort and stability.
  - Wrinkles may appear naturally from usage. It is not a fault of the products.

## **CAUTION**

- Wrinkles or abrasions which appear naturally from usage are not covered by warranty.
- Belts with metallic accessories, zippers or keys inside the back pocket may damage the seat fabric.
- Make sure not to wet the seat. It may change the nature of natural leather.
- Jeans or clothes which could bleach may contaminate the surface of the seat covering fabric.

- Caring for the leather seats
  - Vacuum the seat periodically to remove dust and sand on the seat. It will prevent abrasion or damage of the leather and maintain its quality.
  - Wipe the natural leather seat cover often with dry or soft cloth.
  - Use of proper leather protector may prevent abrasion of the cover and helps maintain the colour. Be sure to read the instructions and consult a specialist when using leather coating or protective agent.
  - Light coloured (beige, cream beige) leather is easily contaminated and the stain is noticeable. Clean the seats frequently.
  - Avoid wiping with wet cloth. It may cause the surface to crack.

- Cleaning the leather seats
  - Remove all contaminations instantly. Refer to instructions below for removal of each contaminant.
  - Cosmetic products (sunscreen, foundation, etc.)
    - Apply cleansing cream on a cloth and wipe the contaminated spot. Wipe off the cream with a wet cloth and remove water with a dry cloth.
  - Beverages (coffee, soft drink, etc.)
     Apply a small amount of neutral detergent and wipe until contaminations do not smear.
  - Oil

Remove oil instantly with absorbable cloth and wipe with stain remover used only for natural leather.

Chewing gum
 Harden the gum with ice and remove gradually.

# Cleaning the lap/shoulder belt webbing

Clean the belt webbing with any mild soap solution recommended for cleaning upholstery or carpet. Follow the instructions provided with the soap. Do not bleach or re-dye the webbing because this may weaken it.

# Cleaning the interior window glass

If the interior glass surfaces of the vehicle become fogged (that is, covered with an oily, greasy or waxy film), they should be cleaned with glass cleaner. Follow the directions on the glass cleaner container.

### NOTICE

Do not scrape or scratch the inside of the rear window. This may result in damage to the rear window defroster grid.

#### **EMISSION CONTROL SYSTEM**

The emission control system of your vehicle is covered by a written limited warranty. Please see the warranty information contained in the Service Passport in your vehicle.

Your vehicle is equipped with an emission control system to meet all emission regulations.

There are three emission control systems which are as follows.

- (1) Crankcase emission control system
- (2) Evaporative emission control system
- (3) Exhaust emission control system

In order to ensure the proper function of the emission control systems, it is recommended that you have your car inspected and maintained by a HYUNDAI authorised repairer in accordance with the maintenance schedule.

### NOTICE

For the Inspection and Maintenance Test (with Electronic Stability Control (ESC) system)

- To prevent the vehicle from misfiring during dynamometer testing, turn the Electronic Stability Control (ESC) system off by pressing the ESC switch.
- After dynamometer testing is completed, turn the ESC system back on by pressing the ESC switch again.

# 1. Crankcase emission control system

The positive crankcase ventilation system is employed to prevent air pollution caused by blow-by gases being emitted from the crankcase. This system supplies fresh filtered air to the crankcase through the air intake hose. Inside the crankcase, the fresh air mixes with blow-by gases, which then pass through the PCV valve into the induction system.

# 2. Evaporative emission control system

The Evaporative Emission Control System is designed to prevent fuel vapours from escaping into the atmosphere.

#### Canister

Fuel vapours generated inside the fuel tank are absorbed and stored in the onboard canister. When the engine is running, the fuel vapours absorbed in the canister are drawn into the surge tank through the purge control solenoid valve

# Purge Control Solenoid Valve (PCSV)

The purge control solenoid valve is controlled by the Engine Control Module (ECM); when the engine coolant temperature is low during idling, the PCSV closes so that evaporated fuel is not taken into the engine. After the engine warms-up during ordinary driving, the PCSV opens to introduce evaporated fuel to the engine.

# 3. Exhaust emission control system

The Exhaust Emission Control System is a highly effective system which controls exhaust emissions whilst maintaining good vehicle performance.

# Engine exhaust gas precautions (carbon monoxide)

 Carbon monoxide can be present with other exhaust fumes. Therefore, if you smell exhaust fumes of any kind inside your vehicle, have it inspected and repaired immediately. If you ever suspect exhaust fumes are coming into your vehicle, drive it only with all the windows fully open. Have your vehicle checked and repaired immediately.

### **⚠** WARNING

Engine exhaust gases contain carbon monoxide (CO). Though colourless and odourless, it is dangerous and could be lethal if inhaled. Follow the instructions following to avoid CO poisoning.

- Do not operate the engine in confined or closed areas (such as garages) any more than what is necessary to move the vehicle in or out of the area.
- When the vehicle is stopped in an open area for more than a short time with the engine running, adjust the ventilation system (as needed) to draw outside air into the vehicle.
- Never sit in a parked or stopped vehicle for any extended time with the engine running.
- When the engine stalls or fails to start, excessive attempts to restart the engine may cause damage to the emission control system.

# Operating precautions for catalytic converters (if equipped)

## A

### WARNING

The exhaust system and catalytic system are very hot whilst the engine is running or immediately after the engine is turned off. To avoid SERIOUS INJURY or DEATH:

- Do not park, idle, or drive the vehicle over or near flammable objects, such as grass, vegetation, paper, leaves, etc. A hot exhaust system can ignite flammable items under your vehicle.
- Keep away from the exhaust system and catalytic converter or you may get burned. Also, do not emove the heat sink around the exhaust system, do not seal the bottom of the vehicle, and do not coat the vehicle for corrosion control. It may present a fire risk under certain conditions.

Your vehicle is equipped with a catalytic converter emission control device.

Therefore, the following precautions must be observed:

- Use only UNLEADED FUEL for petrol engines.
- Do not operate the vehicle when there are signs of engine malfunction, such as misfire or a noticeable loss of performance.
- Do not misuse or abuse the engine. Examples of misuse are coasting with the engine off and descending steep grades in gear with the engine off.
- Do not operate the engine at high idle speed for extended periods (5 minutes or more).
- Do not modify or tamper with any part of the engine or emission control system. We recommend that all inspections and adjustments are made by a HYUNDAI authorised repairer.
- Avoid driving with a very low fuel level. If you run out of petrol, it could cause the engine to misfire and result in excessive loading of the catalytic converter.

Failure to observe these precautions could result in damage to the catalytic converter and to your vehicle. Additionally, such actions could void your warranties.

## Petrol Particulate Filter (GPF) (if equipped)

The Petrol Particulate Filter (GPF) system removes the soot in the exhaust gas.

The GPF system automatically burns (or oxidizes) the accumulated soot in accordance with driving situations, unlike a disposable air filter.

In other words, the accumulated soot is automatically purged out by the engine control system and by the high exhaustgas temperature at normal/ high driving speeds.

However, when the vehicle is continually driven at repeated short distances or driven at low speed for a long time, the accumulated soot may not be automatically removed because of low exhaust gas temperature. In this case, the accumulated soot may reach a certain amount regardless of the soot oxidization process, then the GPF light will illuminate.

The Petrol Particulate Filter (GPF) Light stops illuminating, when the driving speed exceeds 50 mph (80 km/h) with engine RPM 1,500 ~ 4,000 and the gear in the 3rd position or above for about 30 minutes.

When the GPF light starts to blink or the waning message "Check exhaust system" pops up even though the vehicle was driven as mentioned above, we recommend that you have the GPF system checked by a HYUNDAI authorised repairer.

With the GPF light blinking for an extended period of time, it may damage the GPF system and lower the fuel economy.

### **MARNING**

Petrol Fuel (if equipped with GPF)

We recommend you to use only the regulated petrol fuels, when your vehicle is equipped with the GPF system.

When you use other petrol fuels which contain unspecified additives, they may damage the GPF system and cause exhaust emission problems.

# Index

7	Δ	
и	_	

Accessing your vehicle	5.5
Immobiliser system	
Remote key	
Remote key precautions	
Smart key	
Smart key precautions	
Air cleaner	
Filter replacement.	
Air conditioner compressor label	
air conditioning system	
Airbag - supplemental restraint system	
Additional safety precautions	
Airbag warning labels	
Do not install a child restraint on the front passenger seat	
How does the airbags system operate?	
SRS Care	
What to expect after an airbag inflates	
Where are the airbags?	
Why didn't my airbag go off in a collision?	3-53
Appearance care	9-70
Exterior care	9-70
Interior care	9-76
AUDIO (Without Touch Screen)	5-94
Getting to know the basic operations	5-101
System layout – control panel	5-94
System layout – steering wheel remote control	5-98
Turning the display on or off	5-101
Turning the system on or off	5-100
Automated Manual Transmission (AMT)	
Automated Manual Transmission (AMT) operation	
Cluster display for transmission warning message	
Features of the Automated Manual Transmission (AMT)	
Good driving practices	
Parking	
Transmission ranges	

Automatic climate control system	5-61
Automatic heating and air conditioning	5-62
Manual heating and air conditioning	5-63
System maintenance	5-69
System operation	5-67
В	
D	0.26
Battery	
Battery capacity label	
Battery recharging	
For best battery service	
Reset items	
Before driving	
Before entering the vehicle	
Before starting	
Bluetooth	
Connecting Bluetooth devices	
Using a Bluetooth audio device	5-113
Using a Bluetooth phone	
Brake/clutch fluid	9-17
Checking the brake/clutch fluid level	9-17
Braking system	6-30
Anti-lock Brake System (ABS)	6-33
Brake Assist System (BAS)	6-40
Disc brakes wear indicator	6-31
Electronic Stability Control (ESC)	6-34
Emergency Stop Signal (ESS)	6-39
Good braking practices	
Hill-Start Assist Control (HAC)	
Parking brake	
Power brakes	
Rear drum brakes	
Vehicle Stability Management (VSM)	
Bulb wattage	
0-	11

C	
Caution: modifications to original vehicle specification	2
Centre console overview.	
Child Restraint System (CRS)	3-30
Installing a Child Restraint System (CRS)	3-32
Our recommendation:Children always in the rear	3-30
Selecting a Child Restraint System (CRS)	
Climate control air filter	9-22
Filter inspection	9-22
Filter replacement	9-22
CLUSTER display	
Cluster display control	
Cluster display modes	4-26
Trip computer	4-34
User settings mode	4-28
Cruise Control (CC)	7-38
Cruise Control operation	7-38
D	
Declaration of conformity	
CE RED for EU	
Declaration of conformity	
Dimensions	
Door locks	_
Auto door lock/unlock features	
Child-protector rear door locks	
Deadlocks	
How to lock the door in case of emergency	
Operating door locks from inside the vehicle	
Operating door locks from outside the vehicle	
Driver Attention Warning (DAW)	
Driver Attention Warning malfunction and limitations	
Driver Attention Warning operation	
Driver Attention Warning settings	7-32

Emergency commodity	8-36
Fire extinguisher	
First aid kit	8-36
Triangle reflector	8-36
Tyre pressure gauge	8-36
Emission control system	
Crankcase emission control system	9-79
Evaporative emission control system	9-79
Exhaust emission control system	9-80
Engine compartment	9-3
Engine compartment overview	2-9
Engine coolant	9-14
Changing the engine coolant	9-16
Checking the coolant level	9-14
Engine number	2-18
Engine oil	9-11
Checking the engine oil and filter	9-12
Checking the engine oil level	9-11
Engine specification	2-10
Explanation of scheduled maintenance items	9-8
Air cleaner filter	9-9
Exterior features	5-32
Bonnet	5-32
Fuel filler door	5-35
Tailgate	5-33
Exterior overview (front view)	2-2
Exterior overview (rear view)	2-4

F
Foreword
G
Gross vehicle weight
H
Hazard warning flasher8-3High Beam Assist (HBA)5-46High Beam Assist malfunction and limitations5-47High Beam Assist operation5-46High Beam Assist settings5-46How To Use This Manual1-3Hyundai motor company1-2
I and the second
If the engine overheats

If you have a flat tyre (with tyre mobility kit)	8-24
Checking the tyre inflation pressure	8-30
Components of the Tyre Mobility Kit	8-27
Distributing the sealant	8-30
Introduction	8-25
Notes on the safe use of the Tyre Mobility Kit	8-26
Using the Tyre Mobility Kit	8-28
Ignition switch	6-6
Engine Start/Stop button	6-9
Key ignition switch	6-6
Important safety precautions	3-2
Airbag hazards	3-2
Always wear your seat belt	3-2
Control your speed	3-3
Driver distraction	3-2
Keep your vehicle in safe condition	3-3
Restrain all children	3-2
Importer information for United Kingdom	2-21
In case of an emergency whilst driving	8-3
If the engine stalls at a crossroad or crossing	
If the engine stalls whilst driving	8-3
If you have a flat tyre whilst driving	8-4
Infotainment system	5-87
Antenna	5-87
Audio / Video / Navigation system	5-89
Bluetooth® Wireless Technology hands-free	
How vehicle radio works	5-90
Steering wheel audio control	5-88
USB port	5-87
Infotainment System specifications	
Bluetooth	
USB	5-122
Instrument cluster	4-2
Cluster display messages	
Gauges and meters	
Instrument cluster control	
Transmission shift indicator	
Warning and indicator lights	

Intelligent Speed Limit Assist (ISLA)	7-25
Intelligent Speed Limit Assist malfunction and limitations	7-29
Intelligent Speed Limit Assist operation	7-27
Intelligent Speed Limit Assist settings	7-26
Interior features	5-77
Ashtray	5-77
Cargo area cover	5-86
Clock	5-84
Coat hook	5-84
Cup holder	5-77
Floor mat anchor(s)	5-85
Luggage net (holder)	5-86
Power outlet	5-79
Sunvisor	5-78
USB charger	5-80
Wireless mobile phone charging system	5-81
Interior overview	2-6
ISG (IDLE STOP AND GO) SYSTEM	6-42
ISG system malfunction	6-45
The battery sensor deactivation	6-46
To activate ISG system	6-42
To deactivate ISG system	6-45
J	
Jump starting	8-6
L	
Lane Following Assist (LFA)	7.42
Lane Following Assist (LFA)  Lane Following Assist malfunction and limitations	
Lane Following Assist Settings	
Turning Lane Following Assist On/Off	
Lane Keeping Assist (LKA)	
Lane Keeping Assist (LKA)  Lane Keeping Assist malfunction and limitations	
Lane Keeping Assist Control and Infiltations	
Lane Keeping Assist Operation  Lane Keeping Assist settings.	
Lane ixeeding (Xooist Settings	/-13

Light bulbs9-5	56
Headlight and front fog light aiming9-6	61
Headlight, Position Light, Turn signal Light, Fog Light and Daytime Running Light, Low Beam Assist-Static light bulb replacement9-5	
High mounted stop light replacement 9-6	
Interior light bulb replacement 9-6	
License plate light bulb replacement	
Side repeater light replacement 9-6	
Lighting	
Exterior lights 5-3	
Interior lights	
Luggage volume	14
M	
Maintenance services9-	-4
Owner maintenance precautions9-	
Owner's responsibility9-	
Manual climate control system	
Heating and air conditioning	
System maintenance	
System operation	
Manual Speed Limit Assist (MSLA)	
Manual Speed Limit Assist operation	
Manual transmission	
Good driving practices6-1	
Manual transmission operation	
Media player	
Using the media player	
Using the USB mode	
Mirrors	
Inside rearview mirror 5-2	
Outside rearview mirror 5-2	
Outside real view initial	23
0	
Owner maintenance9-	-5
Owner maintenance schedule 9-	

#### Index

P	
Pan-european eCall	5-120
SOS	
SOS Test	5-120
Pan-European eCall System	
Information on data processing	
Pan-European eCall System	
Parking brake	
R	
RADIO	5-102
Changing the radio mode	
Listening to saved radio stations	
Saving radio stations	
Scanning for available radio stations	
Searching for radio stations	
Turning on the radio	
REAR OCCUPANT ALERT (ROA)	
Rear View Monitor (RVM)	
Rear View Monitor malfunction and limitations	
Rear View Monitor Operation	7-48
Rear View Monitor settings	
Recommended lubricants and capacities	
Recommended SAE viscosity number	
Returning used vehicles	1-9
Reverse Parking Distance Warning (PDW)	7-50
Reverse Parking Distance Warning malfunction and limitations	7-51
Reverse Parking Distance Warning operation	
Reverse Parking Distance Warning settings	

### S

Safety and vehicle damage warning	3
Safety messages	1-3
Scheduled maintenance services	9-7
Seat belts	3-19
Additional seat belt safety precautions	3-27
Care of seat belts	
Pre-tensioner seat belt	3-24
Seat belt restraint system	3-22
Seat belt safety precautions	3-19
Seat belt warning light	3-20
Seats	3-4
Front seats	3-6
Head restraint	3-12
Rear seats	3-10
Safety precautions	3-5
Seat warmers	3-17
Special driving conditions	6-47
Driving at night	
Driving in flooded areas	6-48
Driving in the rain	6-48
Hazardous driving conditions	
Highway driving	
Reducing the risk of a rollover	
Rocking the vehicle	6-47
Smooth cornering	6-48
Steering wheel	
Heated steering wheel	
Horn	
Motor Driven Power Steering (MDPS)	5-21
Tilt steering / Telescope steering	
Storage compartment	
Centre console storage	
Glove box	5-76
System status icons	5-121

Т	
Theft-alarm system	9
Towing	
Emergency towing8-3	
Removable towing hook	
Towing service	2
trademarks	23
Trailer towing	6
Driving with a trailer6-6	52
If you decide to pull a trailer?6-5	57
Maintenance when towing a trailer 6-6	5
Trailer towing equipment	1
Tray	6
Two way radio installation	.2
Tyre load and speed capacity2-1	3
Tyre Pressure Monitoring System (TPMS)	0
Low tyre pressure light8-1	2
Resetting TPMS8-1	1
TPMS malfunction indicator	4
Tyres and wheels2-1	2
Tyre specification and pressure label2-1	8
Tyres and wheels	0
Check tyre inflation pressure	1
Low aspect ratio tyres9-3	8
Recommended cold tyre inflation pressures	1
Tyre care	0
Tyre maintenance	5
Tyre replacement	3
Tyre rotation9-3	2
Tyre sidewall labelling9-3	5
Tyre traction9-3	5
Wheel alignment and tyre balance9-3	3
Wheel replacement	5

V	
Vehicle Break-In Process	1-9
Vehicle certification label	
Vehicle data collection and event data recorders	
Vehicle handling instructions	
Vehicle Identification Number (VIN)	
Vehicle modifications	
Vehicle weight	
Overloading	
o veriouding.	. 0 22
W	
Warning!	3
Washer fluid	
Checking the parking brake	
Checking the washer fluid level	
Windows	
Power windows	
Windscreen defrosting and defogging	
Automatic climate control system	
Defroster	
Winter Driving	
Snow or icy conditions	
Winter Precautions	
Wiper Blades	
Blade inspection	
Blade replacement	
Wipers and washers	
Rear window wiper and washer switch	
Windscreen washers	
Windscreen wipers	